

PHILIPS

HD5850




English 3
繁體中文 11

Introduction


Congratulations on your purchase and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

General description



- 1 Cooking plate
- 2 Cooking zone (heating zone)
 - Cooking Zone Diameter: Ø 218 mm
 - For optimal heating performance and safety, always use cookware that matches the size of the cooking zone.
- 3 Air inlet
- 4 Control Panel
- 5 Air outlets
- 6 Power cord



Control Panel

- 1 Boost button
- 2 Timer Button
- 3 Increase ^ and decrease ∨ button
- 4 Power level
- 5 Child lock button
- 6 ON/OFF button
- 7 Status display
- 8 Preset cooking mode buttons

Preparing for use

- 1 Place the appliance on a dry, stable and level surface.
- 2 Make sure there is at least 10cm free space around the appliance to prevent overheating.
- 3 Always place the cookware on the cooking zone during cooking.
- 4 Make sure you use cookware of the correct types and sizes (see the tables below).

Choosing the proper cookware

Use cookware that meets below requirements:

Material	Cookware with a bottom made of iron or magnetic stainless steel
Shape	Cookware with a flat bottom

Do not use cookware described as below:

Material	Cookware with a bottom made of non-iron metal, heat resistant glass pots, ceramic, glass, aluminum or copper.
----------	---

Shape	Cookware with a concave or convex bottom
Size	Cookware with a bottom diameter of less than 12 cm or more than 26 cm

Using the appliance

Cooking power level

P1	P2	P3	P4	P5	P6	P7	P8	P9	P10
120W	300W	500W	800W	1000W	1200W	1400W	1600W	1800W	2000W

Cooking modes

Cooking modes	Default Cooking Power	Default Cooking Time	Adjustable Cooking Power	Adjustable Cooking Time
Low heat	P3	120 min	P1-P4	1-180 min
Stew	P5-P3-P2	120 min	P1-P10	1-180 min
BBQ	P6	60 min	P1-P10	1-180 min
Soup	P8-P5-P6-P2	120 min	P1-P10	1-180 min
Stir Fry	P9	60 min	P1-P10	1-180 min
Steam	P10-P6-P5	60 min	P1-P10	1-180 min
Boil	P10	15 min	P1-P10	1-180 min
Hot Pot	P10	120 min	P1-P10	1-180 min
Boost	b	60 min	P1-P10	1-180 min
Manual mode		60 min	P1-P10	1-180 min

Cooking Mode Usage

Low Heat	Used for gentle cooking or keeping food warm over extended periods. Ideal for delicate dishes and maintaining serving temperature.
Stew	Used for slow-cooked dishes like stews and braises. Follows several automatic power stages but allows manual power changes for recipe customization.
BBQ	Suitable for grilling meats and vegetables on the pan or cookware. Power is manually adjustable and remains consistent for even cooking.
Soup	Used for making soup with automatic power adjustments to maintain optimal simmering and flavor extraction. Follows several automatic power stages.


6 English

Stir Fry	Used for stir-frying with high heat and quick cooking. Power can be freely adjusted to suit different ingredients and techniques.
Steam	Used for steaming vegetables, seafood, and other items while preserving nutrients and texture.
Boil	Used for boiling water or food items. Starts at default power and allows manual adjustment of temperature and time for precise cooking.
Hot Pot	Used for hot pot meals with high initial power. Allows manual adjustment to maintain boiling and accommodate various ingredients.
Boost	Provides high heat quickly for searing or rapid cooking. Suitable for tasks requiring immediate high temperature.
Manual Mode	Allows manual setting of power level using increase or decrease buttons. Suitable for users who prefer full control over cooking settings.


Using the preset cooking modes

There are eight preset cooking modes: Low Heat, Stew, BBQ, Soup, Stir fry, Steam, Boil and Hot pot.

- 1 Follow the steps in "Preparing for use".
- 2 Press the ON/OFF button to switch on the appliance.
 - The ON/OFF indicator lights up.




- 3 Press the button of the desired cooking mode.
 - The corresponding indicator lights up.
 - To increase or decrease cooking power, press \wedge or \vee .
 - The appliance starts working in the selected mode.



- 4 When the cooking is finished, press the ON/OFF button to switch off the appliance.
- 5 Unplug the appliance after the fan stops working.



During cooking, you can change the power level by pressing the increase and decrease button.




The time for induction cooking may be less than the time taken on a gas stove. Make sure that you keep all the ingredients you need ready before you start cooking.

Using the manual cooking mode


- 1 Follow the steps in "Preparing for use".
- 2 Press the ON/OFF button to switch on the appliance.
 - The ON/OFF indicator lights up.



- 3 Press ^ and v to increase or decrease the cooking power.
 - The appliance starts working at the selected cooking power.




- 4 When the cooking is finished, press the ON/OFF button to switch off the appliance.
- 5 Unplug the appliance after the fan stops working.




Using the Timer function

You can use the **Timer** button to decide how much time you want the appliance to work at different cooking modes.


- 1 Follow the steps in "Preparing for use".
- 2 Press the ON/OFF button.
 - The ON/OFF indicator lights up.




- 3 Press the button of the desired cooking mode.
 - The corresponding indicator lights up.




- 4 Press the **Timer** button.
 - The timer indicator lights up.




- 5 Press **^** and **∨** to adjust the cooking time.
 - Short press: increase or decrease by 1 minute.
 - Long press: increase or decrease in 5-minute increments.






- 6** Press the **Timer** button again to confirm your selection.
- The appliance starts working in the selected mode after the cooking time is set.

Using the Child lock function



You can use the **Child Lock** button to lock the control panel to prevent accidental operation.

- 1** Press the **Child Lock** button during any cooking mode or after cooking to activate the lock.
- 2** When the Child Lock is on, you can still use the ON/OFF button. All other buttons are disabled to prevent accidental use.



- 3** To deactivate this function, press and hold the **Child Lock** button for 3 seconds until the lock is released.

Cleaning

Unplug the appliance 3 minutes after the cooking is finished and let it cool down.

Clean the appliance with a damp cloth and, if necessary, with some mild cleaning agent.

Do not unplug the appliance before the fan stops working.

Never immerse the appliance in water nor rinse it under the tap.

Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.

Do not put vinegar on the cooking plate.

Maintenance

Improper use can lead to scratches on the cooking plate. To avoid discoloring and scratches, use the appliance according to the instructions in this user manual and always clean the appliance and cookware properly after use.

Storage

Do not place heavy objects on the cooking plate as it is breakable.

Do not store the appliance in a hot place, for example near a cooker.


If you are not going to use the appliance for a longer period of time, store the appliance in a cool and dry place.

簡介


感謝您購買本產品。歡迎來到飛利浦的世界！

請至 www.philips.com/welcome 註冊您的產品，以獲得飛利浦提供的完整支援。

一般說明



- 1 加熱面板
- 2 烹調區 (加熱區)
 - 烹調區尺寸：直徑 218 公釐
 - 為獲得最佳加熱效果和使用安全，請務必使用與烹調區尺寸相符的鍋具。
- 3 進風口
- 4 控制面板
- 5 出風口
- 6 電源線



控制面板

- 1 強力按鈕
- 2 定時功能按鈕
- 3 增加 ^ 和減少 v 按鈕
- 4 功率等級
- 5 兒童鎖按鈕
- 6 ON/OFF (開/關) 按鈕
- 7 狀態顯示幕
- 8 預設烹調模式按鈕

使用前準備

- 1 將產品放在乾燥、穩固且水平的表面上。
- 2 確保產品周圍至少有 10 公分的空間，以防止過熱。
- 3 烹煮時，請務必將鍋具放在烹調區上。
- 4 請務必使用尺寸和類型都正確的鍋具 (請參閱下方表格)。

選擇合適的鍋具

請使用符合以下要求的鍋具：

材質	鍋具底部應由鐵質或具磁性的不鏽鋼材質製成
形狀	底部平坦的鍋具

請勿使用以下類型的鍋具：

材質	底部為非鐵金屬、耐熱玻璃鍋、陶瓷、玻璃、鋁或銅等材質的鍋具。
形狀	底部為內凹或外凸形狀的鍋具
尺寸	底部直徑小於 12 公分或大於 26 公分的鍋具

使用產品

烹煮功率等級

P1	P2	P3	P4	P5	P6	P7	P8	P9	P10
120W	300W	500W	800W	1000W	1200W	1400W	1600W	1800W	2000W

烹調模式

烹調模式	預設烹調功率	預設烹調時間	可調式烹調功率	可調式烹調時間
低火	P3	120 分鐘	P1-P4	1-180 分鐘
燉煮	P5-P3-P2	120 分鐘	P1-P10	1-180 分鐘
烤肉	P6	60 分鐘	P1-P10	1-180 分鐘
湯	P8-P5-P6-P2	120 分鐘	P1-P10	1-180 分鐘
大火快炒	P9	60 分鐘	P1-P10	1-180 分鐘
蒸煮	P10-P6-P5	60 分鐘	P1-P10	1-180 分鐘
煮沸	P10	15 分鐘	P1-P10	1-180 分鐘
火鍋	P10	120 分鐘	P1-P10	1-180 分鐘
Boost (強力)	b	60 分鐘	P1-P10	1-180 分鐘
手動模式		60 分鐘	P1-P10	1-180 分鐘


烹調模式	使用
低火	用於溫和烹調或長時間保溫。適合烹煮精緻料理與維持上菜溫度。
燉煮	用於燉菜、紅燒等慢煮料理。此模式包含數個自動功率階段，但亦可手動調整功率以配合食譜需求。
烤肉	適合用於在鍋具或鍋子烤肉或烤蔬菜。功率可手動調整，並能維持穩定加熱以確保均勻烹調。
湯	用於熬煮湯品，會自動調整功率以維持最佳的微滾狀態和風味萃取。此模式包含數個自動功率階段。
大火快炒	用於大火快炒，適合高溫加熱和快速烹調。功率可自由調整，以配合不同食材和烹飪技巧。
蒸煮	用於蒸煮蔬菜、海鮮及其他食材，能保留營養及口感。
煮沸	用於煮水或煮食材。以預設功率啟動，並可手動調整溫度和時間，以達到精準烹調效果。
火鍋	適用於火鍋料理，啟動時以高功率加熱。可手動調整火力，以維持沸騰並適應各種食材需求。

Boost (強力)	可迅速提供高溫，用於煎焦或快速烹調。適合需要高溫快煮或瞬間加熱的料理。
手動模式	可使用增加或減少按鈕手動設定功率等級。適合希望完全掌控烹調設定的使用者。


使用預設烹調模式

共有八種預設烹調模式：低火、燉煮、烤肉、湯品、大火快炒、蒸煮、煮沸和火鍋。

- 1 請依照「使用前準備」中的步驟操作。
- 2 按下「ON/OFF」(開/關) 按鈕，開啟產品電源。
 - 電源指示燈會亮起。



- 3 按下所需烹調模式的按鈕。
 - 對應的指示燈亮起。
 - 若要增加或減少烹調功率，請按下 ^ 或 v。
 - 產品會開始執行所選的模式。




- 4 烹調完成後，請按下「ON/OFF」(開/關) 按鈕以關閉產品。
- 5 當風扇停止運轉後，請拔除產品電源插頭。


在烹調過程中，您可隨時按下增加和減少按鈕以變更功率等級。

使用感應加熱的烹調時間可能比瓦斯爐更短。請在開始烹調前，確保所有食材皆已準備妥當。


使用手動烹調模式 - TW

- 1 請依照「使用前準備」中的步驟操作。







- 2 按下「ON/OFF」(開/關) 按鈕，開啟產品電源。
 - 電源指示燈會亮起。



- 3 按下 ^ 和 v 以增加或減少烹調功率。
 - 產品會以所選的烹調功率開始運作。



- 4 烹調完成後，請按下「ON/OFF」(開/關) 按鈕以關閉產品。
- 5 當風扇停止運轉後，請拔除產品電源插頭。




使用定時功能


您可以使用 **Timer** (定時功能) 按鈕來設定產品在不同烹調模式下的運作時間。

- 1 請依照「使用前準備」中的步驟操作。


16 繁體中文




- 2 按下「ON/OFF」(開/關) 按鈕。
 - 電源指示燈會亮起。




- 3 按下所需烹調模式的按鈕。
 - 對應的指示燈亮起。



- 4 按下 **Timer** (定時功能) 按鈕。
 - 定時功能指示燈亮起。





- 5 按下 \wedge 和 \vee 以調整烹調時間。
 - 短按：增加或減少 1 分鐘。
 - 長按：以 5 分鐘為單位增加或減少。



- 6 再次按下 **Timer** (定時功能) 按鈕以確認選擇。
 - 設定烹調時間後，產品會開始執行所選的模式。

使用兒童安全鎖功能



您可以使用 **Child Lock** (兒童安全鎖) 按鈕鎖定控制面板，以防止意外操作。

- 1 在任何烹調模式下或烹調結束後，按下 **Child Lock** (兒童安全鎖) 按鈕可啟動鎖定功能。
- 2 當「Child Lock」(兒童安全鎖) 啟用時，您仍可使用「ON/OFF」(開/關) 按鈕，但其他按鈕皆會停用，以防止誤用。
- 3 若要關閉此功能，請長按 **Child Lock** (兒童安全鎖) 按鈕 3 秒鐘，直到解除鎖定為止。

清潔

烹調完成後，請在 3 分鐘後拔除電源插頭，讓產品冷卻下來。
使用微濕的布清潔產品表面，必要時可搭配溫和的清潔劑。

請在風扇停止運轉後，再拔除電源插頭。

切勿將產品浸泡在水中，或者在水龍頭下沖洗。

切勿使用鋼絲絨、磨蝕性清潔劑或侵蝕性的液體 (例如汽油或丙酮) 清潔產品。

請勿將醋倒在加熱面板上。

維護

不當使用可能會導致加熱面板出現刮痕。為避免變色或刮傷，請依照本使用手冊中的指示正確操作，並在每次使用後妥善清潔產品和鍋具。

收納

請勿在加熱面板上放置重物，因為面板易碎。
請勿將產品存放於高溫環境中，例如爐具旁。

若長時間不使用，請將產品存放在陰涼乾燥之處。

2026 © Versuni Holding B.V.

PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Versuni Holding B.V., and Versuni Holding B.V. is the warrantor in relation to this product.



100% 
www.home.id