



PHILIPS



Specifications are subject to change without notice
© 2015 Koninklijke Philips N.V.
All rights reserved.

HD3160_UM_KO_V1.0



English

1 Your multicooker

Congratulations on your purchase, and welcome to Philips!
To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

2 Important

Please read this safety leaflet carefully before you use the multi-cooker and save it for future reference.

Danger





- Do not immerse the multi-cooker in water; nor rinse it under the tap.

Warning

- This appliance shall not be used by children from 0 year to 8 years. This appliance can be used by children aged from 8 years and above if they are continuously supervised. This appliance can be used by people with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children.
- Children shall not play with the appliance.
- Cooking appliances should be positioned in a stable situation with the handles (if any) positioned to avoid spillage of the hot liquids.
- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
- Make sure that the damaged power cord is replaced by Philips, a service center authorized by Philips or similarly qualified persons in order to avoid a hazard.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- Check if the voltage indicated on the multi-cooker corresponds to the local power voltage before you connect it.
- Only connect the multi-cooker to a grounded power outlet. Always make sure that the plug is inserted firmly into the power outlet.
- Do not use the appliance if the plug, the power cord, the inner pot, the sealing ring, or the main body is damaged.
- Do not let the power cord hang over the edge of the table or worktop on which the multi-cooker stands.
- Make sure the heating element, the temperature sensor, and the outside of the inner pot are clean and dry before you put the plug in the power outlet.
- Make sure the heating element, the temperature sensor, and the outside of the inner pot are clean and dry before you put the plug in the power outlet.
- Pay attention to avoid spillage on the power cord when using this appliance.
- Do not misuse the appliance to avoid injury.
- Always cool it down enough before storage.

Caution

- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.



4 Overview

Product overview (fig. 2)

8 Steam valve	13 Heating element
9 Lid release button	14 Cooker handle
10 Control panel	15 Water level indicators
11 Main unit	16 Inner pot
12 Power socket	17 Detachable inner lid

Controls overview (fig. 3)

18 Display screen	22 Menu button
19 Preset button	23 Warm/Off button
20 Cooking time button	24 Start button
21 Reheat button	

Cooking time regulating range

Program	Default cooking time	Time regulation	Preset time
Rice (밥)	35 min	N/A	1-24 hr
Soup (국)	2 hr	1-4 hr	1-24 hr
Congee (죽)	2 hr	1-4 hr	1-24 hr
Stew (찌개)	2 hr	1-4 hr	1-24 hr
Yogurt (요거트)	6 hr	4-12 hr	N/A
Reheat (재가열)	25 min	25-59 min	N/A
Risottos (리조토)	1 hr 20 min	N/A	1-24 hr
Warm/Off (보온/취소)	N/A	Activated automatically after cooking functions are finished (excluding yogurt)	

5 Using the multicooker

Before first use



- Take out all the accessories from the inner pot. Remove all packaging materials of the inner pot.
- Clean the parts of the multicooker thoroughly before using the multicooker for the first time (see chapter "Cleaning").

Note

- Make sure all parts are completely dry before you start using the multicooker.

Cooking rice (fig. 4 & 5)

- Measure the rice using the measuring cup provided.
- Wash away the dusts and bran of the rice with tap water.
- Put the pre-washed rice in the inner pot.
- Add water to the level indicated on the scale inside the inner pot that corresponds to the number of cups of rice used. Then smooth the rice surface.



For instance, if you cook 4 cups of rice, add water up to the 4-cup level indicated on the scale.

Note

- The level marked inside the inner pot is just an indication; you can always adjust the water level for different types of rice and your own preference.
- Besides following the water level indications, you may also add rice and water at 1:1-1.2 ratio for rice cooking.
- Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the multicooker to overflow and cause potential hazard.

- Press the lid release button to open the lid.
- Wipe the outside of the inner pot dry, then put it in the multicooker. Check if the inner pot is in proper contact with the heating element.

Note

- Make sure that the outside of the inner pot is dry and clean, and that there is no foreign residue on the heating element.

- Close the lid of the multicooker, and put the plug in the power socket.
- Press the menu button (메뉴) until the desired cooking function is selected.
- Press and hold the start button (취사) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep-warm mode automatically. The keep-warm indicator (취사) lights up.

Note



- After the cooking is finished, stir the rice and loosen it immediately to release excessive moisture for fluffy rice.
- Depending on the cooking conditions, the bottom portion of the rice may become slightly browned.

Making soup (fig. 6)

- Put ingredients and water into the inner pot.
- Follow steps 6 and 7 in "Cooking rice".
- Press the menu button (메뉴) until the desired cooking function is selected.
 - To set a different cooking time, refer to chapter "Adjusting the cooking time".
- Press and hold the start button (취사) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep-warm mode automatically. The keep-warm indicator (취사) lights up.

Cooking congee (fig. 6)

- Follow steps 1 to 7 in "Cooking rice".
- Note
- Do not exceed the maximum water level indicated in the inner pot, as this may cause the multicooker to overflow.



Tip

- Besides following the water level indications, you may also add rice and water at 1:4 ratio for congee cooking.

- Press the menu button (메뉴) until the desired cooking function is selected.
 - To set a different cooking time, refer to chapter "Adjusting the cooking time".
- Press and hold the start button (취사) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep-warm mode automatically. The keep-warm indicator (취사) lights up.

Stewing (fig. 6)


- Put the food and ingredients in the inner pot.
- Follow steps 6 and 7 in "Cooking rice".
- Press the menu button (메뉴) until the desired cooking function is selected.
 - To set a different cooking time, refer to chapter "Adjusting the cooking time".
- Press and hold the start button (취사) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep-warm mode automatically. The keep-warm indicator (취사) lights up.

Making yogurt (fig. 7)

- Whisk the ingredients for the yogurt well and put them in the yogurt cups provided.
- Put the yogurt cups in the inner pot. Make sure that yogurt cups sealed.
- Pour some water in the inner pot. Make sure that half of the yogurt cups are immersed in water.
- Follow steps 6 and 7 in "Cooking rice".
- Press the menu button (메뉴) until the desired cooking function is selected.
 - To set a different cooking time, refer to chapter "Adjusting the cooking time".
- Press and hold the start button (취사) for 3 seconds to start cooking.
- When the cooking is finished, the multicooker beeps and switches to stand by mode automatically.

Cooking risottos (fig. 8)

- Follow steps 1 to 7 in "Cooking rice".
- Press the menu button (메뉴) until the desired cooking function is selected.
- Press and hold the start button (취사) for 3 seconds to start cooking.
- When the rice is ready, the multicooker beeps for a while.
- Add the ingredients for risottos by placing them on top of the rice. Close the lid to resume the cooking process.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep-warm mode automatically. The keep-warm indicator (취사) lights up.



Reheating (fig. 9)

- Loosen the cooled rice and evenly distribute it in the inner pot.
- Pour some water onto the rice to prevent it from becoming too dry. The quantity of the water depends on the amount of rice.
- Follow steps 6 and 7 in "Cooking rice".
- Press the reheating button (재가열).
 - To set a different cooking time, refer to chapter "Adjusting the cooking time".
- Press and hold the start button (취사) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep-warm mode automatically. The keep-warm indicator (취사) lights up.

Adjusting the cooking time (fig. 10 & 11)

- You can adjust the cooking time for reheat, yogurt, congee, soup and stew. Refer to the "Functions overview" table for the time regulation of each function.
- After you have selected the desired cooking function using the menu button, the default cooking time will be displayed on the screen.
- To set a different cooking time, press the cooking time button (00:00), and the hour unit starts flashing on the display.
 - Press the cooking time button repeatedly to set the hour unit.
 - After the hour unit is set, wait for a few seconds before the hour unit is confirmed, and the minute unit starts flashing on the display.
 - Press the cooking time button repeatedly to set the minute unit.

Preset time for delayed cooking (fig. 12)

- You can preset the delayed cooking time in different cooking modes. The preset timer is available from 1 to 24 hours.
- Press the menu button (메뉴) until the desired cooking function is displayed on the screen.
 - The preset time is displayed on the screen, and the hour unit starts flashing.
 - Press the preset time button (00:00) repeatedly to set the hour unit.
 - When the hour unit is set, wait for a few seconds before the hour unit is confirmed, and the minute unit starts flashing on the display.
 - Press the preset time button (00:00) repeatedly to set the minute unit.
 - After the minute unit is set, press and hold the start button (취사) for 3 seconds to confirm the preset timer.
 - The preset indicator lights up in yellow when the preset timer is activated. It turns blue when the preset time has elapsed.
 - The cooking will be finished when the preset time has elapsed. The multicooker beeps and switches to keep-warm or standby mode automatically.

Note

- The preset timer is not available in yogurt and reheat mode.
- If the preset time is shorter than the cooking time, the multicooker will start the cooking process immediately.

