

**ENGLISH****Introduction**

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](http://www.philips.com/welcome).

**Important**

Read this important information carefully before you use the appliance and save it for future reference.

**Danger**

- Always put the ingredients to be fried in the basket, to prevent them from coming into contact with the heating elements.
- Do not cover the air inlet and the air outlet openings while the appliance is operating.
- Do not use oil with oil as this may cause a fire hazard.
- Never immerse the appliance in water or any other liquid, nor rinse it under the tap.
- Do not let any water or other liquid enter the appliance to prevent electric shock.
- Never put any amount of food that exceeds the maximum level indicated in the basket.
- Never touch the inside of the appliance while it is operating.

**Warning**

Check the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance. Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.

If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Keep the appliance and its cord out of the reach of children.

Keep the mains cord away from hot surfaces.

Only connect the appliance to an earthed wall socket. Always make sure that the plug is inserted into the wall socket properly. This applies to all electrical appliances. Do not open the covers of an external timer or a separate remote-control system.

Do not place the appliance against a wall or against other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance. Do not place anything on top of the appliance.

Do not use the appliance for any other purpose than described in the user manual.

During hot frying, hot steam is released through the outlet openings. Please exercise care at a safe distance from the steam and from the air outlet opening. Also be careful of hot steam and air when you remove the pan from the appliance.

The accessible surfaces may become hot during use. (fig. 1)

The pan, basket and accessories inside the Airfryer become hot during use. Be careful when you handle them.

Do not place the appliance on or near a hot gas stove or all kinds of electric stoves and electric cooking plates, or in a heated oven.

Never use live ingredients or baking paper in the appliance.

Do not use the appliance on or near combustible materials such as a tablecloth or curtain.

Do not let the appliance operate unattended.

Immediately unplug the appliance if you see dark smoke coming out of the appliance. Wait for the smoke emission to stop before you pull the pan out of the appliance.

Storage of potatoes: The temperature shall be appropriate to the potato variety stored and it shall be above 6°C to minimize the risk of acrylamide exposure in the prepared foodstuff.

Do not plug in the appliance or operate the control panel with wet hands.

**Caution**

This appliance is intended for normal household use only. It is not intended for use in environments such as staff kitchens of shops, offices, farms or other work environments. Nor is it intended to be used by clients in hotels, motels, bed and breakfasts and other residential environments.

Always return the appliance to a service centre authorised by Philips for repair or maintenance. Do not repair the appliance yourself otherwise the guarantee becomes invalid.

If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and Philips refuses any liability for damage caused.

Always place and use the appliance on a dry, stable, level and horizontal surface.

Always unplug the appliance after use.

Make sure the ingredients prepared in this appliance come out golden-yellow instead of dark or brown. Remove burnt remnants. Do not fry fresh potatoes at a temperature above 180°C (to minimise the production of acrylamide).

Be careful when cleaning the upper area of the cooking chamber: Hot heating element, edge of metal parts.

**Electromagnetic fields (EMF)**

This Philips appliance complies with all applicable standards and regulations regarding electromagnetic fields.

**Recycling**

Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

**Guarantee and support**

If you have need information or support, please visit:

[www.philips.com/support](http://www.philips.com/support) or read the separate worldwide guarantee leaflet.

**Troubleshooting**

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, visit [www.philips.com/support](http://www.philips.com/support) for a list of frequently asked questions or contact the Consumer Care Centre in your country.

Problem	Possible cause	Solution
The outside of the appliance becomes hot during use.	This is normal. All handles and knobs that you need to touch during use stay cool enough to touch.	

The pan, the basket, and the inside of the appliance always become hot when the appliance is switched on to ensure the food is properly cooked. These parts are always too hot to touch.		
--	--	--

If you leave the appliance switched on for a longer time, some areas get too hot to touch. These areas are marked on the appliance with the following icon:		
---	--	--

You did not use the right potato type.		
--	--	--

The amount of ingredients in the basket is too big.		
---	--	--

Certain types of ingredients need to be shaken halfway through the cooking time.		
--	--	--

Problem	Possible cause	Solution
The Airfryer does not switch on.	The appliance is not plugged in.	Check if the plug is inserted in the wall outlet properly.
Several appliances are connected to one outlet.	The Airfryer has a high wattage. Try a different outlet and check the fuses.	
I see some peeling off spots inside my Airfryer.	Some small spots can appear inside the pan of the Airfryer due to the incidental touching or scratching of the coating (e.g. during cleaning with cleaning tools and/or while inserting the basket).	You can prevent damage by lowering the basket into the pan properly if you insert the basket at an angle; its side may knock against the wall of the pan, causing small pieces of coating to chip off. If this occurs, please be informed that this is not harmful as all materials used are food-safe.
White smoke comes out of the appliance.	You are cooking fatty ingredients.	Briefly pour off any excess oil or fat from the pan and then continue cooking.
The pan still contains greasy residues from previous use.	White smoke is caused by greasy residues heating up in the pan. Always clean the pan and the basket thoroughly after every use.	
Breading or coating did not adhere properly to the food.	Using a flat pan will result in breading or coating causing white smoke. Firmly press breading or coating to food to ensure it sticks.	
My display shows 6 dashes during cooking.	Marinade, liquid or meat juices are splattering on the rendered fat or grease.	Pat food dry before placing it in the basket.
My display shows 6 dashes after the appliance has been unplugged for one minute.	Safety feature has been activated.	Unplug the appliance and let it cool down for 1 minute before plugging in again.
My display shows 6 dashes after the appliance has been unplugged for one minute.	Safety feature has been activated.	Call the Philips service hot line or contact the Consumer Care Center in your country.

Problem	Possible cause	Solution
Kentang goreng ralhan yang tidak sesuai dengan harapan saya.	Anda tidak mendapatkan kentang yang tepat.	Untuk mendapatkan hasil yang benar dan kentang yang sesuai dengan harapan anda, ikuti petunjuk dalam petunjuk penggunaan.
Takaran bahan dalam kerangjan terlalu banyak.	Jangan terlalu tambah masakan udara dalam lubang keluar udara selagi kerangjan dibuat.	Ikti petunjuk dalam petunjuk penggunaan untuk membuat kentang goreng di rumah.
Jenis bahan tertentu perlu digoyang-goyang sedikit selama waktu memasak.	Jangan sekali-kali merendam alat di dalam air atau cairan apapun, jangan pulah membilasnya di bawah keran.	Ikuti petunjuk dalam petunjuk penggunaan untuk membuat kentang goreng di rumah.
Airfyer tidak dapat diketik.	Steker alat tidak ditarikkan.	Periksa apakah steker telah dipasang dengan benar pada stopkontak dinding.
Saya masih ada beberapa titik yang terkelupas di dalam Airfyer.	Beberapa titik kecil dapat hilang di dalam Airfyer karena sentuhan yang tidak disengaja atau goresan pada lapisan (misalkan selama pembersihan dengan alat pembersih yang kasar dan/atau ketika memasukkan kerangjan).	Anda dapat mencegah kerusakan permanen dan menurunkan kerangjan ke panas yang berlebihan jika Anda menghirauinya.
Asap putih keluar dari alat.	Asap putih keluar dari alat.	Periksa apakah steker telah dipasang dengan benar pada stopkontak dinding.
Layar menampilkan 6 tanda pilih selama memasak.	Fitur pengaman telah diketikkan dengan benar pada kerangjan.	Potongan kecil dari pelapis tidak melekat dengan benar pada kerangjan.
Layar menampilkan 6 tanda pilih selama memasak.	Fitur keamanan telah diketikkan dengan benar pada kerangjan.	Tepuk-tepuk makarna hingga segera meletakkan pada kerangjan.
My home-made fries do not turn out as I expected.	As you are aware, the hot area of the steker could touch them, the appliance is completed safe to use.	Cabut steker alat lalu biarkan dingin selama 1 menit sebelum ditarikkan kembali.
The heat inside the outside walls becomes hot during use.	The heat inside radiates to the outside walls.	Fitur pengaman telah diketikkan dengan benar pada kerangjan.
The pan, the basket, and the inside of the appliance always become hot when the appliance is switched on to ensure the food is properly cooked. These parts are always too hot to touch.		
If you leave the appliance switched on for a longer time, some areas get too hot to touch. These areas are marked on the appliance with the following icon:		
You did not use the right potato type.		
The amount of ingredients in the basket is too big.		
Certain types of ingredients need to be shaken halfway through the cooking time.		

Problem	Possible cause	Solution
Biaran alat mendingin selama kira-kira 30 minit sebelum Anda menggunakan atau membersihkannya.	Postikan bahan yang ditambah dalam alat ini matang dengan wama kuning keemasan, bukan kehitaman atau kecokelatan. Buang sisa makanan yang gosong. Jangan mengoreng kentang segar dengan suhu di atas 180°C (untuk meminimumkan produksi senyawa akrilida).	
Berhati-hati ketika membersihkan bagian atas ruang pemasak terhadap elemen pemanas, pinggar komponen logam.	Alat Philips ini telah memenuhi semua standar dan peraturan yang berlaku terhadap teknologi elektromagnetik.	
<b>Mendaur ulang</b>	<b>Jangan</b> membanding alat bersama limbah rumah tangga biasa jika alat sudah tidak bisa dipakai lagi, tetapi serahkanlah ke titik sampah khas. Selain itu, alat ini boleh dimuatkan dalam kemasan plastik dan melanjutkan hidupnya.	<b>Menggunakan</b> plastik dan kertas dalam kemasan plastik dan melanjutkan hidupnya.
<b>Garansi dan dukungan</b>	Jika Anda membutuhkan informasi atau dukungan, harap kunjungi <a href="http://www.philips.com/support">www.philips.com/support</a> atau baca pamflet garansi internasional terpisah.	
<b>Penyelesaian masalah</b>	Babi ini merangkum berbagai masalah paling umum yang mungkin Anda temui pada alat. Jika Anda tidak dapat mengatasi masalah ini, silakan hubungi <a href="http://www.philips.com/support">www.philips.com/support</a> atau baca pamflet garansi internasional terpisah.	
<b>Masalah</b>	<b>Kemungkinan</b>	<b>Solusi</b>
Babi luar atau akan menjadi panas sewaktu digunakan.	Panas di bagian dalam akan memancarkan kepanasan ke bagian luar.	Hal ini normal. Semua gegang dan kerap yang perlu Anda pegang selama penggunaan akan cukup dingin untuk disentuh.
My display shows 6 dashes during cooking.	Safety feature has been activated due to overheating of the appliance.	Unplug the appliance and let it cool down for 1 minute before plugging in again.
My display shows 6 dashes after the appliance has been unplugged for one minute.	Safety feature has been activated.	Call the Philips service hot line or contact the Consumer Care Center in your country.

Problem	Possible cause	Solution
Anda tidak mendapatkan kentang yang sesuai dengan harapan saya.	Anda tidak mendapatkan kentang yang sesuai dengan harapan saya.	Untuk mendapatkan hasil yang benar dan kentang yang sesuai dengan harapan anda, ikuti petunjuk dalam petunjuk penggunaan.
Takaran bahan dalam kerangjan terlalu banyak.	Jangan terlalu tambah masakan udara dalam lubang keluar udara selagi kerangjan dibuat.	Ikti petunjuk dalam petunjuk penggunaan untuk membuat kentang goreng di rumah.
Jenis bahan tertentu perlu digoyang-goyang sedikit selama waktu memasak.	Jangan sekali-kali merendam alat di dalam air atau cairan apapun, jangan pulah membilasnya di bawah keran.	Ikuti petunjuk dalam petunjuk penggunaan untuk membuat kentang goreng di rumah.
Airfyer tidak dapat diketik.	Steker alat tidak ditarikkan.	Periksa apakah steker telah dipasang dengan benar pada stopkontak dinding.
Beberapa titik yang terkelupas di dalam Airfyer.	Beberapa titik kecil dapat hilang di dalam Airfyer karena sentuhan yang tidak disengaja atau goresan pada lapisan (misalkan selama pembersihan dengan alat pembersih yang kasar dan/atau ketika memasukkan kerangjan).	Anda dapat mencegah kerusakan permanen dan menurunkan kerangjan ke panas yang berlebihan jika Anda menghirauinya.
Asap putih keluar dari alat.	Asap putih keluar dari alat.	Periksa apakah steker telah dipasang dengan benar pada stopkontak dinding.
Layar menampilkan 6 tanda pilih selama memasak.	Fitur pengaman telah diketikkan dengan benar pada kerangjan.	Potongan kecil dari pelapis tidak melekat dengan benar pada kerangjan.
Layar menampilkan 6 tanda pilih selama memasak.	Fitur keamanan telah diketikkan dengan benar pada kerangjan.	Tepuk-tepuk makarna hingga segera meletakkan pada kerangjan.
My home-made fries do not turn out as I expected.	As you are aware, the hot area of the steker could touch them, the appliance is completed safe to use.	Cabut steker alat lalu biarkan dingin selama 1 minit sebelum ditarikkan kembali.
The heat inside the outside walls becomes hot during use.	The heat inside radiates to the outside walls.	Fitur pengaman telah diketikkan dengan benar pada kerangjan.
The pan, the basket, and the inside		

