







EN	User manual	LT	Vartotojo vadovas
BG	Ръководство за потребителя	LV	Lietotāja rokasgrāmata
CS	Příručka pro uživatele	PL	Instrukcja obsługi
ET	Kasutusjuhend	RO	Manual de utilizare
HR	Korisnički priručnik	SK	Priručka užívateľa
HU	Felhasználói kézikönyv	SL	Uporabniški priročnik
KK	Колданушынын нускасы	SR	Korisnički priručnik



© 2017 Koninklijke Philips N.V.
All rights reserved.
3140 035 32933



English

1 Important

Read this user manual carefully before you use the appliance, and save the user manual for future reference.

Danger

- Never immerse the body of the breadmaker in water or any other liquid, nor rinse it under the tap.
- Do not cover the steam and air vents while the breadmaker is operating.

Warning

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or metal capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years. Do not let the mains cord hang over the edge of the table or worktop on which the appliance stands.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- The appliance is not intended to be operated by means of an external timer or a separate remote control system.
- The accessible surfaces may become hot during use.

- Do not put over 560 g flour, and 9 g, 12 g, 14 g yeast for general bread, super rapid bread, and Easter cake programs respectively.
- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Only connect the appliance to an earthed wall socket. Always make sure that the plug is inserted firmly into the wall socket.
- Do not use the appliance if the plug, the mains cord, the body of the appliance or the bread pan is damaged.
- Make sure that the heating element, the rotating shaft of the bread pan and the outside of the bread pan are clean and dry before you put the plug in the wall socket.
- Do not use the appliance for any other purpose than described in this manual.
- Do not plug in the appliance or operate the control panel with wet hands.
- Do not come near the steam and air vents with your face or hands when the appliance is operating.
- Do not open the lid during the baking process, as this may cause the dough or bread to collapse.
- During the baking process, the appliance itself and the lid become extremely hot. Be careful not to burn yourself.
- Do not remove the bread pan from the appliance during use.

- Never use any utensils to mix the ingredients in the bread pan during a baking program.
- Only put ingredients in the bread pan. Do not put or spill any ingredients and/or additives in the inside of the appliance to avoid damage to the heating element.
- When you remove jam from the bread pan, lift the bread pan with both hands in oven mitts to pour out the hot jam.

Caution

- This appliance is intended for household use only. If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and Philips refuses any liability for damage caused.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not touch the bread pan with sharp utensils to avoid damage.
- Do not expose the appliance to high temperatures, nor place it on a working or still hot stove or cooker.
- Always place the appliance on a stable, level and horizontal surface.
- Always put the bread pan in the appliance before you put the plug in the wall socket and switch on the appliance.
- Always unplug the appliance after use.
- Always let the appliance cool down before you clean or move it.
- Do not place the bread pan in a conventional oven to bake bread.
- The accessible surfaces may become hot when the appliance is operating. Always use oven mitts when you lift the bread pan by its handle or when you handle the hot bread pan, the kneading blade or the hot bread.
- Beware of the hot steam that comes out of the steam vents during baking or out of the breadmaker when you open the lid during or after the baking process.
- Do not lift and move the appliance while it is operating.
- Do not touch moving parts. Do not expose the appliance to direct sunlight.
- Do not insert metallic objects or alien substances into the steam vents.
- Do not use the bread pan if it is damaged.
- Always clean the appliance after use.
- Do not clean the appliance in the dishwasher.
- Do not use the appliance outdoors.
- Leave a free space of at least 10cm above, behind and on both sides of the appliance to prevent damage due to radiated heat.
- To avoid damage to the appliance, do not place the bread pan or any other object on top of the appliance.

Recycling

This symbol means that this product shall not be disposed of with normal household waste (2012/19/EU). Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.



Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

Power failure backup

This appliance has a backup function that remembers the status before a power failure, provided the power supply resumes within 10 minutes. If the power failure occurs during a cooking process, the countdown of the cooking time continues where it left off when the power supply resumes. If the power failure lasts longer than 10 minutes and the failure occurs during a cooking process, the breadmaker automatically resets to the preset setting when the power supply resumes. Open the breadmaker, remove its contents and start all over again. If you have set the timer and the preset cooking process has not yet started when a power failure occurs, the breadmaker automatically resets to the preset setting when the power supply resumes. Open the breadmaker, remove its contents and start all over again.

2 Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

3 Your breadmaker

Main unit

1 Viewing window	3 Control panel
2 Cover lid	4 Mains plug

Control panel

1 CYCLE	5 Preset timer: preset time for delayed baking
2 Loaf weight: to select bread loaf weight	6 Program menu: to select a baking program
3 Crust color: to select a crust color (light/medium/dark)	7 Start/stop/cancel button: to start or stop bread making process
4 LCD status display	

CYCLE: cycle button allows you to select and set processing steps in the homemade mode. For details, see the homemade program in the recipe book.

Accessories

1 Kneading blade	4 Measuring spoon
2 Bread pan	5 Measuring cup
3 Hook	6 Yoghurt container with lid (HD9046 only)

4 Use your breadmaker

Before the first use

- Remove all packaging material from the appliance. Be careful not to throw away the kneading blade.
- Remove any labels from the body of the appliance.
- To remove any dust that may have accumulated on the appliance, wipe the outside of the appliance, the bread pan and the kneading blade with a damp cloth.

Note

- Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.
- Dry all parts thoroughly before you start to use the appliance.




Prepare your breadmaker and ingredients

- Put your breadmaker on a stable, horizontal and level surface.
- Turn the bread pan anticlockwise and lift it out.
- Push the kneading blade firmly onto the shaft.
- Measure the ingredients for the recipe you want to prepare (see the recipes booklet).
 - Always measure ingredients accurately.
 - All ingredients should be at room temperature unless recipe suggests otherwise.
- Put ingredients in the bread pan in the order they are listed in the recipe.
 - Always add liquid ingredient first, and then add dry ingredients.
 - Do not let the yeast touch the salt.

Note

- Do not add more quantities than mentioned in the recipe as it may damage the breadmaker.
- Always use active dry yeast with this breadmaker.
- The yeast should be dry and separate from other ingredients when it is added to the bread pan.
- Butter and other fats should be cut into small pieces before putting in the bread pan to aid the mixing.

HD9045/HD9046



- The milk and yoghurt mixture proportion is 10:1 (For example: 400ml milk with 40ml yoghurt).
- Pour milk into the yoghurt container.
- Add yoghurt into the yoghurt container, and mix well.
- Close and tighten the lid.
- Start the yoghurt program.
 - Yoghurt will be ready in 8 hours.

5 Cleaning and Maintenance

Note

- Unplug the breadmaker before starting to clean it.
- Wait until the breadmaker has cooled down sufficiently before cleaning it.
- Never immerse the appliance in water or any other liquid, nor rinse it under the tap.
- Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.
- For maximum safety, keep the appliance clean and free of grease and food residues.

Interior

Inside of the cover and the main body:

- Wipe with wrung out and damp cloth.
- Make sure to remove all the food residues stuck to the breadmaker.

Heating element:

- Wipe with wrung out and damp cloth.
- Remove food residues with wrung out and damp cloth or toothpicks.

Exterior

Surface of the cover lid and outside of the main body:

- Wipe with a cloth dampened with soap water.
- ONLY use soft and dry cloth to wipe the control panel.
- Mix soap to remove all the food residues around the control buttons.

Accessories

Bread pan:

- Clean the bread pan with a soft cloth moistened with hot water or washing-up liquid.
- Do not immerse the bread pan in water and do not clean it in the dishwasher.
- Soak in hot water and clean with sponge.
- Thoroughly wash with warm water and soap.
- Make sure it is dried before use.

Tip

- After baking, immediately remove the kneading blade from the bread pan to prevent it from getting stuck.

6 Storage

Store your breadmaker in a safe and dry place.

7 Bread ingredients

Bread flour

Bread flour has high content of high gluten (so it can be also called high-gluten flour which contains high protein), it has good elastic and can keep the size of the bread from collapsing after rise. As the gluten content is higher than the common flour, so it can be used for making bread with large size and better inner fiber. Bread flour is the most important ingredient of making bread.

Whole-wheat flour

Whole-wheat flour is ground from grain. It contains wheat skin and gluten. Whole-wheat flour is heavier and more nutritious than common flour. The bread made by whole-wheat flour is usually small in size. So many recipes usually combine the whole-wheat flour or bread flour to achieve the best result.

Rye flour

Rye flour has high fiber level but it has lower gluten content than wheat flour. Rye bread usually has darker color and stronger taste than white and wheat bread. It should be used with bread flour in this breadmaker.

Corn flour and oatmeal flour

Corn flour and oatmeal flour are ground from corn and oatmeal separately. They are the additive ingredients of making rough bread, which are used for enhancing the flavor and texture.

All purpose flour

It has weaker gluten than bread flour. In our recipes, it can be used for Easter cake, cake, steam bun and fried bread sticks.

Sugar

Sugar is very important ingredient to increase sweet taste and color of bread. And it is also considered as nourishment in the yeast bread. White sugar is largely used. Brown sugar, powder sugar or cotton sugar may be called by special requirement.

Yeast

After yeasting process, the yeast will produce carbon dioxide. The carbon dioxide will expand bread and make the inner fiber softer. For this breadmaker, please use active dry yeast. Yeast must be stored in the refrigerator, as the fungus in it will be killed at high temperature. Before using, check the production date and storage life of your yeast. Store it back to the refrigerator as soon as possible after each use. Usually the failure of bread rising is caused by the bad yeast.

Salt

Salt is necessary to improve bread flavor and crust color. But salt can also restrain yeast from rising. Never use too much salt in a recipe. But bread would be larger if without salt.

Egg

Eggs can improve bread texture, make the bread more nourish and large in size, the egg should be stirred evenly.

Grease, butter and vegetable oil

Grease can make bread soft and delay storage life. Butter should be melted or chopped to small particles before using.

Water and other liquid

Water is essential ingredient for making bread. Generally speaking, water temperature between 20°C and 25°C is the best. The water may be replaced with fresh milk or water mixed with 2% milk powder, which may enhance bread flavor and improve crust color. Some recipes may call for juice for the purpose of enhancing bread flavor, e.g. apple juice, orange juice, lemon juice and so on.

8 Environment

Do not throw away the appliance with normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you can help to preserve the environment.

9 Guarantee and service

If you need service or information, or if you have a problem, visit the Philips website at www.philips.com or contact the Philips Customer Care Center in your country. You can find its phone number in the worldwide guarantee leaflet. If there is no Customer Care Center in your country, go to your local Philips dealer.

Български

1 Важно

Преди да използвате уреда, прочетете внимателно това ръководство за потребителя и го запазете за справка в бъдеще.

Опасност

- Никога не потапяйте корпуса на уреда за хляб във вода или друга течност и не го мийте с течеща вода.
- Не покривайте парните и вентилационните отвори, когато уреда работи.

Предупреждение

- Този уред може да се използва от деца на възраст над 8 години и от хора с намалени физически възприятия или умствени недостатъци или без опит и познания, ако са инструктирани за безопасна употреба на уреда и са под наблюдение с цел гарантиране на безопасна употреба и ако са им разяснени евентуалните опасности.
- Не позволявайте на деца да си играят с уреда. Почитване и поддръжка на уреда може да се извършва от деца на възраст над 8 години и под родителски надзор.
- Пазете уреда и захранващия кабел далеч от достъп на деца под 8 години. Не оставяйте захранващия шнур да виси през ръба на масата или стойката, на която е поставен уредът.
- С оглед предотвратяване на опасност, при повреда в захранващия кабел той трябва да бъде сменен от Philips, авторизиран от Philips сервиз или квалифициран техник.
- Уредът не е предназначен за използване с външен таймер или отделна система за дистанционно управление.
- Външните повърхности може да се нагорещат, докато уреда работи.
- Не слагайте повече от 560 г брашно и 9, 12 или 14 г мая, когато използвате програмите съответно за обикновен хляб, супер бърз хляб или козунак.
- Преди да включите уреда в електрически контакт, проверете дали посоченото върху уреда напрежение отговаря на това на местната електрическа мрежа.

