
User manual

PHILIPS

HD2072

使用手册



1) Handle of the top uni 2) Control Panel • Functional • Select buttons Start · Easy Clean

 Indicators
 Soymilk Five Grains Soymilk Rice Paste Fruit/Veggie Drink

 Pureed Soup • Corn Juice (HD2073 only) In Progress Keep Warm

Easy Clean

Overflow sensor - Monitor soymilk and preven overflowing 4) Blade

Lower part of the top unit Upper plug

Pot unit Base Power connection cover

Power cord connector Pot handle

Waterproof lid for coupling - prevent drip or splash, which makes washing safer Upper plug connector



Important safety instructions

Read this user manual carefully before you use the appliance, and save the user manual for future reference.

· Before you insert the plug into the power outlet, make sure that the appliance is assembled correctly. Make sure that your hands are dry before you insert the plug into the power outlet.

· Before you connect the appliance to the power, make sure that the voltage indicated on the bottom of the

appliance corresponds to the local power voltage. This appliance can only be used with a grounded plug. Make sure that the plug is firmly inserted into the power outlet.

 Never connect this appliance to a timer switch, to avoid a hazardous situation. • Make sure that you clean the appliance before use (see

the "Cleaning before first use" section). • Do not use this appliance to heat up soymilk or other liquid foods. • Never use the appliance for dry heating. Never add contents (including water) above MAX

(the maximum level indication) or below MIN (the minimum level indication). If the power cord, the plug, or other parts are damaged, do not use the appliance

• If the power cord is damaged, you must have it replaced by Philips, a service center authorized by

Philips or similarly qualified persons to avoid a hazard. Do not replace parts of the appliance yourself. This appliance is not intended for use by persons (including children) with reduced physical, sensory

or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.

 For their safety, do not allow children to play with the Make sure that the water you add into the soymilk

maker is warm in ambient temperature. This appliance is intended for household use only.

During processing: • Do not use this appliance on an unstable or uneven surface.

2 first use

Method 2

into it, then soak for 10 minutes

Product

**** information

• Packaging: 230 × 230 × 345 mm

Capacity: 1000 - 1300 ml (for 2-4 servings)

• Soymilk maker: 239.1 x 176.2 x 310.3 mm

Heating power: 900 W Dimensions (L \times W \times H):

Weight
• Net weight: 2.3 kg

prior notice.

Gross weight: 3.1 kg

• Keep the appliance and its power cord out of the reach of children. Never let the appliance run unattended.

Be careful when lifting the top unit in upright position

Cleaning before

1 Pour boiling water into the pot, put the top unit

2 Clean the appliance (see the "Cleaning" section)

1 Follow the instructions in the "Make soymilk"

2 Pour the soymilk away when it is done, and then

clean the appliance (see the "Cleaning" section).

keep a good distance from steam to avoid burns or

• Do not touch the steam or the metal parts of the

appliance, to avoid burns or scalding. • Do not disconnect the power cord or remove the top

unit before processing is complete. • If you have to stop processing, disconnect the power

cord before you perform other operations. If there is a power outage no less than 3 minutes after start processing, do not immediately restart the soymilk maker. Empty the contents in the soymilk maker, and then put in new contents before restarting. Otherwise the contents will stick to the pot or overflow, or the appliance will set off a long alarm.

After processing:

 Disconnect the power before you continue other • Disconnect the power and remove the power cord

before cleaning or disassembling this appliance. • To prevent steam scalding, keep a certain distance from the soymilk maker before you lift the top unit.

• The blade on the top unit is sharp. Be careful not to cut yourself or others. • To prevent a short circuit or an electric shock, • do not use water to rinse the outside of the pot uni

or top unit (including the top unit handle, control panel, upper plug, upper plug connector, and the power cord connector) and keep them away from drip or splash; · do not immerse the top unit in water;

· do not immerse the base of the soymilk maker in • Use a microwave oven to heat up cold soymilk. Do not

use this appliance to heat it, as the contents will stick to the inner side of the pot. • Some foods may discolor the overflow sensor. This is perfectly normal

• Store the power cord in a cool and dry place. To prevent an electric shock, do not use the power

cord to connect other appliances. Electromagnetic Fields (EMF)

evidence available today.

 This Philips soymilk maker complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this use

manual, the appliance is safe to use based on scientific

 To shorten the processing time, you can add warm water no hotter than 70°C. · Soymilk can also be served without being

3 Use the appliance

• If you wish to cancel a function once it is

selected, do not lift the top unit to prevent the

facial scalding. You can unplug the power cord,

· Measure ingredients as instructed. You can adjust the

1 Take a cup of dry soybeans with supplied measuring

2 Put the soybeans evenly at the bottom of the pot.

MIN (the minimum level indication).

→ The **Soymilk** indicator lights up.

cord, and connect the power.

is connected.

7 Press Start.

6 Press Select to select Soymilk.

plug is correctly inserted into the connector.

• To extend the life of the blade, soak the soybeans

(8-9 hours in fall and spring, 6-7 hours in summer,

and 9-10 hours in winter) and wash it thoroughly

3 Pour water into the pot. Make sure that the water level

is between MAX (the maximum level indication) and

4 Put the top unit into the pot. Make sure that the upper

→ The indicators flash in cycle, indicating that the power

→ The In Progress indicator flashes and the appliance

sounds once, indicating that processing starts.

→ After about 25 minutes, you will hear 6 beeps and

the **Keep Warm** indicator will light up indicating that

keep warm mode. This lasts for an hour, and then

automatically stops (see the Keep warm section).

8 After processing, disconnect the power. Hold the handle of

the pot tightly with one hand and lift the top unit with the

9 Filtrate soymilk with the filter and it is ready to serve. You

soymilk is ready. The appliance will automatically enter

5 Open the power connection cover, insert the power

re-plug it, and then select another function.

Warning

Make soymilk

For 2-4 people.

quantity to fit your personal taste.

cup and wash it thoroughly.

before processing.

can add some sugar before serving.

Make five grains soymilk • Measure ingredients as instructed. You can adjust the quantity to fit your personal taste.

1 Measure 30g of soybeans (around 1/2 cup) and 50g of rice (around 1/2 cup) with the supplied measuring cup. Wash them thoroughly.

• To extend the life of the blade, soak the soybeans (8-9 hours in fall and spring, 6-7 hours in summer, and 9-10 hours in winter) and wash it thoroughly before processing.

2 Put the rice and the soybeans evenly at the bottom of 3 Pour water into the pot. Make sure that the water level is between MAX (the maximum level indication) and

MIN (the minimum level indication). 4 Put the top unit into the pot. Make sure that the upper plug is correctly inserted into the connector

5 Open the power connection cover, insert the power cord, and connect the power. The indicators flash in cycle, indicating that the power is connected.

6 Press Select to select Five Grains Soymilk → The Five Grains Soymilk indicator lights up.

7 Press Start. → The In Progress indicator flashes and the appliance sounds once, indicating that processing starts. → After about 26 minutes, you will hear 6 beeps and

the Keep Warm indicator will light up indicating that soymilk is ready. The appliance will automatically enter keep warm mode. This lasts for an hour, and then automatically stops (see the Keep warm section). After processing, disconnect the power. Hold the handle of

the pot tightly with one hand and lift the top unit with the **9** Pour soymilk into the soymilk cup, and it is ready to serve.

You can add some sugar before serving.

 To shorten the processing time, you can add warm water no hotter than 70°

Make rice paste

• Measure ingredients as instructed. You can adjust the

quantity to fit your personal taste. • Example recipes: lily bulb and barley rice paste, for 2-4

1 Measure 35g of barley and 35g of rice (around 2/5 cup each) with supplied measuring cup. Then, take

20g of fresh lily bulbs (around 7-8 pieces). Wash them 2 Put the lily bulbs, barley, and rice evenly at the bottom

of the pot. 3 Pour water into the pot. Make sure that the water level is between MAX (the maximum level indication) and MIN (the minimum level indication).

4 Put the top unit into the pot. Make sure that the upper plug is correctly inserted into the connector. **5** Open the power connection cover, insert the power cord, and connect the power.

→ The indicators flash in cycle, indicating that the power is connected.

6 Press **Select** to select **Rice Paste**. → The Rice Paste indicator lights up.

7 Press Start. → The In Progress indicator flashes and the appliance sounds once, indicating that processing starts.

→ After about 26 minutes, you will hear 6 beeps and the Keep Warm indicator will light up indicating that rice paste is ready. The appliance will automatically enter keep warm mode. This lasts for an hour, and then automatically stops (see the Keep warm section).

8 After processing, disconnect the power. Hold the handle of the pot tightly with one hand and lift the top unit with the

9 Pour rice paste into the soymilk cup, and it is ready to serve. Make corn juice (HD2073 only) You can add some sugar before serving.



 To shorten the processing time, you can add warm water no hotter than 70°C

Make fruit/ veggie drink

• Measure ingredients as instructed. You can adjust the quantity to fit your personal taste.

• Example recipe: banana milkshake, for 2-4 servings. 1 Cut 3 bananas (about 400g) into 1 cm cubes.

2 Put the banana cubes evenly at the bottom of the pot. **3** Pour 300ml of milk and some water into the pot. Make sure that the water mark is between MAX (the maximum level indication) and MIN (the minimum level

4 Put the top unit into the pot. Make sure that the upper plug is correctly inserted into the connector. **5** Open the power connection cover, insert the power

cord, and connect the power. → The indicators flash in cycle, indicating that the power

6 Press **Select** to select **Fruit/Veggie Drink**. → The Fruit/Veggie Drink indicator lights up. 7 Press Start.

→ The In Progress indicator flashes and the appliance sounds once, indicating that processing starts. After about 4 minutes, you will hear 6 beeps, indicating that milkshake is ready. **8** After processing, disconnect the power. Hold the

handle of the pot tightly with one hand and lift the top unit with the other hand. 9 Pour banana milkshake into the soymilk cup, and it

is ready to serve. You can add some sugar before

· After banana milkshake is ready, serve at once

• Wait about 10 minutes until the appliance cools down before the next use. This makes the appliance more durable.

Make vegetable puree soup

· Measure ingredients as instructed. You can adjust the quantity to fit your personal taste. • Example recipes: tremella, lotus seed, and chinese date

cord and connect the power.

→ The Easy Clean indicator lights up and indicating that the easy clean function s → After about 8 minutes, you will hear 6

Progress indicator will turn off indicating clean function is complete.

soaked soybeans. 2 Put the cleaned ingredients evenly at the bottom of the pot. **3** Pour water into the pot. Make sure that the water level

is between MAX (the maximum level indication) and MIN (the minimum level indication). 4 Put the top unit into the pot. Make sure that the upper

1 Take 35g of dry lotus seeds, 20g of chinese dates with

the supplied measuring cup, and then 10g of tremella

the soaked tremella into pieces, and with the size of

(around 2 pieces). Wash and soak them thoroughly. Cut

plug is correctly inserted into the connector. **5** Open the power connection cover insert the power

cord, and connect the power. The indicators flash in cycle, indicating that the power is connected.

6 Press Select to select Pureed Soup. The Pureed Soup indicator lights up. **7** Press **Start**.

→ The In Progress indicator flashes and the appliance sounds once, indicating that processing starts.

→ After about 26 minutes, you will hear 6 beeps and the Keep Warm indicator will light up indicating that vegetable puree soup is ready. The appliance will automatically enter keep warm mode. This lasts for an hour and then automatically stops (see the Keep warm section).

8 After processing, disconnect the power, Hold the handle of the pot tightly with one hand and lift the top unit with the

9 Pour puree into the soymik cup, and it is ready to serve. You can add some sugar before serving.

warm water no hotter than 70°C.

• Measure ingredients as instructed. You can adjust the quantity to fit your personal taste.

1 Take 300-350g of fresh corn (around 5-6 cups with the

is between MAX (the maximum level indication) and MIN (the minimum level indication).

5 Open the power connection cover insert the power cord, and connect the power.

→ The indicators flash in cycle, indicating that the power **6** Press **Select** to select **Corn Juice**.

→ The **Corn Juice** indicator lights up.

→ The In Progress indicator flashes and the appliance sounds once, indicating that processing starts.

keep warm mode. This lasts for an hour, and then automatically stops (see the Keep warm section). 8 After processing, disconnect the power. Hold the handle of

the pot tightly with one hand and lift the top unit with the

• To shorten the processing time, you can add warm water no hotter than 70°C.

You can add some sugar before serving.

After soymilk, rice paste, pureed soup, or corn juice is made, you will hear 6 beeps and the **Keep Warm** indicator will light up. The keep warm function lasts for an hour, and then automatically stops.

drink,

 If you lift the top unit as soon as processing is complete, the appliance does not start the

keep warm function. The appliance does not start the keep warm function at the completion of fruit/veggie

4 Cleaning

· Disconnect the power and remove the power cord before cleaning or disassembling this

avoid cutting yourself and others.

the blade.

unit or inner side of the pot before they cool

the residue will dry up and stick on the appliance, and this become difficult to remove. When this happens, you • To prevent the residue from smelling, cleaning the

(the minimum level indication). 2 Put the top unit into the pot. Make sure that the upper

plug is correctly inserted into the connector.

3 Open the power connection cover, insert the power

→ The indicators flash in cycle, indicating is connected. 4 Press Easy Clean.

5 Clean the appliance as instructed in the "Cle

10 g of wheat Black rice and soybeans • 50 g of black rice (around 1/2 cup)

Pumkin soybeans milk

Sweet potato and

soybean milk

walnut milk

Rice paste

Five grains soymilk

Recipes

Soymilk

Black bean milk

Red bean milk

Mung bean milk

For more recipes, you can visit Philips MyKitchen website www.philips.com/kitchen

75 g of dry beans (a full cup)

85 g of black beans (a full cup

90 g of red beans (a full cup)

90 g of mung beans (a full cup)

• 20 g of rice (around 1/5 cup)

• 20 g of millet (around 1/5 cup)

• 35 g of soybeans (around 1/2 cup)

35 g of pumpkin (around 1/2 cup)

• 40 g of sweet potato (around 1/2 cup)

• 35 g of soybeans (around 1/2 cup)

• 30 g of soybeans (around 1/2 cup)

• 35 g of mung beans (around 2/5 cup)

• 5-10 chinese dates (with stones removed)

• 5-10 longans (with stones removed)

• 20 g of rice (around 1/5 cup)

• 10g of oats (around 1/5 cup)

• 35 g of millet (around 2/5 cup)

15 g of oats (around 1/5 cup)

Classic five grains soymilk • 15 g of soybeans (around 1/5 cup

• some sugar

Black rice, soybeans, and • 60 g of black rice (around 2/3 cup)

some sugar

Mung bean and barley • 35 g of barley (around 2/5 cup)

Walnut and cashew paste • 35 g of rice (around 2/5 cup)

Complete nutritious rice • 35 g of rice (around 1/2 cup)

Barley and lily rice paste • 35 g of barley (around 2/5 cup)

Chinese yam (shān yào) • 50 g of rice (around 1/2 cup)

and chinese date rice • 30 g of chinese yam

some sugar

some crystal sugar

• flesh of 5 walnuts

flesh of 5 cashews

flesh of 5 walnuts

• some sugar

150 g of cashews

some milk and crystal suga

• 15 g of millet (around 1/5 cup)

• 10 peanuts (with shells removed)

• 35 g of rice (around 2/5 cup)

• 20 g of fresh lily bulbs

5 chinese dates (with stones removed

• 10 g of black sesame seeds

flesh of walnuts

• 30 g of soybeans (around 1/2 cup) soaked the soybeans thoroughly,. For details, see the "Make five grains soymilk" section. some black sesame seeds • some sugar Red bean and millet milk • 50 g of read beans (around 1/2 cup) Wash the red beans and millet and soak • 35 g of millet (around 2/5 cup) thoroughly. For details, see the "Make five grains some sugar Rice and soybeans milk • 30g of soybeans (around 1/2 cup) Wash and soak soybeans thoroughly. Wash rice. • 50 g of rice (around 1/2 cup) For details, see the "Make five grain soymilk"

To shorten the processing time, you can add

For 2-4 servings.

supplied measuring cup and wash it thoroughly. **2** Put the fresh corn evenly at the bottom of the pot. 3 Pour water into the pot. Make sure that the water level

4 Put the top unit into the pot. Make sure that the upper plug is correctly inserted into the connector.

7 Press Start.

→ After about 26 minutes, you will hear 6 beeps and the Keep Warm indicator will light up indicating that corn juice is ready. The appliance will automatically enter

9 Pour corn juice into the soymilk cup, and it is ready to serve

Keep Warm

? Troubleshooting

This chapter summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Philips Consumer Care Center in your country,

| Problem | Possible cause | Solution |
|---------------------------------|---|--|
| The indicators do not light up. | The upper plug is not plugged correctly. | Make sure that the top unit is put into the pot correctly. |
| | Too much ingredient is added. | Put proper quantity of ingredient evenly at the bottom of the pot as instructed. |
| | There is water in the top unit or the indicators are broken. | Contact the Philips Consumer Care Center. |
| The indicators light up but | You do not press Start . | Press Start. |
| the appliance does not | The power is disconnected during processing, | Follow the instructions in this user manual. |
| work, | The appliance is broken. | Contact the Philips Consumer Care Center. |
| Processing will not stop. | The appliance is broken. | Contact the Philips Consumer Care Center. |
| The buttons do not work. | The appliance is broken. | Contact the Philips Consumer Care Center. |
| The beans or rice is not | The voltage is too low. | Use a household power regulator. |
| ground well. | Too many beans are added. | Put proper quantity of ingredients as instructed in the "Use the appliance" section. |
| | Insufficient water is added. | Make sure that the water level is between MAX (the maximum level indication) and MIN (the minimum level indication). |
| | The machine is broken. | Contact the Philips Consumer Care Center. |
| Overflow, | A wrong function was selected. | Select a correct function. |
| | Soymilk is too diluted or too many beans are added. | Put proper quantity of ingredient as instructed in the "Use the appliance" section. |
| | The water level is above MAX (the maximum level indication) and MIN (the minimum level indication). | Make sure that the water level is between MAX (the maximum level indication) and MIN (the minimum level indication). |
| | The appliance is broken. | Contact the Philips Consumer Care Center. |
| | The overflow sensor is not cleaned. | Clean the overflow sensor. |

Peanut paste • 200 g of peanuts (with shell removed Brown the peanuts and make sure they are around 1cm in size. Wash rice. Put the peanuts 50 g of rice • some milk and crystal sugar into the pot first, then the clean rice. Add water up to the middle of MAX and MIN. After connecting to the power, press Select to select Rice Paste. Press Start to start processing. Once done, the appliance will sound. Pour the peanut paste to the soymilk cup and serve. Finally, add some milk and sugar to taste. Brown the almonds and make sure they are 70 g of almonds • 30 g of rice around 1cm in size. Wash rice. Put the almonds some milk and crystal sugar nto the pot first, then the clean rice. Add water up to the middle of MAX and MIN. After onnecting to the power, press Select to select Rice Paste. Press Start to start processing. Once done, the appliance will sound. Pour the almond paste to the soymilk cup and serve. Finally, add some milk and sugar to taste. Brown the black sesame seeds and the white • 125 g of black sesame seeds Sesame paste • 25 g of white sesame seeds sesame seeds. Wash rice. Put both the black and white sesame seeds into the pot first then put 50 g of rice the clean rice. Add water up to the middle of some milk and crystal sugar MAX and MIN. After connecting to the power, press **Select** to select **Rice Paste**. Press **Start** to start processing. Once done, the appliance will sound. Pour the sesame paste to the soymilk cup and serve. Finally, add some milk and sugar to taste. 180 g of walnuts Brown the walnuts and make sure they are around 1cm in size. Wash rice. Put the walnuts • 50 g of rice · some milk and crystal sugar into the pot first, then put the clean rice. Add vater up to the middle of MAX and MIN. After onnecting to the power, press **Select** to select Rice Paste. Press Start to start processing. Once done, the appliance will sound. Pour the walnut paste to the soymilk cup and serve. Finally, add some milk and sugar to taste. Fruit/veggie drink

potato and pumpkin and cut them into 1 cm

cubes. For details, see the "Make rice paste"

• 20 g of pumpkin (around 1/3 cup)

• 35 g of rice (around 1/3 cup)

• 35 g of millet (around 1/3 cup)

pumpkin rice paste

Vash and soak soybeans thoroughly, For details

see the "Make soymilk" section.

Soak the soybeans thoroughly, wash the

ingredients. For details, see the "Make five grains

Wash the black rice and black sesame; wash and

Wash the soybeans and soak thoroughly. Remove

Wash the soybeans and soak thoroughly, Remove

the pumpkin skin and cut the pumpkin into 1

soymilk" section

grains soymilk" section.

five grains soymilk" section.

five grains soymilk:" section.

cm cubes. For details, see the "Make five grains

the sweet potato skin and cut the sweet potate

into 1 cm cubes. For details, see the "Make five

Wash black rice and the soybeans. Chop walnut

flesh into small pieces. For details, see the "Make

Wash the ingredients. For details, see the "Make

Wash rice and millet. Chop walnut flesh, chinese

dates, and longans into small pieces. For details,

rown the cashews and make sure they are

water up to the middle of MAX and MIN. Afte

connecting to the power, press Select to select

Rice Paste. Press Start to start processing. Once

done, the appliance will sound. Pour the cashew

paste to the soymilk cup and serve. Finally, add

Wash rice and millet. Chop walnut flesh into

small pieces. For details, see the "Make rice past

Wash the barley and rice. Wash and chop fresh

lily bulbs into small pieces. For details, see the

Wash the chinese dates and rice. Remove the

skin of the chinese yam and cut it into 1 cm

ome milk and sugar to taste.

"Make rice paste" section.

• 5-10 chinese dates (with stones removed) cubes. For details, see the "Make rice paste"

around 1cm in size . Put it into the pot. Add

see the "Make five grains soymilk" section.

| Recipe | Ingredients | Cooking |
|---------------|------------------|--|
| | • 300 ml of milk | Remove the skin of the bananas and cut them into 1 cm cubes. For details, see the "Make fruit/veggie drink" section. |
| ucumber juice | (| Cut the cucumber into 1 cm cubes. For details, see the "Make fruit/veggie drink" section. |

Pureed soup

| Recipe | Ingredients | Cooking |
|-------------------|---|---|
| hinese date puree | 35 g of lotus seeds (around 1/2 cup)30 g of chinese dates (around 1/2 cup) | Wash tremella and soak thoroughly. Cut tremellas and Chinese dates into small pieces. For details, see the ''Make vegetable puree soup' section. |

Corn juice (HD2073 only)

The time taken to process The voltage is too low.

| sorn face (TD2073 only) | | | |
|-------------------------|-------------|--|--|
| Recipe | Ingredients | Cooking | |
| Corn juice | | Wash corn. For details, see the "Make corn juice" section. | |

If you have a problem, need service, or need information, see www.philips.com/support or contact the Philips Consumer Care Center in your country.

Guarantee and

€£

→S! (**!**) 4'

For rated voltage and frequency information, refer to the typeplate on the product. Recycling Product information is subjected to change without

i service

(((BEEP)))



Do not throw away the appliance with the normal household waste at the end of its life ut hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

• Do not immerse the top unit in water. • To prevent scalding, do not touch the top

• Take care of sharp blades during cleaning to

1 After disconnecting the power, lift the top unit, then cover the waterproof lid onto the upper plug connector. Rinse the lower part of the top unit, the overflow sensor. the blade, and the inner side of the pot. 2 Use a cleaning pad to remove the residues which left on the lower part of top unit, the overflow sensor, and

panel, upper plug, upper plug connector, base, and power cord connector. The outside of the pot can be cleaned with a damp cloth. Easy clean • Promptly clean the residue on the appliance; otherwise,

3 Use a dry cloth to clean the top unit handle, control

can use the easy clean function to heat and soak the inner side of the pot and clean the appliance easier. appliance within 10 hours after use.

1 Pour water into the pot. Make sure that water level is between MAX (the maximum level indication) and MIN

| | , | | There is water in the top unit or the indicators are broken. | Contact the Philips Consumer Care Ce |
|---|---|-----------------------------|--|---|
| | | The indicators light up but | You do not press Start . | Press Start . |
| | | the appliance does not | The power is disconnected during processing, | Follow the instructions in this user man |
| | , | work, | The appliance is broken. | Contact the Philips Consumer Care Ce |
| | | Processing will not stop. | The appliance is broken. | Contact the Philips Consumer Care Ce |
| that the power | | The buttons do not work. | The appliance is broken. | Contact the Philips Consumer Care Ce |
| , char the power | | The beans or rice is not | The voltage is too low. | Use a household power regulator. |
| d sounds once, | | ground well. | / | Put proper quantity of ingredients as instructed in the "Use the appliance" se |
| starts. beeps and the In ting that the easy | | | | Make sure that the water level is betwee MAX (the maximum level indication) a MIN (the minimum level indication). |
| Land and the second and | | | The machine is broken. | Contact the Philips Consumer Care Ce |
| leaning" section. | | Overflow. | A wrong function was selected. | Select a correct function. |
| | | | | Put proper quantity of ingredient as ins in the "Use the appliance" section. |
| | | | | 1 1 |

| instructed, but other functions work well. | The water temperature is too low. | Add warm water in ambient temperature. |
|--|--|---|
| Food is burnt. | A wrong function is selected. | Select a correct function. |
| | The inner side of the pot was not cleaned. | Clean the inner side of the pot. |
| | Insufficient water is added. | Make sure that the water level is between MAX (the maximum level indication) and MIN (the minimum level indication). |
| | Too much ingredient is added. | Put proper quantity of ingredient as instructed in the "Use the appliance" section. |
| The beeps occur before soymilk is ready. | Too much water or ingredient is added. | Put proper quantity of ingredient as instructed in the "Use the appliance" section. Make sure that the water level is between MAX (the maximum level indication) and MIN (the minimum level indication). |
| | The appliance is broken. | Contact the Philips Consumer Care Center. |
| | The sea level of your region is too high. | This appliance can only be used in regions no more than 2000m above mean sea level. |
| The appliance begins stirring once you press any button. | The appliance is broken. | Contact the Philips Consumer Care Center. |



使用本產品前,請先仔細閱讀本使用手冊,並保留使 用手冊以供日後參考。

開始調理前:

- 在將插頭插入電源插座之前,請先確保已正確組裝 本產品。
- 請先確定您的雙手乾燥,再將插頭插入電源插座。 • 在您連接產品電源之前,請確認本地電壓與產品底 部所標示的電源電壓相符
- 本產品只可使用有接地的插頭。 請確保插頭已穩固 插到電源插座中。
- 為了避免發生危險,本產品不可加裝定時開關。 • 使用前請務必先清潔本產品 (請參閱「第一次使用 • 請先切斷電源再繼續其他操作。
- 前的清潔」一節)。
- 請勿將本產品用於加熱豆漿或其他液體食物。 • 切勿以本產品乾烘食物。
- 加入的食材 (包含水在內) 不可超過 MAX (最高液 位標示) 或低於 MIN (最低液位標示)。
- 如果電源線、插頭或其他部分損壞,請勿使用本 心。 機頭上的刀片相當鋒利, 須留意勿割傷自己 產品。
- 如果電源線損壞,您必須將其交由 Philips、Philips • 為了避免發生短路或觸電情形,請勿以水沖洗鍋 授權之服務中心,或是具備相同資格的技師進行 更換,以免發生危險。
- 請勿自行更換本產品零件
- 如果負責安全的人員沒有在旁監督或給予使用本產 請勿將機頭浸泡在水中。 品的相關指示,則身體官能或心智能力退化者,或 • 請勿將豆漿機底座浸泡在水中。 是經驗與知識缺乏者 (包括孩童在內) 將不適合使 • 請使用微波爐加熱冷豆漿。 請勿使用本產品加熱
- 為安全起見,請勿讓小孩把玩本產品。 • 請確保您加入豆漿機的水在環境溫度下是溫水。
- 本產品僅供家用。

調理過程中:

2) 控制面板

4 刀片

) 鍋身

8 機座

頂部插桿

9 電源連接外蓋

10 電源線連接座

洗過程更安全 13) 頂部插桿連接座

• 功能按鈕 • Select (選擇)

• 指示燈 • Soymilk (豆漿)

• Easy Clean (簡易清潔)

• Rice Paste (米糊)

HD2073

3) 溢位感測器 - 監控豆漿狀態並防止溢流

接合處防水蓋 - 避免水滴入或濺入,讓清

Pureed Soup (濃湯)

• In Progress (調理中)

• Keep Warm (保溫)

• Easy Clean (簡易清潔)

• Five Grains Soymilk (五穀豆漿)

• Fruit/Veggie Drink (蔬果汁)

• Corn Juice (玉米汁) - 僅限

- 請勿在不穩或不平的表面上使用本產品。
- 請勿讓孩童接觸到本產品與電源線。 • 不可在無人看顧的情況下任由產品運作。
- 垂直掀開機頭時請小心,並和蒸氣保持安全距離以
- 免發生燒燙傷。 • 請勿碰觸蒸氣或本產品的金屬部分,以免發生燒

出長鳴警示聲。

調理完成後

源線。

再掀開機頭

或他人。

滴入或噴濺到這些部位 ·

電磁波 (EMF)

方法 1

方法 2

「清潔」一節)。

豆漿,否則食材會黏著於鍋子內側。

• 請將電源線儲放在陰涼乾燥的地方。

• 調理程序完畢之前,請勿拔除電源線或移除機頭。 • 如果您必須停止調理程序,請在執行其他操作之

否則食材會黏著於鍋內或溢出,或者本產品會發

• 清潔或拆卸本產品之前,請先切斷電源並拔除電

• 為了避免被蒸氣燙傷,請與豆漿機保持一定距離後

• 安裝、拆卸及清潔穿孔流杯時,請格外謹慎小

子或機頭外部 (包含機頭把手、控制面板、頂部插

• 部分食物可能會導致溢位感測器變色, 此為正常

• 為了避免觸電,請勿將本電源線用於連接其他

• 本 Philips 豆漿機符合電磁波 (EMF) 所有相關標準。

只要妥善使用並依照本使用手冊之説明進行操作,

根據現有的科學研究資料,使用本產品並無安全

第一次使用前

1 將沸水倒入內鍋,放入機頭,浸泡 10 分鐘。

1 依照「製作豆漿 (Soymilk)」一節的説明操作。

2 完成後,將豆漿倒出,接著清潔產品 (請參閱

2 清潔產品 (請參閱「清潔」一節)

桿、頂部插桿連接座與電源線連接座),並避免水

- 以免臉部被燙傷。 您可以拔除電源線後 前,先將電源線拔除。 重新插回,然後再選擇其他的功能。 • 如果在調理程序開始後,發生至少 3 分鐘的斷電 情形,請勿立即重新啟動豆漿機。 請先將豆漿機 內的食材清出,並在重新啟動前,放入新食材。 製作豆漿 (Soymilk)
 - 請依照説明測量食材。 您可以視個人喜好調整
 - 份量。

使用產品

- 適合 2-4 人份。
- 1 使用隨附的量杯,取一杯份量的乾燥黃豆,徹 底清洗乾淨。
- 開始調理前,先浸泡黃豆 (春秋季需浸泡 8-9 個小時,夏季 6-7 個小時,冬季 9-10 個小 時) 並徹底清洗乾淨,如此可以延長刀片的 使用壽命。
- 2 將黃豆平鋪於內鍋底部。
- 3 將水倒入內鍋。 請確定水位介於 MAX (最高液 位標示) 與 MIN (最低液位標示) 之間。 4 將機頭放入內鍋。 請確保頂部插桿正確插入連
- 接座中。 5 打開電源連接外蓋,插入電源線並連接電源。
- → 指示燈開始循環閃爍,表示已接上電源。
- 6 按 Select (選擇) 並選擇 Soymilk (豆漿)。 → Soymilk (豆漿) 指示燈會亮起。

7 按 Start (開始)

- → In Progress (調理中) 指示燈會閃爍,產品發出 一聲聲響,表示開始調理。
- → 約25分鐘過後,您會聽見6次嗶聲,接著 Keep Warm (保溫) 指示燈會亮起,表示豆漿 已製作完成。 本產品會自動進入保溫模式, 維持一小時後即自動停止保溫 (請參閱「保 温」一節)。
- 8 調理完成後,請切斷電源。 一手緊握內鍋把手 另一手掀開機頭。
- 9 使用濾網過濾豆漿後,即可飲用。 您可以在飲用 前添加適量的糖。

※ 秘訣

- 如欲縮短調理時間,您可以使用低於 70℃ 的温水。
- 也可以不過濾豆漿直接飲用。

製作五穀豆漿 (Five Grains Soymilk)

- 請依照説明測量食材。 您可以視個人喜好調整 份量。
- 適合 2-4 人份。
- 1 使用隨附的量杯,測取黃豆 30 公克 (約 1/2 杯) 及生米 50 公克 (約 1/2 杯)。 將食材徹底清洗 乾淨。
- 開始調理前,先浸泡黃豆 (春秋季需浸泡 8-9 個小時,夏季 6-7 個小時,冬季 9-10 個小 時) 並徹底清洗乾淨,如此可以延長刀片的 使用壽命。
- 2 將生米及黃豆平鋪於內鍋底部。
- 3 將水倒入內鍋。 請確定水位介於 MAX (最高液 位標示) 與 MIN (最低液位標示) 之間。
- 4 將機頭放入內鍋。 請確保頂部插桿正確插入連 接座中。
- 5 打開電源連接外蓋,插入電源線並連接電源。 → 指示燈開始循環閃爍,表示已接上電源。
- 6 按 Select (選擇) 並選擇 Five Grains Soymilk (五穀
- → Five Grains Soymilk (五穀豆漿) 指示燈會亮起 7 按 Start (開始)。
- → In Progress (調理中) 指示燈會閃爍,產品發出 一
 轉
 整
 響
 ,
 表
 示
 開
 始
 調
 理
 。 → 約 26 分鐘過後,您會聽見 6 次嗶聲,接著
- Keep Warm (保溫) 指示燈會亮起,表示豆漿 已製作完成。本產品會自動進入保溫模式, 維持一小時後即自動停止保溫 (請參閱「保 溫」一節)。
- 8 調理完成後,請切斷電源。 一手緊握內鍋把手, 另一手掀開機頭。
- 9 將豆漿倒入豆漿杯中,即可飲用。 您可以在飲 用前添加適量的糖。

※ 秘訣

• 如欲縮短調理時間,您可以使用低於 70℃ 的温水。

- 製作米糊 (Rice Paste) • 請依照説明測量食材。 您可以視個人喜好調整
- 份量。 • 食譜範例:百合大麥米糊,適合 2-4 人份。

1 使用隨附的量杯,測取大麥 35 公克及生米 35 公克 (各約 2/5 杯)。 接著,取新鮮百合 20 公克

- 若要取消已選擇的功能,請不要掀開機頭,
 - 2 將百合、大麥及生米平鋪於內鍋底部。
 - 3 將水倒入內鍋。 請確定水位介於 MAX (最高液 位標示) 與 MIN (最低液位標示) 之間。
 - 4 將機頭放入內鍋。 請確保頂部插桿正確插入連 接座中。
 - 5 打開電源連接外蓋,插入電源線並連接電源。 → 指示燈開始循環閃爍,表示已接上電源。
 - 6 按 Select (選擇) 並選擇 Rice Paste (米糊)。 → Rice Paste (米糊) 指示燈會亮起。

7 按 Start (開始)。

- → In Progress (調理中) 指示燈會閃爍,產品發出 一聲聲響,表示開始調理。 → 約 26 分鐘過後,您會聽見 6 次嗶聲,接著
- Keep Warm (保溫) 指示燈會亮起,表示米糊 已製作完成。 本產品會自動進入保溫模式, 維持一小時後即自動停止保溫 (請參閱「保 溫」一節)。
- 8 調理完成後,請切斷電源。 一手緊握內鍋把手 另一手掀開機頭。
- 9 將米糊倒入豆漿杯中,即可飲用。 您可以在飲用 前添加適量的糖。

※ 秘訣

• 如欲縮短調理時間,您可以使用低於 70°C 的温水。

製作蔬果汁 (Fruit/Veggie Drink)

- 請依照説明測量食材。 您可以視個人喜好調整 份量。 • 食譜範例:香蕉奶昔,適合 2-4 人份。

 - 1 把 3 根香蕉 (約 400 公克) 切成 1 公分小塊狀。 2 將香蕉塊平鋪於內鍋底部。 3 將 300 毫升的牛奶和少許水倒入內鍋。 請確定
 - 水位介於 MAX (最高液位標示) 與 MIN (最低液 位標示) 之間。 4 將機頭放入內鍋。 請確保頂部插桿正確插入連
 - 接座中。 5 打開電源連接外蓋,插入電源線並連接電源。
 - → 指示燈開始循環閃爍,表示已接上電源。
 - 6 按 Select (選擇) 並選擇 Fruit/Veggie Drink (蔬果汁)。 → Fruit/Veggie Drink (蔬果汁) 指示燈會亮起。 7 按 Start (開始)
 - → In Progress (調理中) 指示燈會閃爍,產品發出 一聲聲響,表示開始調理。約4分鐘過後, 您會聽見6次嗶聲,表示奶昔已製作完成。
 - 8 調理完成後,請切斷電源。 一手緊握內鍋把 手,另一手掀開機頭。
 - 9 將香蕉奶昔倒入豆漿杯中,即可飲用。 您可以 在飲用前添加適量的糖。

• 香蕉奶昔完成後,請立即飲用,以免氧化。 • 如欲繼續使用本產品,請先等候約 10 分 鐘,讓其冷卻。 如此可以讓產品更為 耐用。

製作蔬菜濃湯 (Pureed Soup)

- 請依照説明測量食材。 您可以視個人喜好調整 份量。
- 食譜範例:銀耳蓮子紅棗湯,適合 2-4 人份。
- 1 使用隨附的量杯,取乾燥蓮子 35 公克、紅棗 20 公克及銀耳 10 公克 (約 2 片)。 徹底清洗並 浸泡食材。 把浸泡過的銀耳切成片狀,尺寸如 同泡渦的黃豆大小。
- 3 將水倒入內鍋。 請確定水位介於 MAX (最高液 位標示) 與 MIN (最低液位標示) 之間。
- 4 將機頭放入內鍋。 請確保頂部插桿正確插入連 接座中。
- → 指示燈開始循環閃爍,表示已接上電源。
- → Pureed Soup (濃湯) 指示燈會亮起。 7 按 Start (開始)。

→ In Progress (調理中) 指示燈會閃爍,產品發出 一聲聲響,表示開始調理。

「保溫 | 一節)。

- 清潔或拆卸本產品之前,請先切斷電源並
- 拔除電源線。
- 請勿將機頭浸泡在水中。
- 為了避免被燙傷,在冷卻之前,請勿碰觸 機頭或鍋子內側。
- 清潔過程中,請小心處理尖鋭刀片,以防 割傷自己及他人。
- 1 切斷電源後,掀開機頭,然後將防水蓋蓋在 頂部插桿連接座上。 沖洗機頭下部、溢位感 測器、刀片和鍋子內側。
- 2 使用清潔墊清除機頭下部、溢位感測器與刀片 上的殘渣。
- 3 使用乾布擦拭機頭把手、控制面板、頂部插 桿、頂部插桿連接座、機座與電源線連接座。 鍋子外部可以使用濕布擦拭。

簡易清潔 (Easy Clean)

- 請即刻清潔產品上的殘渣; 否則待殘渣變乾 後,便會黏著於產品上,變得很難清除。 如果 發生此狀況,您可以使用簡易清潔功能,加熱 鍋子內側並讓其浸泡在水中,如此可以比較容 易清除殘渣與清潔產品。
- 為了避免殘渣產生異味,請在使用後的 10 小 時內清潔本產品。
- 1 將水倒入內鍋。 請確定水位介於 MAX (最高液 位標示) 與 MIN (最低液位標示) 之間。
- → 指示燈開始循環閃爍,表示已接上電源。 4 按 Easy Clean (簡易清潔)。
- Progress (調理中) 指示燈會熄滅,表示簡易清 潔功能已經完成。

尺寸(長×寬×高) • 豆漿機: 239.1 × 176.2 × 310.3 公釐

如需額定電壓與頻率資訊,請參閱本產品的型

產品資訊如有變更,恕不另行通知。

豆漿

黑豆漿

紅豆漿

| | 乾燥黃豆 75 公克 (一整杯) | |
|----|----------------------|-----------------------------------|
| | 黑豆 85 公克 (一整杯) | 徹底清洗並浸泡黃豆。 如需詳細資料,請參 |
| | 紅豆 90 公克 (一整杯) | 閲「製作豆漿 (Soymilk)」一節。 |
| | 綠豆 90 公克 (一整杯) | |
| 漿 | | |
| 食譜 | 食材 | 廚具 |
| 豆漿 | • 黃豆 15 公克 (約 1/5 杯) | 徹底浸泡黃豆,清洗食材。 如需詳細資料, |
| | • 生米 20 公克 (約 1/5 杯) | 請參閱「製作五穀豆漿 (Five Grains Soymilk)」 |
| | • 小米 20 公克 (約 1/5 杯) | 一節。 |
| | • 燕麥 15 公克 (約 1/5 杯) | |
| | • 小麥 10 公克 | |

紫米豆漿

● 少許糖 • 黃豆 30 公克 (約 1/2 杯) 米豆漿 • 生米 50 公克 (約 1/2 杯)

- 2 將機頭放入內鍋。 請確保頂部插桿正確插入
- 3 打開電源連接外蓋,插入電源線並連接電源。
- → Easy Clean (簡易清潔) 指示燈會亮起,並發 出一聲聲響,表示簡易清潔功能開始作用。
- → 約8分鐘過後,您會聽見6次嗶聲,接著 In
- 5 請依照「清潔」一節的説明清潔本產品。

💌 產品資訂

馬達功率:150W 加熱功率:900W

• 包裝: 230×230×345 公釐

• 淨重: 2.3 公斤 • 總重: 3.1 公斤 容量:1000-1300毫升(適合2-4人份)

i 保固與服務

如果您有任何問題、需要維修或資訊,請參閱 www.philips.com/support 或聯絡您當地的 Philips

棄物一併丟棄。請將該產品放置於政府指 ■ 定的回收站。此舉能為環保盡一份心力。

清洗生米與小米。 將核桃仁、紅棗與龍眼切

將腰果烘烤至褐色,並確定每顆腰果的大小約

1 公分。 將腰果倒入鍋中。 將水加到 MAX 和

MIN 的中間。 接上電源後,按 Select (選擇) 並

選擇 Rice Paste (米糊)。 按 Start (開始) 開始調

理。 完成後,產品會發出聲響。 將腰果糊倒

入豆漿杯中,即可飲用。 最後,可添加適量

清洗牛米與小米。 將核桃仁切成小塊。 如需

詳細資料,請參閱「製作米糊 (Rice Paste)」

清洗大麥與生米。 清洗新鮮百合並將其切成

小塊。 如需詳細資料,請參閱「製作米糊

的牛奶和砂糖增加風味。

(Rice Paste)」一節。

一節。

| 艮碹 | 艮仞 | 则共 |
|------|------------------|-----------------------------------|
| 香蕉奶昔 | • 香蕉 400 公克 | 去除香蕉皮,將香蕉切成 1 公分小塊狀 |
| | • 牛奶 300 毫升 | 如需詳細資料,請參閱「製作蔬果汁 (Fru |
| | | Veggie Drink)」一節。 |
| 小黃瓜汁 | 一條小黃瓜 (約 200 公克) | 將小黃瓜切成 1 公分小塊狀。 如需詳細 |
| | | 料,請參閱「製作蔬果汁 (Fruit/Veggie Drink). |
| | | 一節。 |

• 生米 50 公克 (約 1/2 杯)

• 地瓜 30 公克 (約 1/2 杯)

• 南瓜 20 公克 (約 1/3 杯)

• 生米 35 公克 (約 1/3 杯)

• 小米 35 公克 (約 1/3 杯)

• 去殼花生 200 公克

• 生米 50 公克

• 杏仁 70 公克

• 生米 30 公克

• 少許牛奶和砂糖

• 黑芝麻籽 125 公克

• 白芝麻籽 25 公克

• 生米 50 公克

• 核桃 180 公克

• 生米 50 公克

• 少許牛奶和砂糖

• 少許牛奶和砂糖

• 少許牛奶和砂糖

• 山藥 30 公克

• 少許砂糖

地瓜南瓜米糊

• 5-10 顆去核紅棗

清洗紅棗與生米。 去除山藥皮,將山藥切成

作米糊 (Rice Paste)」一節。

閲「製作米糊 (Rice Paste)」一節。

1 公分小塊狀。 如需詳細資料,請參閱「製

清洗小米與生米。 去除地瓜皮與南瓜皮,將

其切成 1 公分小塊狀。 如需詳細資料,請參

將花生烘烤至褐色,並確定每顆花生的大小

約1公分。清洗生米。先將花生倒入鍋中,

接著倒入清洗過的生米。 將水加到 MAX 和

MIN 的中間。 接上電源後,按 Select (選擇)

並選擇 Rice Paste (米糊)。 按 Start (開始) 開

始調理。 完成後,產品會發出聲響。將花生

糊倒入豆漿杯中,即可飲用。 最後,可添加

將杏仁烘烤至褐色,並確定每顆杏仁的大小

約1公分。清洗生米。 先將杏仁倒入鍋中,

接著倒入清洗過的生米。 將水加到 **MAX** 和

MIN 的中間。 接上電源後,按 Select (選擇)

並選擇 Rice Paste (米糊)。 按 Start (開始) 開

始調理。 完成後,產品會發出聲響。 將杏仁

糊倒入豆漿杯中,即可飲用。 最後,可添加

將黑芝麻籽和白芝麻籽烘烤至褐色。 清洗

生米。 先將黑、白芝麻籽倒入鍋中,接著

倒入清洗過的生米。 將水加到 MAX 和 MIN

的中間。接上電源後,按 Select (選擇) 並選

擇 Rice Paste (米糊)。 按 Start (開始) 開始調

理。 完成後,產品會發出聲響。 將芝麻糊倒

入豆漿杯中,即可飲用。 最後,可添加適量

將核桃烘烤至褐色,並確定每顆核桃的大小

約1公分。清洗牛米。 先將核桃倒入鍋中,

接著倒入清洗過的生米。 將水加到 MAX 和

MIN 的中間。 接上電源後,按 Select (選擇)

並選擇 Rice Paste (米糊)。 按 Start (開始) 開

始調理。 完成後,產品會發出聲響。 將核桃

糊倒入豆漿杯中,即可飲用。 最後,可添加

適量的牛奶和砂糖增加風味。

適量的牛奶和砂糖增加風味。

的牛奶和砂糖增加風味。

適量的牛奶和砂糖增加風味。

| 農 湯 | | |
|------------|----------------------|----------------------|
| 食譜 | 食材 | 廚具 |
| 銀耳蓮子紅棗濃湯 | • 銀耳二片 (約 10 公克) | 徹底清洗並浸泡銀耳。 將銀耳與紅棗切成小 |
| | • 蓮子 35 公克 (約 1/2 杯) | 塊。 如需詳細資料,請參閱「製作蔬菜濃湯 |
| | • 紅棗 30 公克 (約 1/2 杯) | (Pureed Soup)」一節。 |

玉米汁 (僅限 HD2073)

| • | , | |
|-----|-----|--|
| 食譜 | 食材 | 廚具 |
| 玉米汁 | ` ' | 清洗玉米。 如需詳細資料,請參閱「製作玉 米汁 (Com Juice)」一節。 |
| | | 米汁 (Corn Juice)」一節。 |

本單元概述您使用本產品時可能遇到的最常見問題。 如果您無法利用以下資訊解決遇到的問題,請聯絡您所在 國家/地區的 Philips 顧客服務中心。

| 指示燈未亮起。 | 頂部插桿未正確插置。 | 請確定機頭已妥當放入內鍋中。 |
|----------------------|------------------|---------------------------|
| | 加入太多食材。 | 請依照説明將適當份量的食材平鋪在內鍋 底部。 |
| | 機頭有水,或是指示燈損壞。 | 請聯絡 Philips 顧客服務中心。 |
| 指示燈亮起,但產品 | 您未按下 Start (開始)。 | 按 Start (開始)。 |
| 沒有作用。 | 在調理過程中,電源被切斷。 | 請遵循本使用手冊的説明指示進行。 |
| | 產品已損壞。 | 請聯絡 Philips 顧客服務中心。 |
| 產品持續進行調理, 無法停止操作。 | 產品已損壞。 | 請聯絡 Philips 顧客服務中心。 |

豆子或生米 電壓過低。 使用家用功率調節器。 研磨不足。 加入太多豆子。 依「使用產品」一節的説明,放入適當份 量的食材。 添加的水量不足。 請確定水位介於 MAX (最高液位標示) 與 MIN (最低液位標示) 之間。 機器已損壞。 請聯絡 Philips 顧客服務中心。 請選擇正確的功能。 選錯功能。 豆漿過稀或是放入太多豆子。 依「使用產品」一節的説明,放入適當份 量的食材。 水位超過 MAX (最高液位標示) 與 請確定水位介於 MAX (最高液位標示) 與 MIN (最低液位標示)。 MIN (最低液位標示) 之間。 請聯絡 Philips 顧客服務中心 產品已損壞。 未清潔溢位感測器。 請清潔溢位感測器。 調理豆漿的時間比手 電壓過低。 使用家用功率調節器。 冊指示的時間還久, 水溫過低。 請使用環境溫度下的溫水。 但其他功能運作正常。

| MC ∧L | 1 HEW! | 11T/(2)1/A |
|-----------|--------------|------------------------|
| 食物燒焦。 | 選錯功能。 | 請選擇正確的功能。 |
| | 未清潔鍋子內側。 | 請清潔鍋子內側。 |
| | 添加的水量不足。 | 請確定水位介於 MAX (最高液位標示) 身 |
| | | MIN (最低液位標示) 之間。 |
| | 加入太多食材。 | 請依照「使用產品」一節的説明,放入達 |
| | | 當份量的食材。 |
| 豆漿完成前, | 加入太多水或食材。 | • 依「使用產品」一節的説明,放入適當 |
| 後出嗶聲。 | | 份量的食材。 |
| | | • 請確定水位介於 MAX (最高液位標示 |
| | | 與 MIN (最低液位標示) 之間。 |
| | 產品已損壞。 | 請聯絡 Philips 顧客服務中心。 |
| | 您所在地區的海平面過高。 | 本產品只能用於不超過平均海平面以_ |
| | | 2000 公尺的地區。 |
| -旦按下任何按鈕, | 產品已損壞。 | 請聯絡 Philips 顧客服務中心。 |
| 下產品即開始攪拌。 | | |
| | | |
| | | |

| | | 頂部插桿未正確插置。 | 請確定機頭已妥當放入內鍋中。 |
|--|----------------------|------------------|---------------------|
| | | 加入太多食材。 | 請依照説明將適當份量的食材平鋪在內部 |
| | | | 底部。 |
| | | 機頭有水,或是指示燈損壞。 | 請聯絡 Philips 顧客服務中心。 |
| | 沒有作用。 | 您未按下 Start (開始)。 | 按 Start (開始)。 |
| | | 在調理過程中,電源被切斷。 | 請遵循本使用手冊的説明指示進行。 |
| | | 產品已損壞。 | 請聯絡 Philips 顧客服務中心。 |
| | 產品持續進行調理, 無法停止操作。 | 產品已損壞。 | 請聯絡 Philips 顧客服務中心。 |
| | 按鈕無法使用。 | 產品已損壞。 | 請聯絡 Philips 顧客服務中心。 |

2 將洗淨的食材平鋪於內鍋底部。

5 打開電源連接外蓋,插入電源線並連接電源。

8 調理完成後,請切斷電源。 一手緊握內鍋把手,

6 按 Select (選擇) 並選擇 Pureed Soup (濃湯)。

→ 約 26 分鐘過後,您會聽見 6 次嗶聲,接著 Keep Warm (保溫) 指示燈會亮起,表示蔬菜 濃湯已製作完成。本產品會自動進入保溫模 式, 維持一小時後即自動停止保溫 (請參閱

(約 7-8 瓣)。 將食材徹底清洗乾淨。

另一手掀開機頭。 9 將濃湯倒入豆漿杯中,即可飲用。 您可以在飲用 前添加適量的糖。

※ 秘訣

• 如欲縮短調理時間,您可以使用低於

製作玉米汁 (Corn Juice) (僅限

• 請依照説明測量食材。 您可以視個人喜好調整

1 使用隨附的量杯,取新鮮玉米 300-350 公克 (約

3 將水倒入內鍋。 請確定水位介於 MAX (最高液

4 將機頭放入內鍋。 請確保頂部插桿正確插入連

5 打開電源連接外蓋,插入電源線並連接電源。

→ 指示燈開始循環閃爍,表示已接上電源。

→ In Progress (調理中) 指示燈會閃爍,產品發出

→ 約 26 分鐘過後,您會聽見 6 次嗶聲,接著

Keep Warm (保溫) 指示燈會亮起,表示玉米

汁已製作完成。本產品會自動進入保溫模

式, 維持一小時後即自動停止保溫 (請參閱

8 調理完成後,請切斷電源。 一手緊握內鍋把手

9 將玉米汁倒入豆漿杯中,即可飲用。 您可以在飲

• 如欲縮短調理時間,您可以使用低於

當豆漿、米糊、濃湯或玉米汁製作完成後,您會

聽見 6 次嗶聲,接著 Keep Warm (保溫) 指示燈

會亮起。 保溫功能可維持一個小時,之後會自

• 如果您在調理完成時隨即掀開機頭,產品

• 如果是製作蔬果汁,當調理完成時,產品

6 按 Select (選擇) 並選擇 Corn Juice (玉米汁)。

→ Corn Juice (玉米汁) 指示燈會亮起。

一聲聲響,表示開始調理。

「保温」一節)。

另一手掀開機頭。

※ 秘訣

動停止保溫。

* 秘訣

用前添加適量的糖。

70°C 的温水。

保溫 (Keep Warm)

便不會啟動保溫功能。

不會啟動保溫功能。

顧客服務中心。

位標示) 與 MIN (最低液位標示) 之間。

70°C 的温水。

份量。

接座中。

7 按 Start (開始)。

• 適合 2-4 人份。

5-6 杯),徹底清洗乾淨。

2 將新鮮玉米平鋪於內鍋底部。

如果需要更多食譜,您可以造訪 Philips MyKitchen 網站: www.philips.com/kitchen

| 廚具 |
|----------------------|
| |
| 徹底清洗並浸泡黃豆。 如需詳細資料,請參 |
| 閲「製作豆漿 (Soymilk)」一節。 |
| |
| |

綠豆漿 五穀豆

| 食材 | 廚具 |
|--|--|
| • 黄豆 15 公克 (約 1/5 杯) • 生米 20 公克 (約 1/5 杯) • 小米 20 公克 (約 1/5 杯) • 燕麥 15 公克 (約 1/5 杯) • 小麥 10 公克 | 徹底浸泡黃豆,清洗食材。 如需詳細資料,請參閱「製作五穀豆漿 (Five Grains Soymilk)」 一節。 |
| (, | 清洗紫米與黑芝麻:徹底清洗並浸泡黃豆。如需詳細資料,請參閱「製作五穀豆漿 (Five Grains Soymilk)」一節。 |
| • 紅豆 50 公克 (約 1/2 杯) • 小米 35 公克 (約 2/5 杯) | 徹底清洗並浸泡紅豆與小米。 如需詳細資料,請參閱「製作五穀豆漿 (Five Grains |

紅豆小米漿 Soymilk)」一節。

徹底清洗並浸泡黃豆。 清洗生米。 如需詳 • 少許糖 Soymilk)」一節。

細資料,請參閱「製作五穀豆漿 (Five Grains 南瓜豆漿 徹底清洗並浸泡黃豆。 去除南瓜皮,將南瓜 • 黄豆 35 公克 (約 1/2 杯) 切成 1 公分小塊狀。 如需詳細資料,請參閱 • 南瓜 35 公克 (約 1/2 杯) 「製作五穀豆漿 (Five Grains Soymilk)」一節。

地瓜豆漿 徹底清洗並浸泡黃豆。 去除地瓜皮,將地瓜 • 地瓜 40 公克 (約 1/2 杯) • 黃豆 35 公克 (約 1/2 杯) 切成 1 公分小塊狀。 如需詳細資料,請參閱 「製作五穀豆漿 (Five Grains Soymilk)」一節。 紫米黃豆核桃漿 • 紫米 60 公克 (約 2/3 杯) 清洗紫米與黃豆。 將核桃仁切成小塊。 如

• 黃豆 30 公克 (約 1/2 杯) 需詳細資料,請參閱「製作五穀豆漿 (Five • 5 顆核桃仁 Grains Soymilk)」一節。 • 少許糖 • 大麥 35 公克 (約 2/5 杯) 清洗食材。 如需詳細資料,請參閱「製作五

綠豆大麥糊 • 綠豆 35 公克 (約 2/5 杯) 穀豆漿 (Five Grains Soymilk)」一節。 • 生米 20 公克 (約 1/5 杯) • 燕麥 10 公克 (約 1/5 杯)

• 小米 35 公克 (約 2/5 杯) 成小塊。 如需詳細資料,請參閱「製作五穀 • 5 顆腰果 豆漿 (Five Grains Soymilk)」一節。 • 5 顆核桃仁 • 5-10 顆去核紅棗

• 5-10 顆去核龍眼

• 腰果 150 公克

• 少許牛奶和砂糖

• 生米 35 公克 (約 1/2 杯)

• 黑芝麻籽 10 公克

• 10 顆去殼花生

• 5 顆去核紅棗

• 核桃仁

• 少許糖

• 小米 15 公克 (約 1/5 杯)

• 大麥 35 公克 (約 2/5 杯)

• 生米 35 公克 (約 2/5 杯)

新鮮百合 20 公克

少許糖

• 生米 35 公克 (約 2/5 杯)

米糊

營養滿分的米糊

大麥百合米糊

核桃腰果糊

號牌。

本產品使用壽命結束時請勿與一般家庭廢