

# PHILIPS

HD7000



---

EN

User manual

---

TC

使用手册

# Contents

<b>1</b>	<b>Important .....</b>	<b>3</b>
	Danger.....	3
	Warning .....	3
	Caution.....	3
	Electromagnetic Fields (EMF) .....	4
<b>2</b>	<b>Rice cooker .....</b>	<b>5</b>
	Product overview.....	5
	Control panel overview.....	6
	Additional instructions - Instructional sticker .....	7
<b>3</b>	<b>Using your rice cooker.....</b>	<b>7</b>
	Before first use.....	7
	Table of cooking times .....	8
	Preparation before cooking .....	9
	Cooking rice .....	10
	Claypot rice.....	11
	Healthy rice.....	11
	Dual layer rice .....	12
	Porridge and soup .....	12
	Steaming food.....	13
	Reheat.....	13
	Stew.....	14
	Setting the cooking time .....	14
	Setting the preset cooking time	14
	Adjusting the cooking time and preset cooking time .....	15
<b>4</b>	<b>Cleaning and Maintenance</b>	<b>15</b>
	Inner lid .....	15
	Moisture lock valve.....	16
	Interior .....	16
	Exterior .....	16
	Accessories .....	16
	Inner pot instructions .....	16
<b>5</b>	<b>Recycling .....</b>	<b>17</b>
<b>6</b>	<b>Warranty and Support.....</b>	<b>17</b>
<b>7</b>	<b>Specifications.....</b>	<b>18</b>
<b>8</b>	<b>Troubleshooting .....</b>	<b>18</b>
<b>9</b>	<b>Explanation of Protection Codes .....</b>	<b>19</b>

# 1 Important

Please read these safety instructions carefully before use, and keep them in a safe place for future reference.

---

## Danger

- Do not immerse this appliance in water.

---

## Warning

- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge in its use, unless they are supervised or have been instructed in the use of the appliance by a person responsible for their safety.
- Children should be supervised to make sure that they do not play with the appliance.
- Use the handle (if available) to move the appliance safely and prevent hot liquid from leaking out.
- Never use the appliance on wet surfaces.
- This appliance is only intended for household use and other similar applications, such as:
  - staff kitchens in stores, offices, and other work environments;
  - farmhouses;
  - use by guests in hotels, hostels, and other residential environments;
  - similar environments where only bed and breakfast accommodation is provided.
- If the power cord set is damaged, it must be replaced with a power cord set provided by the manufacturer.
- This appliance is not intended to be operated with an external timer or separate remote control system.
- Check that the voltage indicated on the appliance matches your local mains voltage before switching it on.
- This appliance must only be used with a socket with a grounding wire. Always make sure the plug is firmly inserted into the power outlet.
- Do not use this appliance if the plug, power cord, inner pot, sealing ring, or main body is damaged.
- Do not allow the power cord to hang over the edge of the table or worktop where the appliance is placed.
- Before plugging the appliance into a power socket, make sure the heating element, temperature sensor, and the outside of the inner pot are clean and dry.
- Do not use wet hands to plug in the appliance or press any buttons on the control panel.
- When the appliance is in use and immediately after use, the steam valve and the liquid and steam inside it will be very hot. Do not attempt to disassemble the steam valve until it has completely cooled.

---

## Caution

- Do not use any accessories or components produced by other manufacturers or not specifically recommended by Philips, as this will void your warranty.
- Do not expose the appliance to high temperatures, and do not place it on a stove or cooker that is on or still hot.
- Do not expose the appliance to direct sunlight.
- Place the appliance on a stable, level, and flat surface.
- Make sure the inner pot is inside the appliance before plugging it in and switching it on.
- Do not cook with the inner pot directly over open fire.
- Do not use the inner pot if it is deformed.
- The surface of the appliance may become hot when in use. Take extra care when handling the product.

## 4 English

- Do not cover the steam vent with a cloth while the appliance is running.
- Be careful of hot steam being discharged from the steam vent while cooking, and from the appliance when opening the lid. Keep your hands and face away from the appliance to avoid burning yourself on the steam.
- Do not lift or move the appliance while it is running.
- To avoid overflow, do not exceed the maximum water level indicated in the inner pot, as this may be dangerous.
- Do not place cooking utensils in the pot while cooking, warming, or reheating rice.
- Only use the cooking utensils provided. Do not use sharp utensils.
- Do not insert metal objects or foreign objects into the steam vent.
- Do not place magnetic materials on the lid. Do not use this appliance near magnetic materials.
- The appliance must be left to cool before it can be cleaned or moved.
- The appliance should be cleaned after each use. Refer to Cleaning and Maintenance for detailed cleaning instructions.
- Always unplug the appliance when not in use for a long time.
- When moving this appliance, take care to hold it firmly to avoid dropping it and causing injury.
- Do not touch the inner pot immediately after opening the lid, to avoid burns.
- Do not open the lid during cooking to avoid burns.
- This appliance may be used at altitudes of 0–2000 meters.
- Avoid contact between the inner pot and other metal utensils when cleaning to prevent the stainless steel from rusting due to scratches or electrochemical reactions.
- If the appliance is used improperly, or if it is not used according to the instructions in this user manual, the warranty shall become void and Philips shall refuse liability for any damage caused. Please visit <https://www.philips.com.cn/c-m/consumer-support> to download the user manual.
- The surface of the heating element is subject to residual heat after use.
- Make sure that the power plug is fully inserted into and has proper contact with the power socket during use.
- If you need to use an extension cord socket, make sure to use one that complies with national standards.
- Disconnect the power supply when the appliance is left unattended.
- In the event of abnormal noises, odors, overtemperature or faults, stop using the appliance immediately, turn it off and disconnect the power supply.
- Never supply power to the appliance from outlets in lamp sockets.
- The total rated current of all the household appliances connected to an extension cord socket must not exceed the rated current of the original socket or cord.
- This appliance must not be used in proximity to flammable or explosive substances or in similar environments.
- Do not disassemble the appliance yourself or modify the internal circuitry, components or protection devices.
- When unplugging the appliance, do not pull or stretch the power cord.
- Do not replace the fuse element of the appliance or power supply with common conductors or fuse elements with a current capacity that exceeds the specified value.
- Do not modify the settings of the low-voltage circuit breaker or the residual current device yourself.

---

## Electromagnetic Fields (EMF)


This appliance complies with the applicable standards and regulations regarding exposure to electromagnetic fields.

## 2 Rice cooker

Congratulations on your purchase, and welcome to Philips!

To make the most of the support that Philips offers, make sure you register your product at [www.philips.com.cn](http://www.philips.com.cn).


### Product overview



## 6 English


①	Top lid	⑨	Quick Start Guide
②	Detachable inner lid	⑩	Steamer basket
③	Water level indications	⑪	Measuring cup
④	Inner pot	⑫	Power cord
⑤	Lid release button	⑬	Steam valve
⑥	Power socket	⑭	Control panel
⑦	Rice spoon		
⑧	Soup ladle		

## Control panel overview



①	Back button	②	Menu selection/time adjustment button
③	Rice texture selection button	④	Menu selection/time adjustment button
⑤	Time/Preset time button	⑥	Confirm/start button
⑦	Quick cook rice shortcut button	⑧	Tasty white rice shortcut button
⑨	Congee shortcut button	⑩	Healthy rice shortcut button

## Additional instructions - Instructional sticker



**Note: Please remove the instructional sticker before use**

## 3 Using your rice cooker

### Before first use

- 1 Remove all packaging materials from the appliance.
- 2 Take out all the accessories from the inner pot.
- 3 Clean the parts of the rice cooker thoroughly before using the rice cooker for the first time (see Cleaning and Maintenance).

## 8 English



### Caution

- Make sure all parts are completely dry before you start using the rice cooker.
- Make sure the outside of the inner pot is dry and clean, and that there is no foreign residue inside the appliance.
- Make sure the inner pot is in proper contact with the heating element.

**Table of cooking times**

Cooking function	Default cooking time	Cooking time range	Preset time	Texture firmness
Quick cook rice	30 min	Non-adjustable	1–24 hours	Non-adjustable
Tasty white rice	45 min	Non-adjustable	1–24 hours	Standard
	50 min	Non-adjustable	1–24 hours	Soft and sticky
	40 min	Non-adjustable	1–24 hours	Chewy
Claypot rice	1 hours	Non-adjustable	Non-adjustable	Non-adjustable
	1 hours	Non-adjustable	1 hour 30 min–24 hours	Standard
Multigrain rice	65 min	Non-adjustable	1 hour 30 min–24 hours	Soft and sticky
	55 min	Non-adjustable	1 hour 30 min–24 hours	Chewy
Congee	1 hours	1–2 hours	Set cooking time–24 hours	Non-adjustable
Multigrain congee	70 min	1 hour 10 min–4 hours	Set cooking time–24 hours	Non-adjustable
Soup	2 hours	1 hour 30 min–4 hours	Set cooking time–24 hours	Non-adjustable
Steam	30 min	1 min–1 hour	1 hour 30 min–24 hours	Non-adjustable
Stew	2 hours	1–4 hours	Non-adjustable	Non-adjustable
Reheat	25 min	Non-adjustable	Non-adjustable	Non-adjustable
Keep warm	2 hours	1 min–12 hours	Non-adjustable	Non-adjustable
Boiled/Steamed Rice	50 min	Non-adjustable	1–24 hours	Non-adjustable
Healthy rice	45 min	Non-adjustable	1–24 hours	Non-adjustable
	60 min	Non-adjustable	1 hour 30 min–24 hours	Standard
Brown rice	65 min	Non-adjustable	1 hour 30 min–24 hours	Soft and sticky
	55 min	Non-adjustable	1 hour 30 min–24 hours	Chewy

- \* The table above lists the default cooking times corresponding to each cooking function, i.e. the length of time initially displayed on the screen.
- \* Cooking times may vary depending on factors such as environmental conditions, the type of rice, and amount of water. Therefore, the actual completion time will be when the appliance finishes cooking.
- \* For menus with adjustable cooking times, the selected cooking time will be remembered once cooking begins. For menus with preset delayed cooking times, the preset time will be remembered once cooking begins. For menus with adjustable texture settings, the selected texture will be remembered once cooking begins.
- \* Once cooking has started, the menu that was used will be remembered. After switching off and back on again, this menu will be set as the default selected menu.

## Preparation before cooking

### ! Warning

- Make sure the detachable inner lid and steam valve are properly installed.
- Make sure all parts are completely dry before using the appliance.
- After the cooking process is finished, unplug the rice cooker from the electrical outlet.
- Do not exceed the volume indicated or the maximum water level indicated in the inner pot, as this may cause the appliance to overflow.

### == Caution

- After having opened the lid during cooking (especially when a large amount of water has been added), close the top lid slowly or wait 1–2 minutes until the steam has dissipated/pressure has decreased before closing the lid. This is to prevent liquid from the inner pot being expelled through the steam vent.
- This appliance is suitable for use at altitudes below 2000 meters.
- For rice cooking, follow the water level indications on the inside of the inner pot. You can adjust the water level according to different types of rice and your own preference, but you must not exceed the maximum volume indicated on the inner pot.
- Within 30 seconds of the cooking process starting, you can press  once to cancel the current operation and return to the settings interface. After cooking for 30 seconds, you can press  twice within a 3-second period to cancel the current operation and return to the settings interface.
- If no operation is started within 5 minutes after switching the rice cooker on, it will enter standby mode. You can press any button to wake it from standby mode and return to the settings interface.
- In the settings interface, the selected menu is fully illuminated, while the unselected menus are dimmed.


Perform the following preparations before cooking with the rice cooker:

- 1 Press the lid release button to open the top lid.





## 10 English


2 Take the inner pot out of the cooker.



3 Put the pre-washed food in the inner pot, wipe the outside and bottom of the inner pot dry using a soft cloth, then put it back into the rice cooker.



4 Put the plug into the power socket.



### Caution

- Make sure the outside of the inner pot is dry and clean, and that there is no foreign residue on the heating element.
- Make sure the inner pot is in proper contact with the heating element.

## Cooking rice

You can use the following menus to cook rice: quick cook rice (  ), tasty white rice (  ), multigrain rice (  ), and brown rice (  ). For details of adjustable cooking time ranges, please see the "Table of cooking times."

- 1 Follow the steps in "Preparation before cooking."
- 2 Tap , , or the quick menu button to select one of the cooking programs.
- 3 After selecting the tasty white rice, multigrain rice, or brown rice functions, you can tap  to select your preferred texture.

- 4 Tap  to confirm. The rice cooker will start working in the selected mode.
  - ↳ The remaining cooking time is displayed on the screen as a countdown.
  - ↳ The interface ring blinks.
- 5 The appliance beeps several times after cooking is completed, and automatically switches to keep warm mode.
  - ↳ The interface ring will fully illuminate.

## Claypot rice

You can use the claypot rice ( ) menu to make crispy rice at the bottom of the pot, such as Cantonese-style claypot rice. For details of adjustable cooking time ranges, please see the "Table of cooking times."

- 1 Follow the steps in "Preparation before cooking."
- 2 To make claypot rice, add an appropriate amount of cooking oil to the rice and water, then stir to mix evenly.
- 3 Tap  or  to select the claypot rice function.
- 4 Tap  to confirm. The rice cooker will start working in the selected mode.
  - ↳ The remaining cooking time is displayed on the screen as a countdown.
  - ↳ The interface ring blinks.
- 5 When the midway beep sounds during cooking (displaying 35 minutes), open the lid, quickly add the ingredients, then close the lid to continue cooking.
- 6 The appliance beeps several times after cooking is completed, and automatically switches to keep warm mode.
  - ↳ The interface ring will fully illuminate.



### Caution

- We recommend using jasmine rice (absorbs less water and gives a better texture).
- Recommended number of cups: Using 3–6 cups of rice makes better crispy rice at the bottom of the pot.
- Ingredients ratio: For 3 cups of rice, add water up to the 3-cup mark and 3 teaspoons of oil, then stir to mix evenly (1 teaspoon = 5ml).

## Healthy rice

You can use the healthy rice menu to reduce the amount of carbohydrates in your rice. For details of adjustable cooking time ranges, please see the "Table of cooking times."

- 1 Put up to 2 cups of rinsed rice in the steamer basket and spread it out evenly.
- 2 Add water to the inner pot up to the steaming mark.
- 3 Put the steamer basket in the inner pot.
- 4 Add water to the steamer basket up to the healthy rice mark. Do not exceed the 2-cup mark.
- 5 Tap the healthy rice quick menu button.
- 6 Tap  to confirm. The rice cooker will start working in the selected mode.
  - ↳ The remaining cooking time is displayed on the screen as a countdown.
  - ↳ The interface ring blinks.
- 7 The appliance beeps several times after cooking is completed, and automatically switches to keep warm mode.
  - ↳ The interface ring will fully illuminate.

## 12 English



### Caution

- When cooking healthy rice, do not add water beyond the maximum mark on the steamer basket. (For 1 cup of rice, add water up to the 1-cup mark so that the rice and water combined do not exceed 2 cups.)
- To prevent dry heating, add water to the inner pot until it reaches the steaming mark.
- When cooking healthy rice, do not select any menu other than "Healthy rice." Otherwise, the appliance may malfunction.

## Dual layer rice

You can use the dual layer ricemenu to make rice with different textures to suit varying tastes. For details of adjustable cooking time ranges, please see the "Table of cooking times."

- 1 Put rinsed rice in the inner pot and add water to the dual layer ricemark. Make sure the rice and water combined do not exceed 2 cups.
- 2 Put rinsed rice in the steamer basket and add water to the dual layer ricemark. Make sure the rice and water combined do not exceed 2 cups.
- 3 Put the steamer basket in the inner pot.
- 4 Tap or to select the dual layer ricefunction.
- 5 Tap to confirm. The rice cooker will start working in the selected mode.
  - ↳ The remaining cooking time is displayed on the screen as a countdown.
  - ↳ The interface ring blinks.
- 6 The appliance beeps several times after cooking is completed, and automatically switches to keep warm mode.
  - ↳ The interface ring will fully illuminate.



### Caution

- When cooking boiled/steamed rice, do not add water beyond the maximum mark on the dual layer rice scale.(For 1 cup of rice, add water up to the 1-cup mark so that the rice and water combined do not exceed 2 cups.)
- Do not make porridge in the inner pot and steam rice in the steamer basket. To avoid leaks, both containers must be steaming simultaneously.
- When cooking boiled/steamed rice, do not select any menu other than "boiled/steamed rice." Otherwise, the appliance may malfunction.

## Porridge and soup

You can use the multigrain congee ( ) and congee ( ) menus to cook porridge, and the soup ( ) menu to make soup. For details of adjustable cooking time ranges, please see the "Table of cooking times."

- 1 Follow the steps in "Preparation before cooking."
- 2 Tap or to select the desired cooking program.
- 3 Tap to confirm. The rice cooker will start working in the selected mode.
  - ↳ The remaining cooking time is displayed on the screen as a countdown.
  - ↳ The interface ring blinks.
- 4 The appliance beeps several times after cooking is completed, and automatically switches to keep warm mode.
  - ↳ The interface ring will fully illuminate.

 Caution

- Be sure to select the correct function for cooking porridge or soup to avoid overflow, as this may be dangerous.

---

## Steaming food

 Caution

- To prevent dry heating, add water to the inner pot to at least the 2-cup mark.

You can use the steam (  ) function menu to steam food. For details of adjustable cooking time ranges, please see the "Table of cooking times."

- 1 Follow the steps in "Preparation before cooking."
- 2 Add water to the inner pot to at least the 2-cup mark.
- 3 Put the steaming basket into the inner pot.
- 4 Place food on a plate or directly onto the steaming basket.
- 5 Tap  or  to select steam (  ).
- 6 Tap  to confirm. The rice cooker will start working in the selected mode.
  - The screen first displays a scrolling light, and then shows the remaining cooking time as a countdown once steam is generated.
  - The interface ring blinks.
- 7 The appliance beeps several times after cooking is completed, and automatically switches to keep warm mode.
  - The interface ring will fully illuminate.

---

## Reheat

You can use the reheat menu (  ) to reheat food. For details of adjustable cooking time ranges, please see the "Table of cooking times."

- 1 Make sure the outside of the inner pot is dry and clean, and that there is no foreign residue on the heating element.
- 2 Break up the cooled rice to spread it evenly in the inner pot.
- 3 Add a small amount of water to the rice to prevent it from becoming too dry. The amount of water used depends on the quantity of rice.
- 4 Tap  or  to select the Reheat function.
- 5 Tap  to confirm. The rice cooker will start working in the selected mode.
  - The remaining cooking time is displayed on the screen as a countdown.
  - The interface ring blinks.
- 6 The appliance beeps several times after cooking is completed, and automatically switches to keep warm mode.
  - The interface ring will fully illuminate.

 Caution

- To prevent dry heating or food from drying out, pour some water over the food. The amount of water used depends on the quantity of rice.

## 14 English

---

### Stew

You can use the Stew (  ) menu to stew food. For details of adjustable cooking time ranges, please see the "Table of cooking times."

- 1 Follow the steps in "Preparation before cooking."
- 2 Mix the prepared ingredients and seasonings evenly in the inner pot.
- 3 Tap  or  to select the stew function.
- 4 Tap  to confirm. The rice cooker will start working in the selected mode.
  - ↳ The remaining cooking time is displayed on the screen as a countdown.
  - ↳ The interface ring blinks.
- 5 The appliance beeps several times after cooking is completed, and automatically switches to keep warm mode.
  - ↳ The interface ring will fully illuminate.



#### Caution

- Be sure to select the correct function for stewing to avoid overflow, as this may be dangerous.
- After using the stew function, clean the steam valve and top lid promptly.

---

### Setting the cooking time

You can set the cooking time for some menus, including congee (  ), multigrain congee (  ), soup (  ), stew (  ), steam (  ), and keep warm (  ). For details of the adjustable ranges, please see the "Table of cooking times."

- 1 Tap  or  to select multigrain congee .
- 2 Tap  and 调时 will light up on the screen.
- 3 Tap  or  to adjust the cooking time, then tap  to confirm.
- 4 The rice cooker starts working in the selected mode.

---

### Setting the preset cooking time

You can preset delayed cooking times for some menus. The maximum preset timer is for 24 hours.



#### Caution

- Preset the time you want the cooking to be finished by. For example: If you preset cooking at 12 pm to eat dinner at 6 pm, the preset time is 6 hours.
- The preset time must be later than or equal to the cooking time. If it is equal to the cooking time, cooking will begin immediately.
- The preset function cannot be used with stew, reheat, and keep warm.

- 1 Follow the steps in "Preparation before cooking."
- 2 Tap  or , or the quick menu button to select the desired function.
- 3 Repeatedly tap  until 预约 lights up on the screen.
- 4 Tap  or  to adjust the cooking time, then tap  to confirm.
- 5 The rice cooker starts counting down. Once the countdown ends, the cooking program starts immediately.

## Adjusting the cooking time and preset cooking time

### 1. Adjusting the cooking time for menu functions other than steaming

Press "+" or "-" to increase/decrease the time by 10 minutes.

Press and hold "+" or "-" to quickly increase/decrease the time by 10 minutes.

### 2. Adjusting the cooking time for steaming

Press "+" or "-" to increase/decrease the time by 1 minute.

Press and hold "+" or "-" to quickly increase/decrease the time by 10 minutes.

### 3. Adjusting the preset cooking time

Press "+" or "-" to increase/decrease the time by 10 minutes.

Press and hold "+" or "-" to increase/decrease the time by 1 hour.

### 4. Adjusting the time for the keep warm mode

Press "+" or "-" to increase/decrease the time by 30 minutes. (Pressing "+" will increase the time from 1 minute to 30 minutes.)

Press and hold "+" or "-" to quickly increase/decrease the time by 30 minutes. (Pressing "-" will decrease the time from 30 minutes to 1 minute.)

The selected cooking time will be remembered.

## 4 Cleaning and Maintenance




### Caution

- Unplug the rice cooker before you start cleaning it.
- Wait until the rice cooker has cooled down sufficiently before cleaning it.
- Do not immerse the entire appliance in water when cleaning it. Do not use strong detergents or abrasive brushes to wipe the appliance.

### Inner lid


- Hold the detachable inner lid and pull it outwards to remove it from the top lid for cleaning.




- Soak in hot water and clean with the soft side of a sponge.
- Make sure to remove all the food residue stuck to the rice cooker.
- After cleaning, wipe off any water droplets from the surface of the inner lid, align the detachable inner lid with the slot in the middle, and secure it in place.
- Do not pull on the inner lid sealing ring. After each use, or after using seasonings (when using stew, steam, etc.), clean and rinse the inner lid promptly to prevent odors and rust.

## Moisture lock valve

- Follow the above steps to remove the detachable inner lid.
- Remove the moisture lock valve from the top lid.



- Wash the moisture lock valve under a faucet to ensure there are no food residues inside. After rinsing clean, reattach it to the inner lid.



We recommend wiping the steam valve after each use to maintain cleanliness.

## Interior

### Inside of the outer lid and the main body, and the heating element:

- Wipe with a wrung out and damp cloth.
- Make sure to remove all the food residue stuck to the rice cooker.

## Exterior

### Surface of the outer lid and outside of the main body:

- Wipe the outer surface of the cooker with a wrung out and damp cloth dipped in a mild detergent.
- Only use a soft and dry cloth to wipe the control panel.
- Make sure to remove all food residue.

## Accessories

### Soup ladle, rice spoon, steamer basket, etc.

- Soak in hot water and clean with a sponge.

## Inner pot instructions

## Specifications of inner pot materials

The inner pot of this appliance is made from 316 stainless steel with no chemical coating, making it safe to use.

The outer surface is made of stainless iron (for better heating and heat conduction) and can attract magnets, which is normal.

## Tips to prevent sticking

Once cooking is complete, the appliance enters keep warm mode. For a better texture and taste, and to prevent the rice from clumping, you can use the rice spoon to stir and fluff the rice.

## Everyday maintenance and cleaning

First use: When using the stainless steel inner pot for the first time, clean using a scouring pad and a mild detergent.

Everyday cleaning: Clean immediately after each use to prevent food residue from building up. When cleaning, use a scouring pad and a mild detergent to scrub thoroughly. Turn the inner pot upside down to drain any water and prevent bacterial growth at the bottom.

Stubborn stains: Soak in water for a period of time to soften any residue, then use the rough side of a scouring pad or similar tool to remove the stains.

Dishwasher cleaning: Place upside down in the lower rack of the dishwasher, use dishwasher detergent (such as dishwasher tablets), and select a gentle or standard cleaning cycle.

## Regular deep cleaning of the inner pot

The stainless steel inner pot has no coating, and may discolor over time due to high-temperature oxidation, food pigment deposits, or water quality issues. We recommend performing deep cleaning once a month to extend its service life.

Solution for discoloration due to high-temperature oxidation, water quality, or natural food color deposits: Soak the inner pot in white vinegar for 30 seconds to 5 minutes, then scrub thoroughly using a scouring pad and a mild detergent. Turn the inner pot upside down to drain any water and prevent bacterial growth at the bottom.

## Preventing discoloration and extending service life

Avoid dry heating: Heating without any contents accelerates oxidation.

Minimize the length of time acidic or high-salt foods are left in the appliance.

Use purified water: Hard water can lead to scale deposits. Regularly clean with vinegar.

**Precautions: Do not use bleach or strong acids or alkalis, as they will corrode the stainless steel surface.**

## 5 Recycling

Do not dispose of this appliance with normal household waste. Take it to an official recycling center instead. This will help us to continue protecting the environment. Make sure to follow the classification and recycling regulations for electrical and electronic products in your country/region. Correct disposal of this appliance can help prevent negative consequences for the environment and human health.

## 6 Warranty and Support

Versuni provides a two-year warranty upon purchase of this product. Any malfunction caused by improper use or maintenance of the product will not be covered by the warranty. Our warranty service does not affect your legal rights as a consumer. For more information or to make a claim on your warranty, please visit our website at [www.philips.com/support](http://www.philips.com/support).

## 7 Specifications

Model Number	HD7000
Rated input power (W)	1250
Rated capacity (L)	4.0
Standby power (W)	1.8
Energy consumption during keep warm (W.h)	35
Energy efficiency rating	Class 1
Inner pot material (metal or non-metal)	Metal
Thermal efficiency value (%)	90

## 8 Troubleshooting

If you experience a problem with this appliance, please check all of the following before contacting us. If you still cannot resolve the problem, please contact the Philips service center in your country/region.

Problem	Solution
The button's indicator light does not come on.	<ul style="list-style-type: none"> <li>Connection error. Check that the power cord is securely connected to the rice cooker and the plug is firmly inserted in the power socket.</li> <li>The indicator light is damaged. Please take the appliance to your Philips dealer or an authorized Philips service center.</li> </ul>
The rice is too soft, too hard, or undercooked.	<ul style="list-style-type: none"> <li>If the product is placed on an unstable or sloped surface, the cooked rice may be too hard or too soft because the amount of water will be inconsistent.</li> <li>The rice may taste different depending on its brand, country of origin, and storage time (new or old).</li> <li>The texture of the rice may vary depending on the room temperature and water temperature.</li> <li>Check if the inner pot is deformed.</li> <li>The water level lines in the inner pot are for reference only, and more or less water may be required based on different types and qualities of rice used.</li> <li>Make sure nothing is inside the appliance or on the surface of the inner pot before switching it on.</li> </ul>
The rice is burnt.	<ul style="list-style-type: none"> <li>Check for any food residue inside the appliance or on the surface of the inner pot. Remove any leftover food.</li> <li>The uncooked rice was not washed. Rinse the rice until the water runs clear.</li> <li>Check if the inner pot is deformed.</li> </ul>
Water is leaking out of the product during cooking.	<ul style="list-style-type: none"> <li>Make sure you add the correct amount of water up to the water level marked on the inner pot for the amount and type of rice you are cooking.</li> <li>Ensure that the water does not exceed the highest level indicated on the inner pot, otherwise the appliance may overflow when cooking.</li> </ul>

Problem	Solution
The display is not working.	<ul style="list-style-type: none"> <li>The rice cooker is not plugged in.</li> </ul>
The rice has an unpleasant smell after cooking.	<ul style="list-style-type: none"> <li>Wash the inner pot with detergent and warm water.</li> <li>Clean the steam valve, inner lid, and inner pot thoroughly after use.</li> </ul>
The problem has not gone away.	<ul style="list-style-type: none"> <li>Your rice cooker may be faulty. If this occurs, please perform the following:           <ol style="list-style-type: none"> <li>1 Self-service. Contact Customer Service and we can provide you with instructions and support via video.</li> <li>2 Repair service. Send the product to a Philips service center.</li> <li>3 On-site service. Please contact us and we will assist you in arranging a Philips authorized repair visit at no additional cost.</li> </ol> </li> </ul>
An error message (such as E1 or E2) is displayed.	The appliance's sensor is faulty. Please take the appliance to your Philips dealer or an authorized Philips service center.

## 9 Explanation of Protection Codes

If one of the following protection codes appears during normal use of this Philips product, you may refer to the following instructions for handling, or you may also call the Philips after-sales service team for professional service and assistance.

Please note that these protective features are designed to protect the product from damage caused by improper use, and are not a sign that there is something wrong with the product.

Protection Code	Purpose	Action to Take
C2	Protection against incorrect placement of the inner pot. Recoverable.	First disconnect the power supply, then check whether the inner pot is inserted correctly before reconnecting the power supply. If the C2 protection code no longer appears, you may use the product as normal. If the C2 protection code still appears, please call the Philips after-sales service team for professional service and assistance.
C1	Protection against overheating of the motherboard's IGBT. Recoverable.	Check that the air inlet and outlet are unobstructed and that the fan is rotating smoothly, and then reconnect to the power supply. If the C1 protection code no longer appears, you may use the product as normal. If the C1 protection code still appears, please call the Philips after-sales service team for professional service and assistance.
EH	Protection against input overvoltage. Recoverable.	Check that the power supply is stable before using the product. If the power supply is confirmed to be stable and this code is still displayed, please call the Philips after-sales service team for professional service and assistance.
EL	Protection against the power supply being too low. Recoverable.	Check that the power supply is stable before using the product. If the power supply is confirmed to be stable and this code is still displayed, please call the Philips after-sales service team for professional service and assistance.

# 目錄

<b>1 重要事項 .....</b>	<b>21</b>	<b>4 清潔及保養 .....</b>	<b>32</b>
危險事項 .....	21	內上蓋 .....	33
警告 .....	21	鎖水閥 .....	33
注意事項 .....	21	內部 .....	33
電磁場 (EMF) .....	22	外觀 .....	34
<b>2 電飯煲 .....</b>	<b>23</b>	配件 .....	34
產品概要 .....	23	內鍋說明 .....	34
控制面板概覽 .....	24	<b>5 回收 .....</b>	<b>35</b>
額外說明 - 指示標貼 .....	25	<b>6 保養及支援 .....</b>	<b>35</b>
<b>3 使用電飯煲 .....</b>	<b>25</b>	<b>7 規格 .....</b>	<b>35</b>
首次使用前 .....	25	<b>8 疑難排解 .....</b>	<b>36</b>
烹調時間設定表 .....	26	<b>9 保護代碼說明 .....</b>	<b>37</b>
烹調前準備 .....	27		
煮飯 .....	28		
煲仔飯 .....	28		
低醣飯 .....	29		
雙層飯 .....	29		
煲粥及煲湯 .....	30		
蒸煮食物 .....	30		
翻熱 .....	31		
燜燉 .....	31		
設定烹調時間 .....	31		
設定預設烹調時間 .....	32		
調整烹調時間及預設烹調時間 .....	32		

# 1 重要事項

使用本產品前請仔細閱讀這些安全指引，並存放在安全的地方以備將來參考。

## 危險事項

- 請勿將本產品浸入水中。

## 警告

- 本產品並不適合身體、感覺或心智能力低下人士（包括兒童），或缺乏經驗及知識人士使用，除非使用產品時有負責其安全之人士監督或指導。
- 兒童應受監督以確保他們不會將產品當作玩具。
- 移動產品時請使用把手（如有）以確保安全，並避免熱燙液體溢出。
- 請勿在潮濕的表面使用產品。
- 本產品只供家居使用及其他類似用途，例如：
  - 店鋪、辦公室及其他工作環境的員工廚房；
  - 農舍；
  - 供酒店、旅館及其他居所的住客使用；
  - 只提供早餐的民宿或類似環境。
- 如電線損壞，必須以生產商提供的電線更換。
- 本電器不得以外部計時器或其他遙控系統操作使用。
- 在連接本產品前，請檢查產品註明的指示電壓與當地電源電壓是否對應。
- 僅將電飯煲連接上接地的電源插座。務必確保插頭已穩固插入電源插座。
- 如插頭、電源線、內鍋、密封圈或機身受損，切勿使用本產品。
- 請勿將電源線懸掛於放置產品的桌面或工作檯邊緣。
- 將插頭插入電源插座前，確保加熱元件、溫度感應器及內鍋外部清潔乾爽。
- 請勿用濕手插入本產品的電源，或按下控制面板的任何按鈕。
- 產品在使用期間及停止運作後的短時間內，蒸氣閥及當中的液體及蒸氣溫度會非常高。在蒸氣閥完全冷卻前，切勿嘗試卸除蒸氣閥。

## 注意事項

- 請勿使用由其他製造商生產或非 Philips 特別推薦的任何配件或部件，因而導致保養失效。
- 請勿將產品暴露於高溫之中，也不要放置於正在使用或仍然燙熱的爐子或廚具上。
- 請勿將產品暴露於直射陽光下。
- 將本產品放置在穩定、平滑且平坦的表面上。
- 將插頭插入電源插座並開啟之前，務必將內鍋放入本產品內。
- 請勿將內鍋直接放置在明火上煮食。
- 如內鍋變形，則請勿使用。
- 產品運作期間，可接觸的表面或會變熱。操作產品時請加倍小心。
- 當本產品運作時，請勿用布遮蓋蒸氣通氣孔。
- 煮食時小心從蒸氣通氣孔噴出的高熱蒸氣，以及在打開煲蓋時從產品噴出的蒸氣。將雙手及臉部遠離本產品，以免受蒸氣燙傷。
- 產品運作時，請勿將其抬起或移動。
- 請勿超過內鍋註明的最高水位，以免溢出造成危險。
- 烹調、保溫或翻熱米飯期間，請勿將廚具放入鍋內。
- 僅使用隨附的廚具。避免使用尖銳的廚具。
- 請勿將金屬物件或異物插入蒸氣氣孔。
- 請勿將磁性物質放在蓋上。請勿在磁性物質附近使用本產品。
- 清潔或移動本產品之前，務必讓本產品冷卻下來。
- 每次使用本產品後都應清潔。請參閱「清潔與保養」部分了解詳細清潔指示。
- 如長時間不使用本產品，務必拔除插頭。
- 在搬動本產品時，請加倍留意緊握，以防止本產品掉落並造成傷害。
- 在打開煲蓋後切勿立即觸摸內鍋以避免燙傷。

## 22 繁體中文

- 在煮食期間切勿發開煲蓋以避免燙傷。
- 本產品適用於海拔 0 至 2000 米的環境。
- 清潔時避免內鍋與其他金屬器具接觸，以免因刮刷或電解反應導致不銹鋼鏽蝕。
- 如不當使用本產品或沒有按照本用戶手冊的指示使用，保養將會失效，而 Philips 拒絕承擔任何造成的損壞。請前往 <https://www.philips.com.cn/c-m/consumer-support> 下載用戶手冊。
- 加熱元件表面在使用過後可能尚有餘熱。
- 使用時確保將電源插頭完全插入並穩妥接觸電源插座。
- 如需使用電源延長插座，請確保使用符合果奶標準的插座。
- 產品不再使用時請拔除電源。
- 如出現異常噪音、異味、溫度過高故障情況，應立即停用產品，關閉並拔除電源。
- 切勿將產品連接燈具電源插座。
- 所有連接至同一個延長電源插座的家電額定總電流不得超出所接駁的原插座或電源線的額定電流。
- 不得在靠近易燃易爆物品或類似環境下使用本產品。
- 不得自行拆解產品或修改內部電路、部件或保護裝置。
- 拔除裝置電源時，切勿拉扯電源線。
- 切勿以超出指定電容值的一般導電或保險斷電裝置替換產品的保險絲。
- 不得自行修改低電壓電路斷電器或漏電斷路器。

## 電磁場 (EMF)


這款產品符合有關電磁場暴露的適用安全標準及條例。

## 2 電飯煲

感謝您購買 Philips 產品，歡迎來到 Philips 世界！

為有助您充分利用 Philips 提供的支援，請確保在此網址註冊您的產品：[www.philips.com.cn](http://www.philips.com.cn)。


### 產品概要



## 24 繁體中文


①	頂蓋	⑨	快速入門指南
②	分離式上蓋	⑩	低醣蒸釜
③	水位顯示	⑪	量杯
④	內鍋	⑫	電源線
⑤	開蓋按鈕	⑬	蒸氣閥
⑥	電源插座	⑭	控制面板
⑦	飯勺		
⑧	湯勺		

## 控制面板概覽



	返回按鈕		食譜選擇/時間調整按鈕
	口感選擇按鈕		食譜選擇/時間調整按鈕
	預約/時間按鈕		確認按鈕
	快速煮飯捷徑按鈕		美味白飯按鈕
	煲粥按鈕		低醣飯按鈕

## 額外說明 - 指示標貼



備註：使用前請移除指示標貼

## 3 使用電飯煲

### 首次使用前

- 1 除下產品的所有包裝。
- 2 從內鍋取出所有配件。
- 3 首次使用電飯煲前，請徹底清潔電飯煲的部件（請參閱「清潔與保養」部分）。

 注意

- 開始使用電飯煲前，確保所有部件完全乾透。
- 確保內鍋外部乾爽清潔，產品內側沒有異物。
- 檢查內鍋與加熱元件適當接合。

**烹調時間設定表**

烹調功能	預設烹調時間	烹調時間範圍	預設時間	軟硬口感
快速煮飯	30 分鐘	無法調整	1-24 小時	無法調整
	45 分鐘	無法調整	1-24 小時	標準
美味白飯	50 分鐘	無法調整	1-24 小時	軟綿
	40 分鐘	無法調整	1-24 小時	軟韌
煲仔飯	1 小時	無法調整	無法調整	無法調整
	1 小時	無法調整	1 小時 30 分鐘-24 小時	標準
雜糧飯	65 分鐘	無法調整	1 小時 30 分鐘-24 小時	軟綿
	55 分鐘	無法調整	1 小時 30 分鐘-24 小時	軟韌
煲粥	1 小時	1-2 小時	預設烹調時間-24 小時	無法調整
雜糧粥	70 分鐘	1 小時 10 分鐘-4 小時	預設烹調時間-24 小時	無法調整
煲湯	2 小時	1 小時 30 分鐘-4 小時	預設烹調時間-24 小時	無法調整
蒸煮	30 分鐘	1 分鐘-1 小時	1 小時 30 分鐘-24 小時	無法調整
燜燉	2 小時	1-4 小時	無法調整	無法調整
翻熱	25 分鐘	無法調整	無法調整	無法調整
保溫	2 小時	1 分鐘-12 小時	無法調整	無法調整
雙層飯	50 分鐘	無法調整	1-24 小時	無法調整
低醣飯	45 分鐘	無法調整	1-24 小時	無法調整
	60 分鐘	無法調整	1 小時 30 分鐘-24 小時	標準
糙米	65 分鐘	無法調整	1 小時 30 分鐘-24 小時	軟綿
	55 分鐘	無法調整	1 小時 30 分鐘-24 小時	軟韌

- 以上時間設定表列出所有烹調功能的預設烹調時間，即畫面中最初顯示的烹調時長。
- 烹調時間可能因應烹調環境、米類和水量等因素而有所不同。因此實際完成時間視乎產品完成烹調的時間而定。
- 如所選食譜可調整烹調時間，產品會在開始烹調時記住所選烹調時間。如所選食譜只提供預設延時烹調時間，產品會在開始烹調時記住預設時間。如所選食譜可調整口感設定，產品會在開始烹調時記住所選口感。
- 一旦開始烹調，產品會記住曾經使用的食譜。關閉並重新開啟電源後，此食譜會設為預設選擇的食譜。

## 烹調前準備

### ！ 警告

- 確保分離式內上蓋及蒸氣閥已正確安裝。
- 開始使用電飯煲前，確保所有部件完全乾透。
- 烹調程序完成後，將電飯煲的插頭從電源插座拔出。
- 請勿超出內鍋註明的食材容量或最高水位，否則可能導致水從電飯煲溢出。

### 注意


- 在烹調期間打開煲蓋後（尤其是加入大量清水時），請慢慢關上煲蓋；或者等候 1-2 分鐘，讓內部蒸氣消散/氣壓降低後再關上煲蓋。這有助防止內鍋中的液體從蒸氣通氣孔噴出。
- 本產品適用於海拔 2000 米下的環境。
- 烹飯時，請遵從內鍋內部註明的水量。您可根據不同米類和個人喜好調整水位，但不應超過指示的最高水位。
- 在烹調程序開始後 30 秒內，您可按一下  以取消目前操作，並返回設定介面。烹調開始 30 秒後，您可在 3 秒內按兩下  以取消目前操作，並返回設定介面。
- 如果開啟電飯煲後 5 分鐘並無任何操作，電飯煲會進入待機模式。您可以按下任何按鈕，以從待機模式喚醒產品並返回設定介面。
- 在設定介面中，您選擇的菜單會完全亮起，未有選擇的菜單則不會亮燈。

使用電飯煲前，請作以下烹調前準備：

1 按下開蓋按鈕打開頂蓋。




2 從電飯煲拿出內鍋。




## 28 繁體中文

3 將已清洗的食物放進內鍋，以柔軟的抹布抹乾表面和內鍋底部，然後放回電飯煲。



4 將插頭插入電源插座。



### 注意事项

- 確保內鍋外部乾爽清潔，加熱元件上沒有異物。
- 檢查內鍋與加熱元件適當接合。

## 煮飯

您可以使用以下菜單煮飯：快速煮飯 ( )、美味白飯 ( )、雜糧飯 ( ) 和糙米飯 ( )。請參閱「烹調時間設定表」，查看可調整烹調時間範圍。

- 1 請遵循「烹調前準備」內所列的步驟。
- 2 點按 ( ) 或快捷菜單按鈕以選擇一種烹調程序。
- 3 選擇美味白飯、雜糧飯或糙米飯功能後，您可點按 ( ) 選擇所需口感。
- 4 點選 ( ) 確認。電飯煲會開始在所選模式下運作。
  - 剩餘烹調時間會以倒數形式顯示於螢幕上。
  - 介面環會隨即閃動。
- 5 產品會在烹調完成後發出數下嗶聲，然後自動切換至保溫模式。
  - 介面環會完全亮起。

## 煲仔飯

您可使用煲仔飯 ( ) 菜單，烹調鍋底帶有飯焦的廣式煲仔飯。請參閱「烹調時間設定表」，查看可調整烹調時間範圍。

- 1 請遵循「烹調前準備」內所列的步驟。
- 2 要烹調煲仔飯，只需在米飯和水中加入適量的食用油，然後均勻攪拌。
- 3 點按 ( ) 或 ( ) 以選擇煲仔飯功能。

- 4 點選  確認。電飯煲會開始在所選模式下運作。
  - ↳ 剩餘烹調時間會以倒數形式顯示於螢幕上。
  - ↳ 介面環會隨即閃動。
- 5 烹調期間響起中段嗶聲（顯示 35 分鐘）時，打開煲蓋並快速加入材料，然後關上煲蓋繼續烹調程序。
- 6 產品會在烹調完成後發出數下嗶聲，然後自動切換至保溫模式。
  - ↳ 介面環會完全亮起。



### 注意

- 建議使用泰國香米（吸收較少水分，口感更佳）。
- 建議米量杯數：使用 3 至 6 杯米製作出煲底飯焦效果。
- 食材比例：如加入 3 杯米，則加水至 3 杯分量的刻度，加入 3 茶匙油，然後均勻攪拌（1 茶匙 = 5 毫升）。

---

## 低醣飯

您可使用低醣飯菜單減少米飯的碳水含量。請參閱「烹調時間設定表」，查看可調整烹調時間範圍。

- 1 將 2 杯清洗過的米放入低醣蒸釜並均勻鋪開。
- 2 在內鍋注水至蒸煮刻度。
- 3 將低醣蒸釜放入內鍋。
- 4 在低醣蒸釜注水至低醣飯刻度。不要超出 2 杯刻度。
- 5 點按低醣飯快速烹調菜單按鈕。
- 6 點選  確認。電飯煲會開始在所選模式下運作。
  - ↳ 剩餘烹調時間會以倒數形式顯示於螢幕上。
  - ↳ 介面環會隨即閃動。
- 7 產品會在烹調完成後發出數下嗶聲，然後自動切換至保溫模式。
  - ↳ 介面環會完全亮起。



### 注意事項

- 烹調低醣飯時，注水量不能超出低醣蒸釜的最高刻度。（烹調 1 杯米應注水至 1 杯刻度，這樣米和水的混合總量便不會多於 2 杯。）
- 要避免在乾水情況下加熱，可在煲底注水至蒸煮刻度。
- 烹調低醣飯時，不要選擇「低醣飯」以外的其他菜單功能。否則電飯煲可能無法正常運作。

---

## 雙層飯

您可使用雙層飯菜單功能，烹調不同口感的米飯以迎合各種口味。請參閱「烹調時間設定表」，查看可調整烹調時間範圍。

- 1 將洗好的米放入內鍋，並注水至雙層飯刻度。確保米和水的混合總量沒有超出 2 杯。
- 2 將洗好的米放入低醣蒸釜，並注水至雙層飯刻度。確保米和水的混合總量沒有超出 2 杯。
- 3 將低醣蒸釜放入內鍋。
- 4 點按  或  以選擇雙層飯功能。
- 5 點選  確認。電飯煲會開始在所選模式下運作。
  - ↳ 剩餘烹調時間會以倒數形式顯示於螢幕上。
  - ↳ 介面環會隨即閃動。

## 30 繁體中文

6 產品會在烹調完成後發出數下嗶聲，然後自動切換至保溫模式。  
→ 介面環會完全亮起。

### 注意事项

- 烹調雙層飯時，注水量不能超出低醣蒸釜的最高刻度。（烹調 1 杯米應注水至 1 杯刻度，這樣米和水的混合總量便不會多於 2 杯。）
- 不要在內鍋煲粥並同時在蒸架蒸飯。兩個容器必須同步蒸飯以避免溢出。
- 烹調雙層飯時，不要選擇「雙層飯」以外的其他菜單功能。否則電飯煲可能無法正常運作。

## 煲粥及煲湯

您可使用雜糧粥 (粥) 和煲粥 (粥) 菜單來烹調粥品；並使用煲湯 (湯) 菜單煲湯。請參閱「烹調時間設定表」，查看可調整烹調時間範圍。

- 請遵從「烹調前準備」內所列的步驟。
- 點按 (或) 以選擇所需烹調程序。
- 點選 (確認。電飯煲會開始在所選模式下運作。  
→ 剩餘烹調時間會以倒數形式顯示於螢幕上。  
→ 介面環會隨即閃動。
- 產品會在烹調完成後發出數下嗶聲，然後自動切換至保溫模式。  
→ 介面環會完全亮起。

### 注意事项

- 確保選擇正確的煲粥或煲湯功能以避免溢出並造成危險。

## 蒸煮食物

### 注意事项

- 要避免在乾水情況下加熱，至少在內鍋注水至 2 杯刻度。

您可使用蒸煮 (蒸) 功能菜單蒸煮食物。請參閱「烹調時間設定表」，查看可調整烹調時間範圍。

- 請遵從「烹調前準備」內所列的步驟。
- 至少在內鍋注水至 2 杯刻度。
- 將蒸架放入內鍋。
- 將食物放在碟上，或直接放在蒸架上。
- 點按 (或) 以選擇「蒸煮」(蒸)。
- 點選 (確認。電飯煲會開始在所選模式下運作。  
→ 螢幕會先顯示滾動燈光，然後在產生蒸氣後以倒數形式顯示剩餘的烹調時間。  
→ 介面環會隨即閃動。
- 產品會在烹調完成後發出數下嗶聲，然後自動切換至保溫模式。  
→ 介面環會完全亮起。

## 翻熱

您可使用翻熱功能 (◎) 翻熱食物。請參閱「烹調時間設定表」，查看可調整烹調時間範圍。

- 1 確保內鍋外部乾爽清潔，加熱元件上沒有異物。
- 2 散開冷飯以均勻鋪平在內鍋中。
- 3 在冷飯內加入少量水分以免口感太乾。所添加水量視乎飯量而定。
- 4 點按 (◎) 或 (▽) 以選擇翻熱功能。
- 5 點選 (●) 確認。電飯煲會開始在所選模式下運作。
  - 剩餘烹調時間會以倒數形式顯示於螢幕上。
  - 介面環會隨即閃動。
- 6 產品會在烹調完成後發出數下嗶聲，然後自動切換至保溫模式。
  - 介面環會完全亮起。

### 注意事項

- 要避免在乾水情況下加熱或食物太乾，可在食物表面加水。所添加水量視乎飯量而定。

## 燜燉

您可使用燜燉 (¶) 菜單燜煮食物。請參閱「烹調時間設定表」，查看可調整烹調時間範圍。

- 1 請遵從「烹調前準備」內所列的步驟。
- 2 將準備好的食材及調味料在內鍋均勻混合。
- 3 點按 (◎) 或 (▽) 以選擇燜燉功能。
- 4 點選 (●) 確認。電飯煲會開始在所選模式下運作。
  - 剩餘烹調時間會以倒數形式顯示於螢幕上。
  - 介面環會隨即閃動。
- 5 產品會在烹調完成後發出數下嗶聲，然後自動切換至保溫模式。
  - 介面環會完全亮起。

### 注意事項

- 確保選擇正確的燜燉功能以避免溢出並造成危險。
- 使用燜燉功能後，請及時清潔蒸氣閥和頂蓋。

## 設定烹調時間

您可以設定部分菜單的烹調時間，包括粥 (¶)、雜糧粥 (¶)、湯 (¶)、燜燉 (¶)、蒸煮 (¶) 及保溫 (¶)。請參閱「烹調時間設定表」，查看可調整時間範圍。

- 1 點按 (◎) 或 (▽) 以選擇雜糧粥 (¶)。
- 2 點按 (◎) 及 調時 後螢幕會隨即亮起。
- 3 點按 (◎) 或 (▽) 以調整烹調時間，然後點按 (●) 確認。
- 4 電飯煲會開始在所選模式下運作。

### 設定預設烹調時間

您可以為部分菜單預設延時烹調時間。最長預設時間為 24 小時。



#### 注意事項

- 預設您所需的烹調完成時間。例如：如果您在中午 12 時預設烹調並於下午 6 時享用晚餐，則預設時間為 6 小時。
- 預設時間必須長於或等於烹調時間。如果預設時間等於烹調時間，烹調程序會立即開始。
- 預設功能不能與燜燉、翻熱和保溫功能同時使用。

- 1 請遵循「烹調前準備」內所列的步驟。
- 2 點按 、 或快捷菜單按鈕以選擇所需功能。
- 3 重複點按 直至 預約 在螢幕亮起。
- 4 點按 或 以調整烹調時間，然後點按 確認。
- 5 電飯煲會開始倒數。倒數結束後，烹調程序會立即開始。

### 調整烹調時間及預設烹調時間

#### 1. 調整蒸煮功能以外的菜單功能烹調時間

按下「+」或「-」增加/減少烹調時間 10 分鐘。

按住「+」或「-」以快速增加/減少烹調時間 10 分鐘。

#### 2. 調整蒸煮的烹調時間

按下「+」或「-」增加/減少烹調時間 1 分鐘。

按住「+」或「-」以快速增加/減少烹調時間 10 分鐘。

#### 3. 調整預設烹調時間

按下「+」或「-」增加/減少烹調時間 10 分鐘。

按住「+」或「-」以增加/減少烹調時間 1 小時。

#### 4. 調整保溫模式的時間

按下「+」或「-」增加/減少烹調時間 30 分鐘。（按下「+」會將烹調時間從 1 分鐘延長至 30 分鐘。）

按住「+」或「-」以快速增加/減少烹調時間 30 分鐘。（按下「-」將烹調時間從 30 分鐘縮短至 1 分鐘。）

產品會記錄所選烹調時間。

## 4 清潔及保養




#### 注意事項

- 開始清潔前，先拔除電飯煲的插頭。
- 等待電飯煲完全冷卻才清潔。
- 清潔時請勿將整個電飯煲浸入水中。切勿使用高強度清潔劑或研磨性刷子抹擦產品。

## 內上蓋


- 拿著可拆式內上蓋，並將其從頂蓋移除，以進行清洗。




- 放入熱水浸泡，並以海綿的柔軟一面清潔。
- 確保清除所有黏在電飯煲上的所有食物殘渣。
- 清潔後抹走內鍋表面的所有水分，將可拆式內上蓋與中間的凹槽對齊並裝回原位。
- 請勿拉扯內上蓋的密封圈。每次使用後或使用調味料後（燜燉、蒸煮等），請及時清潔和洗淨內鍋以防產生異味和生銹。

## 鎖水閥

- 按照以上步驟移除可拆式內上蓋。
- 從頂蓋取出鎖水閥。



- 在水龍頭下沖洗鎖水閥，確保當中並無食物殘留。沖洗乾淨後重新安裝至內上蓋。



我們建議每次使用抹淨蒸氣閥以保持清潔。

## 內部

### 外蓋的內部、主體及加熱元件：

- 用擰乾的濕布擦拭。
- 確保清除所有黏在電飯煲上的所有食物殘渣。

## 外觀

### 外蓋表面和機身外部：

- 用擰乾的濕布和溫和的清潔劑擦拭電飯煲的外部表面。
- 請務必用柔軟的乾布擦拭控制面板。
- 確保清除所有食物殘渣。

## 配件

### 湯勺、飯勺、低醣蒸蓋等。

- 放入熱水浸泡，用海綿清潔。

## 內鍋說明

### 內鍋物料規格說明

本產品的內鍋採用不含化學塗層的 316 不銹鋼製成，可放心安全使用。

外鍋以鑄鐵不銹鋼物料製成（能有效加熱和導熱），並會吸附磁鐵，此為正常情況。

### 防黏底烹調貼士

完成烹調後，產品會進入保溫模式。要獲取更佳口感和味道，以及防止黏底，可使用飯勺攪拌使米飯鬆軟。

### 日常保養和清潔

首次使用：首次使用不銹鋼內鍋時，先以百潔布及溫和的清潔劑清潔。

日常清潔：每次使用後立即清潔，避免持續積聚食物殘渣。清潔時使用百潔布及溫和的清潔劑徹底拭擦乾淨。倒轉內鍋排走積水，以免鍋底滋生細菌。

頑固污垢：浸入水中一段時間以軟化任何殘渣，然後使用百潔布粗糙的一面或類似工具清除污垢。

使用洗碗機清潔：將內鍋放在洗碗機的低層擋架，使用如洗碗機專用凝塊，並選擇溫和或標準清洗程序清潔。

### 為內鍋進行定期深層清潔

不銹鋼內鍋不含塗層，因此會因高溫氧化，食物色素沉澱或水質影響逐漸褪色。我們建議每月進行一次深層清潔，以延長內鍋的使用壽命。

因高溫氧化、水質或天然食物色素沉澱導致褪色問題的解決方法：將內鍋浸入白醋中 30 秒至 5 分鐘，然後用百潔布及溫和清潔劑徹底拭擦。倒轉內鍋排走積水，以免鍋底滋生細菌。

### 預防褪色並延長使用壽命

避免在乾水情況下加熱：在沒有加入任何食材下加熱會加速內鍋氧化。

盡快從煲內取出酸性或高鹽度食物。

使用純淨水：硬水會導致鈣沉積。定期用醋清潔。

**注意事項：切勿使用漂白劑或強酸或強鹼清潔內鍋，因其會導致不銹鋼表面腐蝕。**

## 5 回收

請勿與一般家庭廢棄物一併丟棄本產品。應帶往官方回收中心回收。這樣有助我們持續保護環境。遵守國家/地區有關電子設備和產品的分類回收法規。妥善棄置本產品有助預防對環境和人體造成負面影響。

## 6 保養及支援

Versuni 為這款產品提供購買後兩年保養。此保養不適用於因不正確使用或維護不良而造成的損壞。我們的保養不會影響您作為消費者的法律權利。有關啟動保養的詳情，請瀏覽我們的網站：  
[www.philips.com/support](http://www.philips.com/support)。

## 7 規格

型號	HD7000
額定輸入功率 (瓦)	1250
標準容量 (升)	4.0
待機耗電量 (瓦)	1.8
保溫模式耗電量 (瓦時)	35
能源效率等級	1 級
內鍋物料 (金屬或非金屬)	金屬
熱能效益值 (%)	90

## 8 疑難排解

如果您在使用產品時遇到問題，請於送修前先行檢查下列事項。如果無法解決問題，請聯絡您所在國家的 Philips 客戶服務中心。


問題	解決方案
按鈕的指示燈沒有亮起。	<ul style="list-style-type: none"> <li>連接錯誤。檢查並確保電源線已穩妥接上電飯煲，以及插頭已穩固插入電源插座。</li> <li>指示燈損壞。請帶同產品前往 Philips 代理商或認可的 Philips 服務中心。</li> </ul>
飯太軟、太硬或未煮熟。	<ul style="list-style-type: none"> <li>如果將本產品放置在不穩定或傾斜的表面上，煮熟的飯可能因為水位不均勻而太硬或太軟。</li> <li>米飯可能因應米的品牌、原產地、儲存時間（新貨舊米）導致口感不同。</li> <li>飯的質地可能會根據室溫和水溫而變化。</li> <li>檢查內鍋有否變形。</li> <li>內鍋的水位線只供參考，可能需因應不同類型的米粒或所使用的米量多加或減少水量。</li> <li>啟動電源時確保產品內部或內鍋表面並無異物。</li> </ul>
米飯燒焦。	<ul style="list-style-type: none"> <li>檢查本產品內部或內鍋表面是否有食物殘渣。清除所有殘留的食物。</li> <li>您沒有正確洗米。洗米直至水呈透明色。</li> <li>檢查內鍋有否變形。</li> </ul>
烹調期間有水從煲內溢出。	<ul style="list-style-type: none"> <li>確保您加入不超出內鍋上標示水位及所烹調飯量和類型的正確水量。</li> <li>確保水量並無超出內鍋標示的最高水位，否則烹調時食物可能溢出。</li> </ul>
螢幕沒有顯示內容。	<ul style="list-style-type: none"> <li>電飯煲並無連接電源。</li> </ul>
完成烹調後米飯發出難聞氣味。	<ul style="list-style-type: none"> <li>用洗潔劑和溫水清洗內鍋。</li> <li>使用後徹底清潔蒸氣閥、內上蓋及內鍋。</li> </ul>
問題仍然持續。	<ul style="list-style-type: none"> <li>電飯煲可能出現故障。如屬此情況，請使用：           <ol style="list-style-type: none"> <li>自助服務。請聯絡客戶服務中心，我們或能夠提供影片和指引，協助您解決問題。</li> <li>維修服務。請攜同您的產品前往 Philips 客戶服務中心。</li> <li>上門維修。請聯絡我們，我們會協助您安排 Philips 認可的人員維修您的產品，這項服務無須額外收費。</li> </ol> </li> </ul>
顯示錯誤訊息（如 E1 或 E2 等）。	電飯煲感應器出現故障。請帶同產品前往 Philips 代理商或認可的 Philips 服務中心。

## 9 保護代碼說明

如在正常使用此 Philips 產品期間顯示以下保護代碼，請按照下列指示處理，或您可致電聯絡 Philips 售後服務團隊獲取專業維修服務和協助。

請注意，這些保護功能專為保護產品因不當使用而導致損壞而設，並不表示產品本身存在問題。

保護代碼	可能的原因	解決辦法
C2	內鍋放入不當保護。可復原操作。	首先中斷連接電源，然後檢查內鍋是否正確放入，再重新連接電源。產品停止顯示 C2 保護代碼，您可正常使用產品。如果產品仍然顯示 C2 保護代碼，請致電聯絡 Philips 售後服務團隊獲取專業維修服務和協助。
C1	保護主板的 IGBT 免受過熱短路。可復原操作。	先檢查進氣口和排氣口是否堵塞，以及風扇是否順暢轉動，然後重新連接電源。產品停止顯示 C1 保護代碼，您可正常使用產品。如果產品仍然顯示 C1 保護代碼，請致電聯絡 Philips 售後服務團隊獲取專業維修服務和協助。
EH	輸入過壓保護。可復原操作。	使用產品前先確保所輸入的電源穩定。如確定電源穩定但產品仍然顯示此保護代碼，請致電聯絡 Philips 售後服務團隊獲取專業維修服務和協助。
EL	電源過低保護。可復原操作。	使用產品前先確保所輸入的電源穩定。如確定電源穩定但產品仍然顯示此保護代碼，請致電聯絡 Philips 售後服務團隊獲取專業維修服務和協助。





飛利浦及飛利浦盾徽標誌是 Koninklijke Philips N.V.  
的註冊商標且經許可使用。

本產品由 Versuni Holding B.V. 負責生產並銷售，  
且 Versuni Holding B.V. 是本產品的擔保方。

2025 © Versuni Holding B.V.  
保留所有權力。

642001014158



[www.philips.com](http://www.philips.com)