

ENGLISH

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs (Fig. 2).
- To protect against electrical shock do not immerse cord, plug or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children or invalids. Children should be supervised by a responsible person to ensure they do not play with the appliance.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. For assistance in the U.S. and Canada only, call 1-866-309-8817.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not block any ventilation openings. Install in accordance with the manufacturer’s instructions.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Plug the cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Use extreme caution when removing the pan, basket and disposing hot grease.
- Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- Use only on properly grounded outlet.
- A short power-supply (or detachable power-supply cord) should be used to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- Extension cords may be used if care is exercised in their use. If an extension cord is used:
 - The marked electrical rating of the cord must be as great as the rating of the appliance.
 - The cord should be arranged so that it will not drape over the edge of the counter or table top where it could be pulled by children or tripped over unintentionally.
 - If the appliance is of grounded type, the extension cord should be a grounded-type 3-wire cord.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
- Oversize foods or metal utensils must not be inserted in the appliance as they may create a risk of fire or electric shock.
- Fire may occur if the appliance is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation. Do not store any item on top of the appliance when in operation.
- Do not place any of the following materials in the appliance: paper, cardboard, plastic and the like.
- Immediately unplug appliance if you see dark smoke coming out of appliance. Wait for smoke emission to stop before pulling pan out of appliance.
- Use on a flat, stable, heat-resistant surface away from water or any heat source.
- Do not leave appliance unattended while operating.
- This appliance operates at high temperatures which may cause burns. Do not touch hot surfaces, parts or inside of appliance while operating (Fig. 2). Allow appliance to cool down completely before handling or cleaning.
- During hot air frying, hot steam is released through the hot air intake openings. Keep hands and face away from steam and air outlet openings.
- Avoid contacting moving parts.
- This appliance works with hot air only; food is not fried in oil or fat! Never fill fat or oil into the pan.
- This product is for household use only.
- Never use the airfryer without the pan and basket in place.
- Be sure before each use of the device that the heater and heater surrounding are clean and clear from any food remainders in order to ensure a flawless function.
- Never use light ingredients or baking paper in the appliance.
- Never touch the inside of the appliance while it is operating.
- Do not place the appliance on or near combustible materials such as a tablecloth or curtain.
- Do not let the appliance operate unattended.
- Immediately unplug the appliance if you see dark smoke coming out of the appliance. Wait for the smoke emission to stop before you pull the pan out of the appliance.

SAVE THESE INSTRUCTIONS

Consuming raw or undercooked meats, poultry, seafood, shellfish or egg may increase your risk of foodborne illness.

Make sure ingredients prepared in this appliance come out golden-yellow instead of dark brown. Remove burnt remnants. For best results, do not fry fresh potatoes at a temperature above 360°F/180°C or beyond golden-yellow.

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome

Your new airfryer allows you to prepare your favorite ingredients and snacks in a healthy way.

The airfryer uses hot air in combination with high-speed air circulation (Rapid Air) and a top grill to prepare a variety of tasty dishes in a healthy, fast and easy way. Your ingredients are heated from all sides and there is no need to add oil to most of the ingredients. For more inspiration, recipes and information about the airfryer, visit www.philips.com/kitchen

General description (Fig. 1)

- Basket
- MAX indication
- Basket handle
- Pan
- Control panel

A - Power on/off button

B - START/PAUSE button

C - Preset button

D - Temperature increase and decrease buttons

E - Time/temperature indication

F - Timer increase and decrease buttons
- Drawer
- Hot air outlet openings
- Air inlet

Automatic shut-off

This appliance is equipped with an automatic shut-off. If you do not press a button within 30 minutes, the appliance switches off automatically. To switch off the appliance manually, press the power on/off button.

Before first use

- Remove all packing material.
- Open the drawer by pulling the handle (Fig. 3).
- Remove the basket by lifting the handle (1). To remove the pan, tilt it backward and lift it off the tracks (2) (Fig. 4).
- Thoroughly clean the basket and pan with hot soapy water and a non-abrasive sponge.

Note: You can also clean these parts in the dishwasher.

- Wipe the inside and outside of the appliance with a moist cloth.
- Place the pan in the drawer (1) and put the basket in the pan (2) (Fig. 5).
- Slide the drawer back into the airfryer by the handle.

Note: The appliance may produce some smoke when you use it for the first time. This is normal.

Preparing for use

- Place the appliance on a stable, horizontal and level surface. Make sure the drawer can be opened completely.

Do not place the appliance on non-heat-resistant surface.

- Pull the power cord out of the cord storage compartment at the back of the appliance.

This airfryer works on hot air. Do not fill the pan with oil, frying fat or any other liquid.

Do not put anything on top of the appliance or block air vents. This disrupts the airflow and affects the hot air frying result.

Using the appliance

Refer to Recipe Book for recipes, cooking temperatures and times and tips.

<div>III</div>	Do not touch hot surfaces. Use handles or knobs. This product is for household use only.
--	--

Preheating

- Put the plug in a grounded wall outlet.
- Press the power on/off button to switch on the appliance (Fig. 6)
 - The display shows the last selected temperature.
- Set the preheating temperature by pressing the increase or decrease buttons (Fig. 7).

Tip: Press and hold the increase or decrease button longer to move the temperature forward or backward faster.

- Press the START/PAUSE button (Fig. 8)
 - The appliance starts preheating to the set temperature.

Note: If you do not want to preheat, but want to start frying immediately, skip steps 3, 4 and 5 and follow the instructions in section ‘Hot air frying’ in this chapter.

- The set temperature flashes until the set temperature has been reached. Then the appliance beeps and the set temperature is displayed continuously. The appliance stops beeping if you set the required cooking time (see step 6 in section ‘Hot air frying’).

Note: You can also start the preheating process manually by setting the temperature and then pressing the timer decrease button until ‘-’ appears (Fig. 9).

Hot air frying

- Put the power plug in a grounded wall outlet.
- Open the drawer by pulling the handle (Fig. 3).
- Put the ingredients in the basket (Fig. 10).

Note: Never fill the basket beyond the MAX indication. This has a negative effect on the end result.

4. Slide the drawer back into the airfryer by the handle (Fig. 11). Never use pan without basket in place. If by accident you heat up the appliance without basket, use oven-safe gloves to open the drawer. The edges and inside of the drawer become very hot.

Caution: Do not touch pan or basket during and directly after use as they get very hot! Only hold pan by basket handle.

- Press the temperature increase or decrease button to set the required cooking temperature.
- Set the required cooking time by pressing the increase or decrease buttons (Fig. 12).

Note: You can change the time or the temperature anytime during the process.

Note: If you have not preheated the appliance, add 3 minutes to the cooking time.

Note: If you do not set the required cooking time within 5 minutes, the appliance automatically shuts off for safety reasons.

- Press the START/PAUSE button to start the cooking proces (Fig. 13).
 - The display starts counting down the set cooking time.
 - Excess oil or rendered fat from the ingredients is collected on the bottom of the pan.

- Some ingredients require shaking midway through the cooking process. To shake ingredients, open the drawer by pulling the handle (Fig. 3). Remove the basket by lifting the handle (1) (Fig. 4), then shake it. Replace the basket into the pan and slide drawer back into airfryer.

Note: Depending on type of ingredients cooking, you may want to carefully pour off any excess oil or rendered fat from pan before replacing basket into pan. Place basket on a heat-resistant surface. To remove the pan, use oven-safe gloves to hold the pan or touch the drawer as they are very hot. Tilt pan backward and lift it off the tracks (2) (Fig. 4).

9. When the appliance starts beeping, the set cooking time has elapsed.

Note: You can also stop the cooking process manually. To do this, press the START/PAUSE button (Fig. 8).

- Open the drawer by pulling the handle and check if the ingredients are ready (Fig. 14).
 - If the ingredients are not ready yet, simply slide the drawer back into the airfryer by the handle and add a few extra minutes to the set time.
- To remove small ingredients (e.g. fries), lift the basket out of the pan by the handle (Fig. 15).

After the cooking process the pan, basket, and ingredients are hot. Depending on the type of ingredients in the airfryer, steam may escape from the pan.

Always remove basket with ingredients from pan to serve, as hot oil or rendered fat may be in bottom of pan. Be careful, steam may escape from pan.

- Empty the basket into a bowl or onto a plate (Fig. 16).

Tip: To remove large or fragile ingredients, use a pair of tongs to lift the ingredients out of the basket (Fig. 17).

- When a batch of ingredients is ready, the airfryer is instantly ready for preparing another batch.

Note: Repeat steps 1 to 9 if you want to prepare another batch.

Note: If you prepare another batch within 30 minutes, it is not necessary to preheat the appliance again.

- Press the power on/off button to switch off the airfryer.

Preset button

You can program the appliance to prepare your favorite ingredients at a specific temperature for a specific length of time.

Note: The appliance can only retain one temperature and one cooking time.

To set your favorite settings:

- Press the power on/off button to switch on the appliance (Fig. 6).
- Press the preset button (star symbol) (Fig.18). The display shows the current saved settings.
- Press the temperature increase or decrease button to set the desired temperature (Fig. 7).
- Press the timer increase or decrease button to set the desired time (Fig. 12).
- Press the preset button (star symbol) (Fig. 18).

You hear a beep and the star symbol lights up continuously to indicate that the settings have been saved.

From now on, the appliance retains your favorite settings. Just press the preset button to recall the saved settings. Press the START/PAUSE button to start the program.

Note: If you want to change the saved settings, simply perform steps 1 to 5 again.

Cleaning

Clean appliance after every use. Remove oil from bottom of pan after every use to prevent smoke.

Let basket, pan, and inside of appliance cool completely before you start cleaning.

Pan and basket have a non-stick coating. Do not use metal kitchen utensils or abrasive cleaning materials as this may damage non-stick coating.

Be careful when cleaning the upper area of the cooking chamber: Hot heating element, edge of Metal parts.

- Unplug the appliance and let it cool down.
- Wipe the outside of the appliance with a moist cloth.

Note: Open the drawer to let the appliance cool down more quickly.

Note: Make sure no moisture remains behind on the control panel. Dry the control panel with a cloth after you have cleaned it.

- Thoroughly clean basket and pan with hot, soapy water and non-abrasive sponge or in dishwasher.

Tip: If residue sticks to basket or bottom of pan, fill pan with hot soapy water. Put basket in pan and let soak for at least 10 minutes.

- Clean inside of appliance with hot water and non-abrasive sponge.
- If necessary, clean heater with a cleaning brush to remove any food residue.

This appliance has no other user-serviceable parts. For assistance in the U.S. or Canada only call 1-866-309-8817.

Storage

- Unplug appliance and let it cool down.
- Be sure all parts are clean and dry.
- Push power cord into cord storage compartment.

Disposal

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. For recycling information, please contact your local waste management facilities or visit www.recycle.philips.com

Warranty and service

If you need information, support, or if you have a problem, please visit www.philips.com/support or in the U.S. or Canada only, call 1-866-309-8817 for assistance.

Troubleshooting

This chapter summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, visit www.philips.com/support or in the U.S. or Canada only, call 1-866-309-8817 for assistance.

Problem	Possible cause	Solution
The appliance does not work.	The appliance is not plugged in.	Put the plug in a grounded wall outlet.
	You have not pressed the on/off button.	Press the on/off button to switch on the appliance.
The ingredients fried with the airfryer are not done.	The amount of ingredients in the basket is too big.	Put smaller batches of ingredients in the basket. Smaller batches are fried more evenly. Do not exceed MAX indication.
	The set temperature is too low.	Set the temperature to the required temperature setting.
	The cooking time is too short.	Set the timer to the required cooking time.
The ingredients are fried unevenly in the airfryer.	Certain types of ingredients need to be shaken halfway through the cooking time.	Ingredients that lie on top of or across each other (e.g. fries) need to be shaken halfway through the cooking time.
Fried foods are not crispy when they come out of the airfryer.	You used a type of food to be prepared in a traditional deep fryer.	Use food intended to be cooked in an oven or lightly brush some oil onto the food for a crispier result.
I cannot slide the pan into the appliance properly.	There are too many ingredients in the basket.	Do not fill the basket beyond the MAX indication.
	The basket is not placed in the pan correctly.	Make sure the pan and basket are placed correctly.
White smoke comes out of the appliance.	You are preparing fatty ingredients.	When you fry greasy ingredients, a large amount of oil or rendered fat leaks into the pan. The oil or fat causes white smoke and the pan may heat up more than usual. This does not affect the appliance or the end result. Midway through the cooking process you can carefully pour off any excess oil or rendered fat from the pan wearing oven-safe gloves then continue cooking.

	The pan still contains greasy residue from previous use.	White smoke is caused by greasy residue heating up in the pan. Make sure you clean the pan properly after each use.
--	--	---

	Marinade, liquid or meat juices are splattering in the rendered fat or grease	Pat food dry before placing it in the basket. Occasionally pour off rendered fat or grease from the pan during cooking.
--	---	---

	Breading or coating did not adhere properly to the food.	White smoke can be caused by tiny pieces of airborne breading. Press breading or coating to food to ensure it sticks.
--	--	---

	Home-made fries are fried unevenly in the airfryer.	Soak the potato sticks in a bowl for at least 30 minutes, take them out and dry them with paper towel.
--	---	--

	You did not use the right potato type.	Use fresh potatoes and be sure they stay firm during frying.
--	--	--

	Home-made fries are not crispy when they come out of the airfryer.	The crispiness of the fries depends on the amount of oil and water in the fries. <ul style="list-style-type: none">Be sure you dry the potato sticks properly before you add the oil. Cut the potato sticks smaller for a crispier result. Add slightly more oil for a crispier result.
--	--	---

	The message ‘E’ appears on the display.	In the U.S. or Canada only, call 1-866-309-8817 for assistance.
--	---	---

	The time and temperature indications change automatically, even though I do not press any buttons.	Make sure you dry the control panel with a cloth after you have cleaned it.
--	--	---

One Year Limited Warranty

Philips warrants that this product shall be free from defects in material, workmanship and assembly, under normal use, in accordance with the specifications and warnings, for a period of one year from the date of purchase. This warranty extends only to the original purchaser of the product, and is not transferable. To exercise your rights under this warranty, you must provide proof of purchase in the form of an original sales receipt that shows the product name and the date of purchase. For customer support or to obtain warranty service, please visit our website www.philips.com/support. THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES. Philips’ liability is limited to repair or, at its sole option, replacement of the product. Incidental, special and consequential damages are disclaimed where permitted by law. This warranty gives you specific legal rights. You may also have other rights that vary from state to state, province to province or country to country. In U.S. only Manufactured for: Philips Personal Health A division of Philips North America LLC P.O. Box 10313, Stamford, CT 06904, United States of America Canada only Manufactured for: Philips Electronics Ltd. 281 Hillmount Road Markham, ON L6C 2S3

	CONFORMS ANSI/UL STD 1026 CERTIFIED TO CAN/CSA C22.2 NO.60335-1
--	---

Intertek PHILIPS and Philips Shield are Registered Trademarks of Koninklijke Philips NV

©2018 Philips North America LLC. All Rights Reserved.

ESPAÑOL

PRECAUCIONES IMPORTANTES

Si utiliza un aparato eléctrico siempre debe tomar medidas de seguridad básicas, tales como:

- Lea todas las instrucciones.
- No toque las superficies calientes. Utilice las asas o los pomos (Fig. 2).
- No suermeje el cable de alimentación, los conectores ni el aparato en agua u otros líquidos para evitar descargas eléctricas.
- Se requiere una estricta supervisión cuando algún niño o persona discapacitada utilice los aparatos, o cuando se utilicen cerca de ellos. Una persona responsable debe supervisar a niños para evitar que jueguen con este aparato.
- Desconecte el aparato del tomacorriente cuando no lo utilice y antes de limpiarlo. Deje que se enfríe antes de añadir o retirar piezas.
- Nunca use ningún aparato si el cable de alimentación o el conector están dañados, si funciona mal o si sufrió algún tipo de daño.
- Evite el uso de accesorios no recomendados por el fabricante del aparato para prevenir lesiones.
- No obstruya ningún orificio de ventilación. Para instalar, siga las instrucciones de fábrica.
- No utilice el dispositivo al aire libre.
- No deje que el cable cuelgue del borde de la superficie sobre la que se encuentra apoyado ni permita que toque superficies calientes.
- No coloque este tipo de aparatos sobre quemadores eléctricos o que funcionen cerca de gas caliente. Tampoco lo coloque dentro de hornos calientes.
- Tome las medidas de precaución necesarias cuando mueva un artefacto que contenga aceite caliente u otros líquidos calientes.
- Enchufe el conector al tomacorriente de pared. Para desconectarlo, lleve los controles a la posición de apagado y desconecte el tomacorriente.
- Utilice el aparato solo para el uso previsto.
- Tenga mucho cuidado al retirar la sartén, la cesta y al eliminar la grasa caliente.
- No limpie con esponjas metálicas. Pueden saltar pedazos de la esponja y tocar partes eléctricas, lo que genera un riesgo de electrocución.
- Solo utilice este artefacto en un tomacorriente con una apropiada conexión a tierra.
- Se debe usar un cable de alimentación corto (o un cable de alimentación desmontable) para reducir el riesgo de enredarse o tropezarse con un cable largo.
- Se pueden utilizar cables de extensión si se toman las precauciones debidas. Si se utiliza un cable de extensión: La clasificación eléctrica del cable debe ser igual a la clasificación del artefacto. El cable debe instalarse de tal manera que no cuelgue del borde de la superficie de apoyo, para así evitar caídas y enredos.

- Este aparato posee toma de tierra, el cable de alimentación deberá constar de 3 cables de los cuales uno debe ser de tierra.
- Este aparato cuenta con un conector polarizado (una hoga es más ancha que la otra). Para reducir el riesgo de descarga eléctrica, este conector está diseñado para ajustarse a una salida polarizada de un solo modo. Si el conector no se ajusta por completo a la salida, invierta el conector. Si sigue sin encajar, póngase en contacto con un electricista calificado. No intente modificar el conector de ningún mod.
- No deben colocarse alimentos de gran tamaño ni utensilios de cocina metálicos en el aparato, ya que pueden generar un incendio o una descarga eléctrica.
- Puede ocurrir un incendio si el artefacto está cubierto o en contacto con material inflamable, esto incluye cortinas, tapicería, paredes o similares, durante su funcionamiento. No almacene objetos sobre el aparato durante su funcionamiento.
- No introduzca ninguno de los siguientes materiales en el aparato: papel, cartón, plástico o similares.
- Desenchufe el aparato inmediatamente si observa que sale humo oscuro del aparato. Espere que se detenga la emisión de humo antes de retirar la sartén del aparato
- Utilice el aparato sobre una superficie horizontal, plana y estable lejos de cualquier fuente de agua o calor.
- No deje el aparato sin supervisión mientras está en funcionamiento.
- Este aparato funciona a altas temperaturas que pueden provocar quemaduras. No toque las superficies y las piezas calientes, ni el interior del aparato mientras está en funcionamiento (Fig. 2). Deje que el aparato se enfríe antes de manipularlo o limpiarlo.
- Mientras el aparato frie con aire caliente, sale vapor caliente por las aberturas de salida de aire. Mantenga las manos y la cara a una distancia segura del vapor y de las aberturas de salida de aire.
- Evite el contacto entre partes móviles.
- Este aparato funciona con aire caliente; la comida no se frie en aceite o grasa. Nunca llene la sartén con aceite o grasa.
- Este producto es solo para uso doméstico.
- Nunca utilice la airfryer sin la sartén ni la cesta en su lugar.
- Antes de cada uso del dispositivo, asegúrese de que el calentador y los alrededores del mismo estén limpios y sin restos de alimentos para garantizar una función impecable.
- Nunca utilice ingredientes ligeros ni papel para hornear en el artefacto.
- Nunca toque el interior del aparato mientras está en funcionamiento.
- No coloque el aparato sobre materiales inflamables ni cerca de ellos (p. ej. manteles o cortinas).
- Nunca deje el artefacto en funcionamiento sin vigilancia.
- Desconecte inmediatamente el artefacto si ve que se desprende humo negro de él. Espere a que se detenga la emisión de humo antes de retirar el sartén del artefacto.

CONSERVE ESTAS INSTRUCCIONES

El consumo de carnes, aves, pescados y mariscos o huevos crudos o sin cocinar puede incrementar el riesgo de contraer enfermedades transmitidas por los alimentos.

Asegúrese de que los ingredientes preparados en este aparato tienen un color dorado o amarillo en lugar de color marrón oscuro. Retire los restos de alimentos. Para obtener los mejores resultados, no freír las patatas frescas a temperatura por encima de 360°F/ 180°C o más allá de color amarillo dorado.

Introducción

Felicitaciones por su compra y bienvenido a Philips. Para disfrutar de todos los beneficios que le ofrece la asistencia de Philips registre su producto en www.philips.com/welcome. La nueva airfryer le permite preparar sus ingredientes y aperitivos favoritos de una manera más sana.

La airfryer utiliza aire caliente combinado con circulación de aire a alta velocidad (Rapid Air) y una Parrilla superior para preparar una variedad de platos sabrosos de una manera rápida, sana y fácil. Los ingredientes se calientan por todos los lados de una sola vez y no hay necesidad de añadir aceite a la mayoría de los ingredientes. Para inspirarse más, consulte recetas e información sobre la airfryer, visite www.philips.com/kitchen.

Información general (Fig. 1)

- Cesta
- Indicación de MÁX.
- Asa de la cesta
- Sartén
- Panel de control

A - Botón de encendido/apagado

B - Botón INICIO/PAUSA

C - Botón de preselección

D - Botones de aumento y reducción de temperatura

E - Indicación de tiempo/temperatura

F - Botones de aumento y reducción del temporizador
- Gaveta
- Aberturas de salida de aire caliente
- Entrada de aire

Apagado automático

Este aparato cuenta con un sistema de apagado automático. Si no presiona unbotón en el transcurso de 30 minutos, el aparato se apaga automáticamente. Para apagar el aparato manualmente, presione el botón de encendido/apagado.

Antes del primer uso

- Quite todo el material de embalaje.
- Para abrir la gaveta tire del asa (Fig. 3).
- Para retirar la cesta levante el asa (1). Para retirar la sartén, inclínela hacia atrás y levántela de los carriles (2) (Fig. 4).
- Limpie a fondo la cesta y la sartén con agua caliente con detergente y una esponja no abrasiva.

Note: También puede lavar estas piezas en el lavavajillas.

- Limpie el interior y exterior del aparato con un paño húmedo.
- Coloque la sartén en la gaveta (1) y coloque la cesta en la sartén (2) (Fig. 5).
- Vuelva a colocar la gaveta en la airfryer tomándola por el asa.

Note: El aparato puede generar un poco de humo cuando se usa por primera vez. Es normal.

Preparación inicial

- Coloque el aparato sobre una superficie estable, horizontal y plana. Asegúrese de que la gaveta pueda abrirse por completo.

No coloque el aparato sobre superficies no resistentes al calor.
--

- Saque el cable de alimentación del compartimento para guardar el cable situado en la parte trasera del aparato. Esta airfryer funciona con aire caliente. No llene la sartén con aceite, grasa para freír ni ningún otro tipo de líquido.
- No coloque nada encima del aparato ni bloquee las rejillas de ventilación. Esto interrumpe el flujo de aire y afecta al resultado de los alimentos fritos con aire caliente.

Uso del aparato

Revise el libro de recetas para consultar recetas, consejos, las temperaturas y los tiempos de cocción.

<div>III</div>	No toque las superficies calientes. Utilice las asas o los pomos (Fig. 2).
--	--

||
||
||