

HD3013

EN Safety leaflet
PE Folleto de seguridad

PHILIPS



Specifications are subject to change without notice.
© 2013 Koninklijke Philips Electronics N.V.
All rights reserved.

HD3013_Safety_PERU_V1.0



English

Read this important information leaflet carefully before you use the rice cooker and save it for future reference.

Danger

- Do not immerse the rice cooker in water, nor rinse it under the tap.

Warning

- Check if the voltage indicated on the rice cooker corresponds to the local power voltage before you connect it.

- Only connect the rice cooker to a grounded power outlet. Always make sure that the plug is inserted firmly into the power outlet.
- Do not use the appliance if the plug, the power cord, the inner pot, the sealing ring, or the main body is damaged.
- Make sure that the damaged power cord is replaced by Philips, a service center authorized by Philips or similarly qualified persons in order to avoid a hazard.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to make sure that they do not play with the rice cooker.
- Keep the power cord out of the reach of children. Do not let the power cord hang over the edge of the table or worktop on which the rice cooker stands.
- Make sure the heating element, the temperature sensor, and the outside of the inner pot are clean and dry before you put the plug in the power outlet.
- Do not plug in the rice cooker or press the control lever with wet hands.

Caution

- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not expose the rice cooker to high temperatures, nor place it on a working or still hot stove or cooker.
- Do not expose the rice cooker to direct sunlight.
- Place the rice cooker on a stable, horizontal, and level surface.
- Always put the inner pot in the rice cooker before you put the plug in the power outlet and switch it on.
- Do not place the inner pot directly over an open fire to cook rice.
- Do not use the inner pot if it is deformed.
- The accessible surfaces may become hot when the rice cooker is operating. Be careful when touching it.
- Beware of hot steam coming out of the steam vent during cooking or out of the rice cooker when you open the lid. Keep hands and face away from the rice cooker to avoid the steam.
- The inner pot, steam basket, and resealable cups, during and after cooking process, may be hot and heavy.
- Do not lift and move the rice cooker while it is operating.
- Do not exceed the maximum water level indicated in the inner pot to prevent overflow.
- Do not place the cooking utensils inside the pot while cooking, keeping warm or reheating rice.
- Only use the cooking utensils provided. Avoid using sharp utensils.
- To avoid scratches, it is not recommended to cook ingredients with crustaceans and shellfish. Remove the hard shells before cooking.
- Do not insert metallic objects or alien substances into the steam vent.
- Do not place a magnetic substance on the lid. Do not use the rice cooker near a magnetic substance.
- Always let the rice cooker cool down before you clean or move it.
- Always clean the rice cooker after use. Do not clean the rice cooker in dishwasher.
- Always unplug the rice cooker if not used for a longer period.
- The rice cooker is intended to be used in household or similar applications such as: Staff kitchen areas in shops, offices, and other residential type environments; Farm houses; By clients in hotels, motels and other residential type environments; Bed and breakfast type environments.
- If the rice cooker is used improperly or for professional or semi-professional purposes, or if it is not used according to the instructions in this user manual, the guarantee becomes invalid and Philips refuses liability for any damage caused.

Electromagnetic fields (EMF)

This appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

Español

Antes de usar la arrocera, lea atentamente este folleto de seguridad y consérvelo por si necesita consultarla en el futuro.

Peligro

- No sumerja la arrocera en agua ni la enjuague bajo la canilla.

Advertencia

- Antes de enchufar la base, compruebe si el voltaje indicado en la arrocera se corresponde con el voltaje de red local.
- Conecte la arrocera solo a una toma de alimentación a tierra. Asegúrese siempre que el enchufe esté firmemente conectado a la toma de alimentación.
- No utilice el aparato si el enchufe, cable, recipiente interno, anillo sellador o el aparato principal presentan daños.
- Asegúrese de que el cable de alimentación sea reemplazado por Philips, un centro de servicios autorizado por Philips o personas igualmente calificadas para evitar situaciones de peligro.
- No se debe utilizar el aparato con un temporizador externo o un sistema separado de control remoto.
- El aparato no debe ser utilizado por personas con capacidad física, mental o sensorial reducida (adultos o niños), ni por personas que carezcan

del conocimiento y la experiencia necesarios, salvo que una persona responsable de su seguridad los supervise o les brinde instrucciones acerca del uso del aparato.

- Se debe supervisar a los niños para asegurarse de que no jueguen con este aparato.
- Mantenga el cable de alimentación fuera del alcance de los niños. No deje que el cable de alimentación cuelgue de la mesa o la encimera donde está puesta la arrocera.
- Asegúrese de que el calentador, el sensor de temperatura y la parte externa del recipiente interno estén limpios y secos antes de enchufar el aparato en la toma de alimentación.
- No enchufe la arrocera ni accione la palanca de control con las manos mojadas.

Precaución

- No utilice nunca accesorios ni piezas que Philips no recomienda específicamente o de otros fabricantes. Si utiliza otras piezas o accesorios, quedará anulada su garantía.
- No exponga la arrocera a altas temperaturas ni la coloque sobre una cocina con fuego encendido o aún caliente.
- No exponga esta arrocera a la luz directa del sol.
- Coloque la arrocera sobre una superficie estable, horizontal y plana.
- Coloque siempre el recipiente interno en la arrocera antes de enchufarla a la toma de alimentación y encenderla.
- No coloque el recipiente interior directamente sobre el fuego para cocinar el arroz.
- No utilice el recipiente interno si este está deformé.
- Las superficies accesibles pueden calentarse cuando la arrocera está en funcionamiento. Tenga cuidado al tocar y manipular la arrocera.
- Tenga cuidado del vapor caliente que emana de la ventilación de vapor mientras cocina, o que sale de la arrocera al abrir la tapa. Mantenga las manos y cara lejos de la arrocera para evitar el vapor.
- Durante y después de cocinar, el recipiente interno, cestilla de vapor y los vasos con cierre pueden estar calientes y pesados.
- No mueva ni levante la arrocera mientras se encuentra en funcionamiento.
- No sobrepase el nivel máximo de agua en el recipiente interno para prevenir desbordes.
- No ponga utensilios de cocina dentro del recipiente mientras cocina, mantiene caliente o recalienta el arroz.
- Solo utilice los utensilios de cocina suministrados. Evite utilizar utensilios punzagudos.
- Para evitar rayas, se recomienda no cocinar ingredientes con crustáceos o mariscos. Retire las conchas duras antes de cocinar.
- No inserte objetos metálicos o sustancias extrañas en la ventilación de vapor.
- No ponga sustancias magnéticas en la tapa. No utilice la arrocera cerca de una sustancia magnética.
- Siempre permita que la arrocera se enfríe antes de limpiarla o moverla.
- Siempre limpie la arrocera después de utilizarla. No limpie la arrocera en el lavavajillas.
- Siempre desconecte la arrocera si no la utiliza por un largo período.
- Esta arrocera está diseñada para ser utilizadas en un hogar o en aplicaciones similares tales como: cocina para el personal en una tienda, oficinas y otros ambientes de tipo residencial, granjas, por clientes en hoteles, moteles y otros ambientes de tipo residencial y ambientes de pensión con desayuno.
- Si se le da un uso indebido, se utiliza con fines profesionales o semiprofesionales, o bien, si no se utiliza de acuerdo a las instrucciones contenidas en este manual de usuario, la garantía de la arrocera será inválida y Phillips quedará libre de responsabilidad por cualquier daño causado.

Campos electromagnéticos (CEM)

Este artefacto cumple con todos los estándares de campos electromagnéticos (CEM). Si se utiliza correctamente y de acuerdo con las instrucciones de este manual, puede usarse de forma segura de conformidad con los fundamentos científicos disponibles en la actualidad.