



English

Read this important information leaflet carefully before you use the appliance and save it for future reference.

Danger

- The appliance must not be immersed.

Warning

- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- **WARNING:** If the surface of the cooking plate is cracked, switch off the appliance and do not use it anymore to avoid the possibility of electric shock.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Metallic objects such as knives, forks, spoons and lids should not be placed on the induction cooker since they can get hot.
- The temperature of accessible surfaces may be high when the appliance operates.
- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Only connect the appliance to an earthed wall socket. Always make sure the plug is inserted firmly into the socket.
- Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- Keep the mains cord out of the reach of children. Do not let the mains cord hang over the edge of the table or worktop on which the appliance stands.
- Never connect this appliance to an external timer switch in order to avoid a hazardous situation.

- Make sure the cooking plate is clean and dry before you switch on the appliance.
- Do not cover the air outlets while the induction cooker is operating.
- Do not plug in the appliance or operate the control panel with wet hands.
- Don't clean the appliance while hot.
- Use a soft damp cloth to clean the surfaces in contact with water.
- Do not touch the cooking plate after cooking, as it retains heat from the cookware.
- Do not insert external objects such as iron wires and bolts into the appliance.
- Do not cover any part of the cooking plate with aluminium to prevent the risk of electric shock, short circuiting or fire.
- If the surface of the cooking plate is cracked, switch off the appliance and do not use it anymore to prevent the risk of electric shock, short circuiting or fire.
- The maximum weight that can be put on the induction cooker is 15kg.
- Beware of hot steam that comes out of the cookware during cooking or when you remove the lid.
- Do not lift and move the induction cooker while it is operating.
- Never put empty cookware on the switched-on induction cooker, as this could cause the cookware to become distorted or the heating coil to become damaged.
- Do not store flammable materials and liquids near or on the induction cooker.
- Avoid hard contact between the cookware or other objects and the crystalite cooking plate.
- Always place the cookware on the cooking zone during cooking.

Caution

- The symbol marked on the appliance means "Caution, Hot surfaces", do not touch the hot surface in order to avoid scald.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not expose the induction cooker to high temperatures, hot gas, steam or damp heat. Do not place the induction cooker on or near an operating or still hot stove or cooker.
- Always switch off the appliance before you unplug it.
- Always unplug the appliance and let it cool down before you clean it.
- This appliance is intended for household use only. If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and Philips refuses any liability for damage caused.
- Place the induction cooker on a stable, horizontal and level surface and make sure there is at least 10cm free space around it to prevent overheating.
- Do not use the induction cooker on a gas cooker or metal plate.
- For better ventilation, do not block the air inlet and outlets while the appliance is operating, e.g. do not operate the appliance on a plastic tablecloth.
- Do not place anything between the cookware and the cooking plate.



Automatic shut-off

The appliance is equipped with automatic shut-off. It switches off automatically in the following situations:

- If cookware with a bottom diameter less than 6cm, or small objects like knives, forks, or spoons are placed on the plate during cooking.
- If the voltage is lower than 120V or higher than 280V.
- If no cookware is put on the cooking zone when the induction cooker is working for 1 minute.
- If the induction cooker has been idle for 2 hours.
- If the temperature of the central plate is higher than 300°C, or if the internal temperature of the induction cooker is too high.

Electromagnetic fields (EMF)

This appliance complies with the applicable standards and regulations regarding exposure to electromagnetic fields.

Bahasa Melayu

Baca risalah keselamatan ini dengan teliti sebelum anda menggunakan perkakas dan simpan ia untuk rujukan masa depan.

Bahaya

- Perkakas tidak boleh direndam.

Amaran

- Perkakas ini dimaksudkan untuk digunakan di dalam rumah dan untuk penggunaan lain yang serupa seperti:
 - dapur pekerja di kedai, pejabat dan persekitaran kerja yang lain;
 - rumah ladang;
 - oleh pelanggan di hotel, motel dan persekitaran penginapan lain;
 - persekitaran jenis inap-sarapan.
- Perkakas ini tidak dimaksudkan untuk digunakan oleh orang (termasuk kanak-kanak) yang kurang upaya dari segi fizikal, deria atau mental, atau kurang berpengalaman dan pengetahuan, kecuali mereka telah diberi pengawasan atau arahan berkenaan penggunaan perkakas ini oleh orang yang bertanggungjawab atas keselamatan mereka.
- Kanak-kanak hendaklah diawasi untuk memastikan bahawa mereka tidak bermain dengan perkakas ini.
- AMARAN: Jika permukaan plat memasak retak, matikan perkakas dan jangan gunakannya lagi untuk mencegah risiko kejutan elektrik.
- Perkakas ini tidak dimaksudkan untuk dikendalikan menggunakan pemasa luaran atau sistem kawalan jauh yang berasingan.
- Jika kord sesalur rosak, kord mesti digantikan oleh pengeluar, ejen servis atau pihak yang mempunyai kelayakan yang sama bagi mengelakkan bahaya.
- Objek logam seperti pisau, garpu, sudu dan penutup tidak harus diletakkan di atas periuk aruhan kerana boleh menjadi panas.
- Suhu permukaan yang boleh diakses mungkin tinggi semasa perkakas beroperasi.
- Pastikan bahawa voltan yang dinyatakan pada perkakas sepadan dengan voltan sesalur tempatan anda.
- Sambungkan perkakas hanya kepada soket dinding yang dibumikan. Sentiasa pastikan plag dimasukkan dengan kukuh ke dalam soket.
- Jangan gunakan perkakas jika plag, kord sesalur atau perkakas itu sendiri rosak.
- Jauhkan kord kuasa daripada capaian kanak-kanak. Jangan biarkan kord sesalur utama

tergantung di tepi meja atau permukaan ruang kerja di mana perkakas itu diletakkan.

- Jaminan dan perkhidmatan
- Pastikan plat memasak bersih dan kering sebelum anda menghidupkan perkakas .
- Jangan tutup saluran keluar udara semasa periuk aruhan sedang beroperasi.
- Jangan pasang plag perkakas atau mengendalikan panel kawalan dengan tangan yang basah.
- Jangan sentuh plat memasak selepas memasak, kerana ia mengekalkan haba daripada alat memasak.
- Jangan masukkan objek luaran seperti wayar besi dan bolt ke dalam perkakas.
- Jangan tutup mana-mana bahagian plat memasak dengan aluminium untuk mencegah risiko kejutan elektrik, litar pintas atau kebakaran.
- Jika permukaan plat memasak retak, matikan perkakas dan jangan gunakannya lagi untuk mencegah risiko kejutan elektrik, litar pintas atau kebakaran.

Awas

- Simbol yang ditandakan pada perkakas bermaksud "Awas, Permukaan panas", jangan sentuh permukaan panas untuk mengelakkan kelecuman.
- Jangan sekali-kali gunakan sebarang perkakas atau bahagian dari mana-mana pengilang atau yang tidak disyorkan secara khusus oleh Philips. Jika anda menggunakan aksesori atau bahagian yang sedemikian, jaminan anda menjadi tidak sah.
- Jangan dedahkan periuk aruhan kepada suhu yang tinggi, gas panas, stim atau haba lembap. Jangan letakkan periuk aruhan di atas atau dekat dengan dapur atau pemasak yang sedang beroperasi atau masih panas.
- Sentiasa matikan perkakas sebelum anda mencabut plagnya.
- Sentiasa cabut plag perkakas dan biarkan sehingga sejuk sebelum anda membersihkannya.
- Perkakas ini dimaksudkan untuk penggunaan rumah tangga sahaja. Jika perkakas digunakan dengan cara yang tidak betul, atau untuk tujuan profesional atau separa profesional, atau jika ia tidak digunakan mengikut arahan dalam panduan pengguna ini, jaminan menjadi tidak sah dan Philips menolak sebarang liabiliti terhadap sebarang kerosakan yang berlaku.
- Letakkan periuk aruhan di atas permukaan yang stabil, mendatar dan rata serta pastikan terdapat sekurang-kurangnya 10cm ruang kosong di sekelilingnya untuk mengelakkan daripada pemanasan melampau.



- Jangan gunakan periuk aruhan di atas pemasak gas atau plat logam.
- Bagi pengudaraan yang baik, jangan sekat saluran udara keluar dan masuk semasa perkakas sedang beroperasi, cth. jangan gunakan perkakas di atas alas meja plastik.
- Jangan letak apa-apa di antara alat memasak dan plat memasak.
- Berat maksimum yang boleh diletakkan di atas periuk aruhan ialah 15kg.
- Berhati-hati dengan stim panas yang keluar dari alat memasak semasa memasak atau apabila anda membuka penutupnya.
- Jangan angkat atau pindahkan periuk aruhan semasa ia sedang beroperasi.
- Jangan letak alat memasak yang kosong di atas periuk aruhan yang telah dihidupkan, kerana ini boleh menyebabkan alat memasak tersebut menjadi terherot dan gegelung pemanasan menjadi rosak.
- Jangan simpan bahan dan cecair mudah terbakar berhampiran atau di atas periuk aruhan.
- Elakkan sentuhan yang kuat antara alat memasak atau objek lain dengan plat memasak kristalit.
- Sentiasa letakkan alat memasak pada zon memasak apabila memasak.

Pemhatian automatik

Perkakas dilengkapi dengan pemhatian automatik. Ia akan mati secara automatik dalam keadaan berikut:

- Jika alat memasak dengan garis pusat bawah kurang dari 6cm, atau objek lebih kecil seperti pisau, garpu atau sudu diletakkan di atas plat semasa memasak.
- Jika voltan lebih rendah daripada 120V atau lebih tinggi daripada 280V.
- Jika periuk aruhan telah pun melahut selama 2 jam.
- Jika tiada alat memasak diletakkan di atas plat memasak semasa periuk aruhan sedang beroperasi. Periuk aruhan akan berbunyi bip setiap 2 saat dan mati secara automatik selepas 1 minit.
- Jika suhu di pertengahan plat lebih tinggi daripada 300°C, atau suhu dalam periuk aruhan terlalu tinggi.

Medan elektromagnet (EMF)

Perkakas ini mematuhi piawaian dan peraturan berkaitan dengan pendedahan kepada medan elektromagnet.