

ENGLISH

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Important

Read this important information carefully before you use the appliance and save it for future reference.

Danger

Never immerse the appliance in water or any other liquid, nor rinse it under the tap.

Warning

Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.

Do not use the appliance if the plug, the mains cord or the appliance itself shows visible damage, or if the appliance has been dropped or leaks.

Do not connect the appliance to a direct current supply.

Always return the appliance to a service centre authorised by Philips for examination or repair. Do not attempt to repair the appliance yourself, otherwise the guarantee becomes invalid.

If the mains cord is damaged you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.

Never leave the appliance unattended when it is connected to the mains.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

When you have finished steaming, when you fill or empty the water tank, when you perform cleaning and rinsing and when you leave the appliance even for a short while, remove the mains plug from the wall socket.

Keep the appliance and its mains cord out of reach of children.

Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Only connect the appliance to an earthed wall socket.

Do not use the appliance when the water tank is empty.

This product has been designed and tested with essence oil. Do not mix perfume water, softener with essence oil or other substances as it may not achieve best result and may cause side effects like allergic reaction.

If you have asthma or any other pre-existing lung disease, avoid using scented oil in the steamer as it may cause breathing discomfort.

If you are allergic to scented oil, do not use scented oil in the steamer. If you are not sure, please do skin test before using. Apply a small amount, about a drop or less, to the skin on your inner arm. Do not use if redness or irritation occurs. Keep away from eyes and mucous membranes. If redness, burning, itching or irritation occurs, stop using product immediately. If irritation does occur then wash with soap and water to clean the affected area as it may cause skin irritation on skin.

Caution

Check the mains cord regularly for possible damage.

Beware of hot steam and hot water that comes out of the steamer during use. Steam and hot water can cause burns.

The nozzle of the steamer head can become extremely hot and may cause burns if touched.

This appliance is intended for household use only.

Never drag or pull the appliance across the floor.

Do not place the steamer base on top of table or chair but rather keep the steamer base on the floor during usage duration.

If the hose forms a U shape, steam condenses in the hose. This causes irregular steam or water droplets to come out of the steamer head.

Do not let the mains cord come into contact with hot steam when the appliance is in operation.

Steam may damage or cause discolouration of certain wall or door finishes.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.



Guarantee and support
If you need information or support, please visit www.philips.com/support or read the separate worldwide guarantee leaflet.

简体中文

简介

恭喜您购买了您的产品，欢迎您来到 Philips 大家庭！为了让您能充分享受飞利浦提供的支持，请在 www.philips.com/welcome 上注册您的产品。

重要信息

使用产品之前，请仔细阅读本重要信息，并妥善保管以供日后参考。

危险

不要将本产品浸入水或其它液体中，也不要在水龙头下冲洗。

警告

在将产品连接电源之前，请先检查产品所标电压与当地的供电电压是否相符。

如果插头、电源线或产品本身已经明显损坏，或产品曾坠落或出现渗漏，请勿再使用。

切勿将产品连接到直流电源。

本产品应送往由飞利浦授权的服务中心检查或修理。请不要尝试自己修理产品，否则产品维修保证书将会无效。

如果电源软线损坏，为了避免危险，必须由制造商、其维修部或类似部门的专业人员来更换。电源接通期间，使用者不得离开。

本产品适合由 8 岁或以上年龄的儿童以及肢体不健全、感觉或精神上有障碍或缺乏相关经验和知识的人士使用，但前提是有人对他们使用本产品进行监督或指导，以确保他们安全使用，并且让他们明白相关的危害。

当完成熨烫、为水箱加水或清空水箱、清洁和冲洗产品以及短时间离开产品时，请从电源插座上拔下电源插头。

将产品和电源线放在儿童接触不到的地方。

应照看好儿童，避免他们玩耍本产品。不要让儿童在无人监督的情况下进行清洁和保养。

产品只能使用带接地线的插座。

水箱为空时，请勿使用产品。

根据设计，本产品可以使用精油并已经过相应测试。不要将香水、软化剂与精油或其他物质混合使用，否则可能无法达到最佳效果并可能会造成过敏反应等副作用。

如果您患有哮喘或已有任何其他肺部疾病，请避免在蒸汽挂烫机中使用香油，否则可能造成呼吸困难。

如果您对香油过敏，请不要在蒸汽挂烫机中使用香油。如果您不确定，请在使用前先做皮肤测试。将少量（约一滴或更少）精油滴在手臂内侧的皮肤上。如果皮肤发红或过敏，请不要使用。远离眼睛和黏膜。如果出现发红、灼热、发痒或过敏现象，请立即停止使用产品。如果出现过敏现象，请用肥皂和水清洗以清洁患处，否则可能造成皮肤过敏。

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

警告

定期检查电源线是否损坏。

使用过程中，请注意从蒸汽挂烫机冒出的热蒸汽和热水。蒸汽和热水可能会导致烫伤。

蒸汽挂烫机蒸汽喷头的喷嘴会变得非常烫，如触摸喷嘴，则会导致烫伤。

本产品仅限于家用。

切勿在地板上拖拉本产品。

切勿将蒸汽挂烫机底座放置在桌面或椅子上，使用过程中，请将蒸汽挂烫机底座放在地板上。

如果蒸汽输送管处于 U 形状态，则蒸汽会在输送管内冷凝。从而导致蒸汽输出不连贯或蒸汽喷头中滴出水滴。

产品工作期间，切勿让电源线与高温蒸汽接触。

蒸汽可能损坏或导致某些墙体或门褪色。

电磁场 (EMF)

本飞利浦产品符合所有有关暴露于电磁场的适用标准和法规。

环境保护

本产品使用寿命结束时请勿与一般家庭废弃物一併丢弃。请将该产品放置于政府指定的回收站。此举能为环保尽一份心力。

주의사항

전원 코드에 손상 부위가 있는지 정기적으로 점검하십시오 . 다리미를 사용하는 동안 뜨거운 스팀이나 뜨거운 물이 샐 수 있으니 주의하십시오 . 스팀과 뜨거운 물은 화상을 입을 수 있습니다 .

스티머 헤드의 노즐은 매우 뜨거워질 수 있으므로 만질 경우 화상을 입을 수도 있습니다 .

본 제품은 가정용입니다 .

바닥에서 제품을 끌거나 당기지 마십시오 .

사용 시 스티머 헤드에서 스팀이 고르게 분사되지 않거나 물방울이 떨어질 수 있습니다 .

스팀기가 작동할 때 전원 코드가 뜨거운 스팀에 닿지 않게 하십시오 .

스팀으로 인해 특정 벽 또는 도어 마감이 손상되거나 변색될 수 있습니다 .

EMF(전자기장)

이 필립스 제품은 EMF(전자기장)와 관련된 모든 기준 및 규정을 준수합니다 .

환경

수명이 다 된 제품은 일반 가정용 쓰레기와 함께 버리지 말고 지정된 재활용품 수거 장소에 버리십시오 . 이런 방법으로 환경 보호에 동참하실 수 있습니다 .

보증 및 지원

보다 자세한 정보나 지원이 필요한 경우에는 필립스 웹사이트 (www.philips.com/support)를 방문하시거나 제품 보증서를 참조하십시오 .

한국어

소개

필립스 제품을 구입해 주셔서 감사합니다!

필립스가 드리는 지원 헬프를 받으실 수 있도록 www.philips.com/welcome에서 제품을 등록하십시오 .

중요

본 제품을 사용하기 전에 이 중요 정보를 주의 깊게 읽고 나중에 참조할 수 있도록 잘 보관하십시오 .

위험

제품을 물 또는 다른 액체에 절대 담그거나 행구지 마십시오 .

경고

제품에 전원을 연결하기 전에, 제품에 표시된 전압과 사용 지역의 전압이 일치하는지 확인하십시오 .

플러그 및 전원 코드, 제품 본체에 눈에 띄는 손상이 있거나 흙은, 제품을 떨어뜨렸거나 제품에서 물이 새면, 제품을 사용하지 마십시오 .

제품을 DC 전원에 연결하지 마십시오 .

검사 또는 수리가 필요한 경우에는 항상 필립스 서비스 지정점으로 문의하십시오 . 품질 보증이 무효화되므로, 제품을 직접 수리하지 마십시오 .

전원 코드가 손상된 경우, 안전을 위해 필립스 서비스 센터 또는 필립스 서비스 지정점에 의뢰하여 교체하십시오 .

제품이 전원에 연결된 상태에서는 자리를 절대 비우지 마십시오 .

8 세 이상의 아이들과 신체적, 정신적인 능력이 떨어지거나

경험과 지식이 풍부하지 않은 성인이 이 제품을 사용하려면 제품

사용과 관련하여 안전하게 사용할 수 있도록 지침을 숙지하고

관련 위험을 인식해야 합니다 .

본 제품은 8 세 이상 청소년, 체력이나 체질이 좋지 않은 사람,或是

경험과 지식이 풍부하지 않은 성인,或是

제품을 사용하는 경우에만 사용하십시오 .

필립스 서비스 센터 또는 필립스 서비스 지정점에 문의하십시오 .

제품이 전원에 연결된 상태에서는 자리를 절대 비우지 마십시오 .

제품이 전원에 연결된 상태에서는 자리를 절대 비우지 마십시오 .

제품을 전원에 연결하지 마십시오 .