

HD3011
HD3012
HD3015
HD3016
HD3017
HD3018
HD3021
HD3025
HD3027

EN	Safety leaflet
MS-MY	Risalah Keselamatan
TH	เอกสารที่ช่วยความปลอดภัย
VI	Tài liệu mōng thông tin an toàn
ZH-CN	安全说明

PHILIPS



Specifications are subject to change without notice
© 2013 Koninklijke Philips Electronics N.V.
All rights reserved.

HD3011_3012_3015_3016_3017_3018_3021_3025_3027_Safety ASEAN_V2.0

English

Read this safety leaflet carefully before you use the rice cooker and save it for future reference.

Danger

- Do not immerse the rice cooker in water, nor rinse it under the tap.

Warning

- Check if the voltage indicated on the rice cooker corresponds to the local power voltage before you connect it.
- Only connect the rice cooker to a grounded power outlet. Always make sure that the plug is inserted firmly into the power outlet.

- Do not use the appliance if the plug, the power cord, the inner pot, the sealing ring, or the main body is damaged.
- Make sure that the damaged power cord is replaced by Philips, a service center authorized by Philips or

- similarly qualified persons in order to avoid a hazard.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to make sure that they do not play with the rice cooker.
- Keep the power cord out of the reach of children. Do not let the power cord hang over the edge of the table or worktop on which the rice cooker stands.
- Make sure the heating element, the temperature sensor, and the outside of the inner pot are clean and dry before you put the plug in the power outlet.
- Do not plug in the rice cooker or press any of the buttons on the control panel with wet hands.
- Never connect this rice cooker to an external timer switch in order to avoid a hazardous situation.

Caution

- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not expose the rice cooker to high temperatures, nor place it on a working or still hot stove or cooker.
- Do not expose the rice cooker to direct sunlight.
- Place the rice cooker on a stable, horizontal, and level surface.
- Always put the inner pot in the rice cooker before you put the plug in the power outlet and switch it on.
- Do not place the inner pot directly over an open fire to cook rice.
- Do not use the inner pot if it is deformed.
- The accessible surfaces may become hot when the rice cooker is operating. Only touch the control panel and open lid button.
- Beware of hot steam coming out of the steam vent during cooking or out of the rice cooker when you open the lid. Keep hands and face away from the rice cooker to avoid the steam.
- The inner pot, steam basket, and resealable cups, during and after cooking process, may be hot and heavy.
- Do not lift and move the rice cooker while it is operating.
- Do not exceed the maximum water level indicated in the inner pot to prevent overflow.
- Do not place the cooking utensils inside the pot while cooking, keeping warm or reheating rice.
- Only use the cooking utensils provided. Avoid using sharp utensils.
- Do not use the cooking utensils provided by the rice cooker on open flame.
- To avoid scratches, it is not recommended to cook ingredients with crustaceans and shellfish. Remove the hard shells before cooking.
- Do not insert metallic objects or alien substances into the steam vent.

- Do not place a magnetic substance on the lid. Do not use the rice cooker near a magnetic substance.
- Always let the rice cooker cool down before you clean or move it.
- Always clean the rice cooker after use. Do not clean the rice cooker in dishwasher.
- Always unplug the rice cooker if not used for a longer period.
- The rice cooker is intended to be used in household or similar applications such as: Staff kitchen areas in shops, offices, and other residential type environments; Farm houses; By clients in hotels, motels and other residential type environments; Bed and breakfast type environments.
- If the rice cooker is used improperly or for professional or semi-professional purposes, or if it is not used according to the instructions in this user manual, the guarantee becomes invalid and Philips refuses liability for any damage caused.

Electromagnetic fields (EMF)

This appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

Bahasa Melayu

Baca risalah keselamatan ini dengan teliti sebelum anda menggunakan perkakas, dan simpan manual pengguna untuk rujukan masa depan.

Bahaya

- Jangan sesekali merendam pemasak nasi di dalam air, dan jangan bersihkannya di bawah air pili.

Amaran

- Pastikan bahawa voltan yang ditunjukkan pada pemasak nasi separadan dengan voltan sesalur kuasa luar periuk dalam bersih dan kering sebelum anda menyambungkannya.
- Anda hendaklah menyambungkan pemasak
- Do not place a magnetic substance on the lid. Do not use the rice cooker near a magnetic substance.
- Always let the rice cooker cool down before you clean or move it.
- Always clean the rice cooker after use. Do not clean the rice cooker in dishwasher.
- Always unplug the rice cooker if not used for a longer period.
- The rice cooker is intended to be used in household or similar applications such as: Staff kitchen areas in shops, offices, and other residential type environments; Farm houses; By clients in hotels, motels and other residential type environments; Bed and breakfast type environments.
- If the rice cooker is used improperly or for professional or semi-professional purposes, or if it is not used according to the instructions in this user manual, the guarantee becomes invalid and Philips refuses liability for any damage caused.

- nasi ke salur keluar kuasa yang dibumikan sahaja. Setiap kali hendaklah pastikan bahawa plag telah dimasukkan dengan betul pada alur keluar kuasa.
- Jangan gunakan perkakas jika plag, kord kuasa, periuk dalam, sendal getah, atau jasad utamanya sendiri rosak.
- Pastikan kord kuasa yang rosak diganti oleh Philips, pusat servis yang diluluskan oleh Philips ataupun orang lain yang layak seumpamanya bagi mengelakkan bahaya.
- Perkakas ini tidak dimaksudkan untuk dikendalikan menggunakan pemasak luaran atau sistem kawalan jauh yang berasingan.
- Perkakas ini tidak dimaksudkan untuk digunakan oleh orang (termasuk kanak-kanak) yang kurang upaya dari segi fizikal, deria atau mental, atau kurang berpengalaman dan pengetahuan, kecuali mereka telah diberi pengawasan atau arahan berkenaan penggunaan perkakas ini oleh orang yang bertanggungjawab atas keselamatan mereka.
- Kanak-kanak hendaklah diawasi untuk memastikan bahawa mereka tidak bermain dengan pemasak nasi ini.
- Jauhkan kord kuasa daripada capaian kanak-kanak. Jangan biarkan kord kuasa terjuntai dari tepi meja atau permukaan ruang kerja tempat pemasak nasi itu diletakkan.
- Pastikan elemen pemanasan, sensor suhu dan bahagian luar periuk dalam bersih dan kering sebelum anda menyambungkannya.
- Berhati-hati dengan stim panas yang keluar dari bolong stim semasa memasak atau yang keluar dari periuk pemasak nasi semasa anda membuka

- tudungnya. Jauhkan tangan dan muka anda daripada pemasak nasi untuk mengelakkan daripada terkena stim.
- Periuk dalam, bakul kukus, dan cawan boleh kedap semula, semasa dan selepas proses memasak, mungkin panas dan berat.
- Jangan angkat atau pindahkan pemasak nasi semasa ia sedang beroperasi.
- Jangan melebihi paras air maksimum yang ditunjukkan pada periuk dalam agar tidak melimpah.
- Jangan letakkan alat-alat memasak di dalam periuk ketika memasak, menyimpan panas atau memanaskan semula nasi.
- Hanya gunakan alat-alat memasak yang disediakan. Elakkan daripada menggunakan alat-alat yang tajam.
- Jangan gunakan alat-alat memasak yang disediakan bersama pemasak nasi pada nyala api terbuka.
- Untuk mengelakkan calar, memasak ramuan seperti krustasea dan kerang-kerangan adalah tidak disyorkan. Buang kulitnya yang keras sebelum memasak.
- Jangan letakkan periuk dalam terus di atas api terbuka untuk memasak nasi.
- Jangan gunakan periuk dalam sekiranya ia cacat.
- Permukaan yang dapat dicapai mungkin menjadi panas semasa pemasak nasi sedang berfungsi. Anda hendaklah hanya menyentuh panel kawalan dan butang pembuka tudung sahaja.
- Biarkan pemasak nasi menyukut terlebih dahulu setiap kali sebelum anda membersih atau mengalihnya.
- Bersihkan pemasak nasi setiap kali selepas menggunakanannya. Jangan

- bersihkan pemasak nasi di dalam mesin basuh pinggan manguk.
- Tanggalkan plag periuk nasi jika ia tidak akan digunakan untuk tempoh masa yang lama.
- Pemasak nasi ini dimaksudkan untuk digunakan di dalam rumah atau penggunaan yang serupa dengan: Kawasan dapur kakitangan di kedai, pejabat dan persekitaran jenis kediaman lain; Rumah ladang; Oleh klien di hotel, motel dan persekitaran jenis kediaman lain; Persekutuan jenis inap-sarapan.
- Jika pemasak nasi tidak digunakan dengan cara yang betul, atau untuk tujuan profesional atau separa profesional, atau jika ia tidak digunakan mengikut arahan dalam panduan pengguna ini, jaminan menjadi tidak sah dan Philips menolak sebarang liabiliti terhadap sebarang kerosakan yang berlaku.

- Medan elektromagnet (EMF)
Perkakas ini mematuhi semua piawai yang berkaitan dengan medan elektromagnet (EMF). Jika dikendalikan dengan betul dan menurut arahan di dalam manual pengguna ini, perkakas ini selamat untuk digunakan berdasarkan bukti saintifik yang ada pada masa ini.
- ภาษาไทย
โปรดอ่านเอกสารที่ช่วยความปลอดภัยนี้อย่างละเอียดก่อนใช้เครื่อง และเก็บไว้เมื่อสักครู่เพื่อใช้งานอีกครั้ง
- อันตราย
. ห้ามลุ่มน้ำหรือข่าวลงในน้ำ หรือ ล้างให้ก้อนน้ำโดยเปลี่ยนน้ำ ให้หลัง สอนลมอว่าได้เสียบปลั๊กเข้ากับ เตัวรับແນ掣แล้ว
- คำเตือน
. ก่อนที่คุณจะเชื่อมต่อตัวเครื่อง โปรดตรวจสอบแรงดันไฟที่ แสดงบนแผ่นตัวอ่านที่ว่าตรงกับ แรงดันไฟที่ใช้ภายในบ้านหรือ เมือง
. เชื่อมต่อหัวปลั๊กเข้ากับรั้ว ที่มีสายดินท่านนั้น ให้ตรวจสอบ สายลมอว่าได้เสียบปลั๊กเข้ากับ เตัวรับແນ掣แล้ว
- . ห้ามใช้เครื่อง หากปลั๊กไฟ สายไฟ หล่อชื้นใน ห่วงกันการรั่ว ซึ่ง หรือตัวเครื่องเกิดการชำรุด

