

PHILIPS

HD4911

EN Important information leaflet

KO 중요 정보 책자



English

Read this safety leaflet carefully before you use the appliance and save it for future reference.

Danger

- The appliance must not be immersed.

Warning

- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

- **WARNING:** If the surface of the cooking plate is cracked, switch off the appliance and do not use it anymore to avoid the possibility of electric shock.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Metallic objects such as knives, forks, spoons and lids should not be placed on the induction cooker since they can get hot.
- The temperature of accessible surfaces may be high when the appliance operates.
- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- The symbol marked on the appliances means "Caution, Hot surfaces", do not touch the hot surface in order to avoid scald.
- Only connect the appliance to an earthed wall socket. Always make sure the plug is inserted firmly into the socket.
- Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- Keep the mains cord out of the reach of children. Do not let the mains cord hang over the edge of the table or worktop on which the appliance stands.
- Never connect this appliance to an external timer switch in order to avoid a hazardous situation.
- Make sure the cooking plate is clean and dry before you switch on the appliance.
- Do not cover the air outlets while the induction cooker is operating.
- Do not touch the appliance or operate the control panel with wet hands.
- Don't clean the appliance while hot.
- Use a soft damp cloth to clean the surfaces in contact with water.
- Do not touch the cooking plate after cooking, as it retains heat from the cookware.
- Do not insert external objects such as iron wires and bolts into the appliance.
- Do not cover any part of the cooking plate with aluminium to prevent the risk of electric shock, short circuiting or fire.
- If the surface of the cooking plate is cracked, switch off the appliance and do not use it anymore to prevent the risk of electric shock, short circuiting or fire.



Caution

- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.

- Do not expose the induction cooker to high temperatures, hot gas, steam or damp heat. Do not place the induction cooker on or near an operating or still hot stove or cooker.
- Always switch off the appliance before you unplug it.
- Always unplug the appliance and let it cool down before you clean it.
- This appliance is intended for household use only. If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and Philips refuses any liability for damage caused.
- Place the induction cooker on a stable, horizontal and level surface and make sure there is at least 10cm free space around it to prevent overheating.
- Do not use the induction cooker on a gas cooker or metal plate.
- For better ventilation, do not block the air inlet and outlets while the appliance is operating, e.g. do not operate the appliance on a plastic tablecloth.
- Do not place anything between the cookware and the cooking plate.
- The maximum weight that can be put on the induction cooker is 15kg.
- Beware of hot steam that comes out of the cookware during cooking or when you remove the lid.
- Do not lift and move the induction cooker while it is operating.
- Never put empty cookware on the switched-on induction cooker, as this could cause the cookware to become distorted or the heating coil to become damaged.
- Do not store flammable materials and liquids near or on the induction cooker.
- Avoid hard contact between the cookware or other objects and the crystallite cooking plate.
- Always place the cookware on the cooking zone during cooking.

Automatic shut-off

The appliance is equipped with automatic shut-off. It switches off automatically in the following situations:

- If cookware with a bottom diameter less than 6cm, or small objects like knives, forks, or spoons are placed on the plate during cooking.
- If the voltage is lower than 120V or higher than 280V.
- If the induction cooker has been idle for 2 hours.
- If no cookware is put on the cooking plate while the induction cooker is operating. The induction cooker will beep every 2 seconds and turn off automatically after 1 minute.
- If the temperature of the central plate is higher than 300°C, or if the internal temperature of the induction cooker is too high.

Electromagnetic fields (EMF)

This appliance complies with the applicable standards and regulations regarding exposure to electromagnetic fields.

Warranty and support

Versuni offers a two-year warranty after purchase on this product. This warranty is not valid if a defect is due to incorrect use or poor maintenance. Our warranty does not affect your rights under law as a consumer. For more information or for invoking the warranty, please visit our website www.philips.com/support.

한국어

본 제품을 사용하기 전에 이 안전 책자를 주의 깊게 읽고 나중에 참조할 수 있도록 잘 보관하십시오.

위험

- 제품을 액체에 담그지 마십시오.

경고

- 본 제품은 가정 및 다음과 같은 유사 환경에서 사용하도록 설계되었습니다.
 - 매장, 사무실 및 기타 작업 환경 내 직원용 탕비실;
 - 주거 시설;
 - 호텔 및 기타 숙박 시설;
 - 민박 시설.
- 신체적인 감각 및 인지능력이 떨어지거나 경험과 지식이 풍부하지 않은 성인 및 어린이는 혼자 제품을 사용하지 말고 제품 사용과 관련하여 안전에 책임질 수 있도록 지시사항을 충분히 숙지한 사람의 도움을 받으십시오.
- 어린이가 제품을 가지고 놀지 않도록 보호자의 감독이 필요합니다.
- 경고: 조리 열판에 균열이 생긴 경우에는 감전을 방지하기 위해 제품의 전원을 끄고 더 이상 사용하지 마십시오.
- 본 제품은 외부 타이머나 별도의 리모콘 시스템으로 작동하지 않습니다.
- 전원 코드가 손상된 경우 안전을 위해 제조업체, 서비스 기사 또는 전문 기술자에게 의뢰하여 교체하십시오.
- 나이프, 포크, 스푼, 뚜껑과 같은 금속성 물체는 뜨거워질 수 있으니 전기 레인지 위에 올려놓지 마십시오.
- 제품이 작동하는 동안 손이 닿는 표면의 온도가 매우 높을 수 있습니다.
- 제품에 전원을 연결하기 전에, 제품에 표시된 전압과 사용 지역의 전압이 일치하는지 확인하십시오.
- 제품에 표시된 기호는 “주의, 뜨거운 표면”을 의미하며



- 화상을 방지하기 위해 제품이 뜨거울 때 만지지 마십시오.
- 제품은 반드시 접지된 벽면 콘센트에 연결하십시오. 전원 플러그가 콘센트에 완전히 꽂혔는지 항상 확인하십시오.
- 만약 플러그나 전원 코드 또는 제품이 손상되었을 경우에는 제품을 사용하지 마십시오.
- 전원 코드는 어린이의 손이 닿지 않는 곳에 보관하십시오. 제품이 올려져 있는 식탁이나 조리대의 가장자리로 전원 코드가 흘러내리지 않도록 하십시오.
- 제품을 외부 타이머에 연결하지 마십시오. 위험할 수 있습니다.
- 제품을 켜기 전에는 조리 열판이 깨끗하고 건조한지 확인하십시오.
- 전기 레인지가 작동하는 동안에는 공기 배출구를 막지 마십시오.
- 손이 젖은 상태에서 제품의 콘센트를 꽂거나 제거판을 만지지 마십시오.
- 뜨거운 상태에서 제품을 세척하지 마십시오.
- 물에 적신 부드러운 천으로 물에 닿는 표면을 세척하십시오.
- 조리 용기의 열이 남아있을 수 있으니 조리 후에는 조리 열판을 만지지 마십시오.
- 제품 안에 철선, 볼트와 같은 외부 물체를 넣지 마십시오.
- 감전, 단락 또는 화재의 위험이 있으니 조리 열판의 어떤 부분도 알루미늄으로 덮지 마십시오.
- 조리 열판에 균열이 생긴 경우에는 감전, 단락 또는 화재를 방지하기 위해 제품의 전원을 끄고 더 이상 사용하지 마십시오.

주의

- 다른 제조업체에서 만들었거나 필립스에서 권장하지 않은 제품 액세서리 또는 부품은 절대 사용하지 마십시오. 이러한 액세서리나 부품을 사용했을 경우에는 품질 보증이 무효화됩니다.
- 전기 레인지를 고온, 뜨거운 가스, 스팀 혹은 수증기에 노출시키지 마십시오. 작동 중이거나 뜨거운 상태의 전기 또는 가스 레인지에 전기 레인지를 가까이 놓거나 그 위에 놓지 마십시오.
- 항상 제품의 전원을 끄고 코드를 뽑으십시오.
- 제품을 세척하기 전에 항상 플러그를 뽑고 열기를 식하십시오.
- 본 제품은 가정용입니다. 제품을 부적절하게 사용하거나 사업장 또는 준사업장에서 사용하는 경우, 또는 사용자 설명서에 따라 이용하지 않는 경우, 보증 서비스를 받을 수 없으며 필립스는 이로 인해 발생한 피해에 대한 책임을 지지 않습니다.
- 전기 레인지를 안전하고 평평한 장소에 두고, 과열되지 않도록 제품 주위에 최소 10cm의 여유 공간을 확보하십시오.
- 전기 레인지를 가스 레인지 또는 금속 용기 위에서 사용하지 마십시오.
- 제품이 작동하는 동안 공기 흡입구 및 배출구 막지 마십시오. 예를 들어 제품을 플라스틱 식탁보 위에서 사용하지 마십시오.
- 조리 용기와 조리 열판 사이에는 아무것도 놓지 마십시오.
- 전기 레인지의 최대 하중은 15kg입니다.

- 조리 중 또는 뚜껑을 여는 경우 용기에서 나오는 증기는 매우 뜨거우므로 주의하십시오.
- 작동 중에는 전기 레인지를 들거나 옮기지 마십시오.
- 용기가 변형되거나 코일이 가열되어 손상될 수 있으니 전원이 켜져 있는 전기 레인지 위에는 절대로 비어 있는 용기를 올려놓지 마십시오.
- 가연성 물질 및 용액을 전기 레인지 주변 또는 위에 보관하지 마십시오.
- 내열 글라스세라믹 열판이 조리 용기 또는 다른 물체에 긁히지 않도록 주의하십시오.
- 요리하는 동안 조리 용기를 반드시 조리 영역에 두십시오.

자동 전원 차단

본 제품에는 자동 전원 차단 기능이 있습니다. 다음과 같은 상황에서 전원이 자동으로 꺼집니다:

- 조리 용기 바닥 지름이 6cm 미만이거나 조리 중 나이프, 포크, 스푼과 같은 작은 물체를 열판 위에 올려놓은 경우.
- 전압이 120V보다 낮거나 280V보다 높은 경우.
- 전기 레인지를 2시간 동안 사용하지 않은 경우.
- 인덕션 쿠키 작동 중 조리 열판에 조리 용기를 올려놓지 않은 경우. 인덕션 쿠키에서 2초마다 신호음이 울리고 1분 후에는 자동으로 꺼집니다.
- 열판 중앙의 온도가 300°C 이상이거나 전기 레인지의 내부 온도가 너무 높은 경우.

EMF(전자기장)

이 제품은 EMF(전자기장) 노출과 관련된 해당 표준 및 규정을 준수합니다.

품질 보증 및 지원

Versuni는 제품 구매 후 2년간 보증을 제공합니다. 제품의 결함이 올바르지 못한 사용 또는 잘못된 유지 관리로 인한 것인 경우 보증은 무효합니다. 당사의 보증은 소비자로서 법에 따른 귀하의 권리에 영향을 미치지 않습니다. 자세한 내용을 확인하거나 보증을 청구하려면

www.philips.com/support를 방문하세요.



PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of Versuni Holding B.V., and Versuni Holding B.V. is the warrantor in relation to this product.
2023 © Versuni Holding B.V.

6608.000.0795.8 (07/03/2023)

