

EN	Safety leaflet
PT-BR	Folheto de segurança



**CIC** Centro de Informações  
ao Consumidor  
Grande SP: (11) 2121 0203  
Demais localidades: 0800 701 0203

PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.  
This product has been manufactured by and is sold under the responsibility of Versuni Holding B.V., and Versuni Holding B.V. is the warrantor in relation to this product.  
2023 © Versuni Holding B.V.



6608.000.0018.3 (15/02/2023)



## English

Read this safety leaflet carefully before you use the electric pressure cooker and save it for future reference.

### Danger

- The appliance must not be immersed.

### Warning

- Check if the voltage indicated on the appliance corresponds to the local power voltage before you connect it.
- This appliance is intended to be used in household and similar applications such as:
  - staff kitchen areas in shops, offices and other working environments;
  - farm houses;
  - by clients in hotels, motels and other residential type environments;
  - bed and breakfast type environments.
- Only connect the appliance to a grounded power outlet. Always make sure that the plug is inserted firmly into the power outlet.
- Do not use the appliance if the plug, the power cord, the inner pot, the sealing

ring, or the main body is damaged.

- If the power cord set is damaged, it must be replaced by a cord set available from the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Keep the appliance and its cord out of reach of children.
- Do not let the power cord hang over the edge of the table or worktop on which the appliance stands.
- Make sure the heating element, the temperature sensor, and the outside of the inner pot are clean and dry before you put the plug in the power outlet.
- Do not plug in the appliance or operate on the control panel with wet hands.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- The ducts in the pressure regulator allowing the escape of steam should be checked regularly to ensure that they are not blocked.
- Make sure the power socket is clean and dry before you plug in the appliance.
- The container must not be opened until the pressure has decreased sufficiently.
- Do not use the appliance if too much air or steam is leaking from under the top lid.
- When cooking soup or viscous liquid, do not release pressure by turning

the pressure regulator to the steam vent position, otherwise liquid might spurt from the pressure regulator. Wait until the pressure is naturally released and the floater has dropped to open the top lid.

- **WARNING:** Make sure to avoid spillage on the power connector to avoid a potential hazard.
- **WARNING:** Always follow the instructions and use the appliance properly to avoid potential injury.
- According to the instructions prescribed in this user manual, use a soft damp cloth to clean the surfaces in contact with food and make sure to remove all the food residues stuck to the appliance.

### Caution

- **CAUTION:** The heating element surface is subject to residual heat after use.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not expose the appliance to high temperatures, nor place it on a working or still hot stove or cooker.
- Do not expose the appliance to direct sunlight.
- Place the appliance on a stable, horizontal, and level surface.
- Do not use the handle on the top lid to move the appliance, use the side handles instead.
- When pressure is being released from the pressure regulator valve, hot steam or liquid will be ejected. Keep hands and face away from the steam vent.
- Always put the inner pot in the appliance before you put the plug in the power outlet and switch it on.
- Do not place the inner pot directly over an open fire to cook food.
- Do not use the inner pot if it is deformed.

- Make sure that the sealing ring is clean and in good condition.
- The accessible surfaces may become hot when the appliance is operating. Take extra caution when touching the surfaces.
- Beware of hot steam coming out of the floating valve and pressure regulator valve during cooking or when you open the lid. Keep hands and face away from the appliance to avoid the steam.
- Do not lift and move the appliance while it is operating.
- Do not exceed the maximum water level indicated in the inner pot to prevent overflow.
- Do not place cooking utensils inside the pot while cooking.
- Only use the cooking utensils provided. Avoid using sharp utensils.
- To avoid scratches, it is not recommended to cook ingredients with crustaceans and shellfish. Remove the hard shells before cooking.
- Do not place a magnetic substance on the lid. Do not use the appliance near a magnetic substance.
- Always let the appliance cool down to room temperature before you clean or move it.
- Always clean the appliance after use. Do not clean the appliance in dishwasher.
- Always unplug the appliance if not used for a longer period.
- If the appliance is used improperly or for professional or semi-professional purposes, or if it is not used according to the instructions in this safety leaflet, the guarantee becomes invalid and Philips refuses liability for any damage caused.

### Electromagnetic fields (EMF)

This appliance complies with the applicable standards and regulations regarding exposure to electromagnetic fields.

Leia atentamente este folheto de segurança antes de usar a panela de pressão elétrica e guarde-o para consultas futuras.

## Perigo

- O aparelho não deve ser imerso.

## Aviso

- Antes de ligar o aparelho, verifique se a tensão indicada no aparelho corresponde à tensão do local.
- Este aparelho destina-se ao uso doméstico e a aplicações semelhantes, tais como:
  - cozinhas para funcionários em lojas, escritórios e outros ambientes de trabalho;
  - casas de campo;
  - hóspedes em hotéis, motéis e outros tipos de ambientes residenciais;
  - ambientes do tipo pousadas e hospedarias.
- O aparelho deve ser conectado somente a uma tomada aterrada. Sempre verifique se o plugue foi conectado corretamente à tomada.
- Não use o aparelho caso o plugue, o cabo de energia, a panela interna, o anel de vedação ou a estrutura principal estejam danificados.
- Se o conjunto de cabos de energia estiver danificado, ele deverá ser substituído por um conjunto de cabos disponibilizado pelo fabricante.
- O aparelho não deve ser usado por pessoas (inclusive crianças) com capacidades físicas, mentais ou sensoriais reduzidas ou pouca experiência e conhecimento, a menos que sejam supervisionadas ou instruídas sobre o uso do aparelho por uma pessoa responsável por sua segurança.
- Crianças pequenas devem ser supervisionadas para que não brinquem com o aparelho.
- Crianças não devem realizar limpeza ou manutenção sem a supervisão de um adulto.
- Mantenha o aparelho e o cabo fora do alcance de crianças.

- Não deixe o cabo de energia pendurado no canto da mesa ou na bancada em que o aparelho fica.
- Verifique se o elemento de aquecimento, o sensor de temperatura e a parte externa da panela interna estão limpos e secos antes de conectá-los à tomada de energia.
- Não conecte o aparelho à tomada nem opere o painel de controle com as mãos molhadas.
- O aparelho não deve ser operado por meio de um temporizador externo ou sistema de controle remoto à parte.
- Os canais no regulador de pressão que permitem a fuga de vapor devem ser verificados regularmente para assegurar que eles não estejam bloqueados.
- Certifique-se de que o soquete de energia esteja limpo e seco antes de ligar o aparelho.
- O recipiente não deve ser aberto até que a pressão tenha diminuído o suficiente.
- Não utilize o aparelho se houver o vazamento demasiado de ar ou de vapor sob a tampa superior.
- Ao cozinhar sopa ou líquidos viscosos, não libere a pressão virando o regulador de pressão para a posição de saída de vapor, senão, o líquido pode jorrar pelo regulador. Espere até que a pressão seja liberada naturalmente e a boia caia para abrir a tampa superior.
- AVISO: certifique-se de evitar derramamentos sobre o conector de alimentação para evitar um risco potencial.
- AVISO: siga sempre as instruções e utilize o aparelho corretamente para evitar possíveis ferimentos.
- De acordo com as instruções neste manual do usuário, utilize um pano macio e úmido para a limpeza das superfícies em contato com os alimentos. Certifique-se de remover todos os resíduos de

alimentos colados no aparelho.

## Atenção

- ATENÇÃO: A superfície do elemento de aquecimento está sujeita ao calor residual após o uso.
- Nunca use acessórios ou peças de outros fabricantes ou que não sejam especificamente recomendados pela Philips. Caso contrário, a garantia será anulada.
- Não exponha o aparelho a altas temperaturas nem coloque-o em um forno ou fogão quente ou em funcionamento.
- Não exponha o aparelho à luz solar direta.
- Coloque o aparelho em uma superfície estável, horizontal e nivelada.
- Não use a alça da tampa superior para movimentar o aparelho, use as alças laterais.
- Quando a pressão está sendo liberada da válvula reguladora de pressão, é expelido vapor quente ou líquido. Mantenha as mãos e o rosto longes da saída de vapor.
- Coloque a panela interna no aparelho antes de conectar o plugue à tomada de energia e ligar o aparelho.
- Não coloque a panela interna no fogo para cozinhar alimentos.
- Não use a panela interna caso esteja danificada.
- Assegure-se que o anel de vedação esteja limpo e em boas condições.
- As superfícies acessíveis podem ficar muito quentes durante o funcionamento do aparelho. Tenha muito cuidado ao tocar as superfícies.
- Cuidado com o vapor quente que sai da válvula flutuante e do regulador de pressão durante o cozimento ou quando abrir a tampa. Mantenha as mãos e o rosto longe do aparelho para evitar o vapor.
- Não levante nem mova o aparelho enquanto ele estiver em funcionamento.

- Para evitar vazamento, não exceda o nível máximo de água indicado na panela interna.
- Não coloque utensílios de cozinha dentro da panela interna enquanto cozinha.
- Use apenas os utensílios fornecidos. Evite usar utensílios pontiagudos.
- Para evitar arranhões, não é recomendável cozinhar alimentos com crustáceos e mariscos. Remova as cascas duras antes do preparo.
- Não coloque substâncias magnéticas na tampa. Não use o aparelho próximo de substâncias magnéticas.
- Sempre deixe o aparelho esfriar até a temperatura ambiente antes de limpá-lo ou movê-lo.
- Limpe sempre o aparelho após o uso. Não coloque o aparelho na lava-louças.
- Desconecte o aparelho da tomada após um longo período de inatividade.
- Se o aparelho for usado de forma inadequada, para fins profissionais/semiprofissionais, ou não for usado de acordo com este folheto de segurança, a garantia perderá a validade e a Philips se eximirá da responsabilidade pelo dano causado.

## Campos eletromagnéticos

Este aparelho cumpre todas as normas e regulamentos aplicáveis relativos à exposição a campos eletromagnéticos.