

EN	Safety leaflet
KO	안전 설명서

PHILIPS



Specifications are subject to change without notice.
© 2013 Koninklijke Philips N.V.
All rights reserved.

HD4933_Safety_Korea_V1.0



English

Important

Read this safety leaflet carefully before you use the appliance and save it for future reference.

Danger

- Never immerse the appliance in water or rinse it under the tap.

Warning

- **WARNING:** if the surface of the cooking plate is cracked, switch off the appliance and do not use it anymore to prevent the risk of electric shock, short circuiting or fire.
- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Only connect the appliance to an earthed wall socket. Always make sure the plug is inserted firmly into the socket.
- Do not use the appliance if the plug, the mains cord

or the appliance itself is damaged.

- If the mains cord is damaged, you must have it replaced by Philips, a service center authorised by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance is intended for household use only. If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and Philips refuses any liability for damage caused.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep the appliance and its cord out of reach of children less than 8 years. Do not let the mains cord hang over the edge of the table or worktop on which the appliance stands.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- The temperature of accessible surfaces may be high when the appliance operates.

- Make sure the cooking plate is clean and dry before you switch on the appliance.
- Do not cover the air outlets while the induction cooker is operating.
- Do not plug in the appliance or operate the control panel with wet hands.
- Do not touch the cooking plate after cooking, as it retains heat from the cookware.
- Metallic objects such as knives, forks, spoons and lids should not be placed on the induction cooker since they can get hot.
- Do not insert external objects such as iron wires and bolts into the appliance.
- Do not cover any part of the cooking plate with aluminum to prevent the risk of electric shock, short circuiting or fire.

Caution

- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not expose the induction cooker to high temperatures, hot gas, steam or damp heat. Do not place the induction cooker on or near an operating or still hot stove or cooker.
- Always switch off the appliance before you unplug it.
- Always unplug the appliance and let it cool down before you clean it.
- This appliance is intended for household use only. If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and Philips refuses any liability for damage caused.

- Place the induction cooker on a stable, horizontal and level surface and make sure there is at least 10cm free space around it to prevent overheating.
- Do not use the induction cooker on a gas cooker or metal plate.
- For better ventilation, do not block the air inlet and outlets while the appliance is operating, e.g. do not operate the appliance on a plastic tablecloth.
- Do not place anything between the cookware and the cooking plate.
- Do not put heavy objects on the induction cooker.
- Beware of hot steam that comes out of the cookware during cooking or when you remove the lid.
- Do not lift and move the induction cooker while it is operating.
- Never put empty cookware on the switched-on induction cooker, as this could cause the cookware to become distorted or the heating coil to become damaged.
- Do not store flammable materials and liquids near or on the induction cooker.
- Avoid hard contact between the cookware or other objects and the cooking plate.
- Always place the cookware on the cooking zone during cooking.
- Always use cookware with a bottom diameter from 10cm to 23cm during cooking.

Automatic shut-off

The appliance is equipped with automatic shut-off. It switches off automatically in the following situations:

- If cookware with a bottom diameter less than 6cm, or small objects like knives, forks, or spoons are placed on the plate during cooking.
- If the voltage is lower than 120V or higher than 280V.
- If no cookware is put on the cooking zone for more than 1 minute when the induction cooker is working.
- If the cookware has been boiling dry for 3 minutes.
- If the induction cooker has been idle for 2 hours.
- If the temperature of the central plate is higher than 300°C, or if the internal temperature of the induction cooker is too high.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

한국어

주의 사항

본 제품을 사용하기 전에 이 안전 책자를 주의 깊게 읽고 나중에 참조할 수 있도록 잘 보관하십시오.

위험

- 제품을 물에 담그거나 헹구지 마십시오.

경고

- 경고: 조리 열판에 균열이 생긴 경우에는 감전, 단락 또는 화재를 방지하기 위해 제품의 전원을 끄고 더 이상 사용하지 마십시오.
- 제품에 전원을 연결하기 전에, 제품에 표시된 전압과 사용 지역의 전압이 일치하는지 확인하십시오.
- 제품은 반드시 접지된 벽면 콘센트에 연결하십시오. 전원 플러그가 콘센트에 완전히 꽂혔는지 항상 확인하십시오.
- 만약 플러그나 전원 코드 또는 제품이 손상되었을 경우에는 제품을 사용하지 마십시오.
- 전원 코드가 손상된 경우, 안전을 위해 필립스 공인 서비스 센터 또는 전문 기술자에게 의뢰하여 교체하십시오.
- 본 제품은 가정용입니다. 제품을 부적절하게 사용하거나 사업장 또는 준사업장에서 사용하는 경우, 또는 사용 설명서에 따라 이용하지 않는 경우, 보증 서비스를 받을 수 없으며 필립스는 이로 인해 발생한 피해에 대해 책임을 지지 않습니다.
- 8세 이상의 아이들과 신체적인 감각 및 정식적인 능력이 떨어지거나 경험과 지식이 풍부하지 않은 성인이 이 제품을 사용하려면 제품 사용과 관련하여 안전하게 사용할 수 있도록 지시사항을 충분히

숙지한 사람의 도움을 받아야 합니다.

- 8세 이하 및 관리 하에 있지 않은 어린이가 제품을 청소 및 관리할 수 없습니다.
- 어린이가 제품을 가지고 놀지 못하도록 지도해 주십시오.
- 제품 및 코드를 8세 이하 어린이의 손에 닿지 않는 곳에 보관하십시오. 제품이 올려져 있는 식탁이나 조리대의 가장자리로 전원 코드가 흘러내리지 않도록 하십시오.
- 본 제품은 외부 타이머나 별도의 리모콘 시스템으로 작동하지 않습니다.
- 제품이 작동하는 동안 손이 닿는 표면의 온도가 매우 높을 수 있습니다.
- 제품을 켜기 전에는 조리 열판이 깨끗하고 건조한지 확인하십시오.
- 전기 레인지가 작동하는 동안에는 공기 배출구를 막지 마십시오.
- 손이 젖은 상태에서 제품의 콘센트를 꽂거나 제어판을 만지지 마십시오.
- 조리 용기의 열이 남아있을 수 있으니 조리 후에는 조리 열판을 만지지 마십시오.
- 나이프, 포크, 스푼, 뚜껑과 같은 금속성 물체는 뜨거워질 수 있으니 전기 레인지 위에 올려놓지 마십시오.
- 제품 안에 철선, 볼트와 같은 외부 물체를 넣지 마십시오.
- 감전, 단락 또는 화재의 위험이 있으니 조리 열판의 어떤 부분도 알루미늄으로 덮지 마십시오.

주의

- 다른 제조업체에서 만들었거나 필립스에서 권장하지 않은 제품 액세서리 또는 부품은 절대 사용하지 마십시오. 이러한 액세서리나 부품을 사용했을 경우에는 품질 보증이 무효화됩니다.
- 전기 레인지를 고온, 뜨거운 가스, 스팀 혹은 수증기에 노출시키지 마십시오. 작동 중이거나 뜨거운 상태의 전기 또는 가스 레인지에 전기 레인지를 가까이 놓거나 그 위에 놓지 마십시오.
- 항상 제품의 전원을 끄고 코드를 뽑으십시오.
- 제품을 세척하기 전에 항상 플러그를 뽑고 열기를 식히십시오.
- 본 제품은 가정용입니다. 제품을 부적절하게 사용하거나 사업장 또는 준사업장에서 사용하는 경우, 또는 사용 설명서에 따라 이용하지 않는 경우, 보증 서비스를 받을 수 없으며 필립스는 이로 인해 발생한 피해에 대해 책임을 지지 않습니다.
- 전기 레인지를 안전하고 평평한 장소에 두고, 과열되지 않도록 제품 주위에 최소 10cm의 여유 공간을 확보하십시오.
- 전기 레인지를 가스 레인지 또는 금속 용기 위에서 사용하지 마십시오.
- 제품이 작동하는 동안 공기 흡입구 및 배출구 막지 마십시오. 예를 들어 제품을 플라스틱 식탁보 위에서 사용하지 마십시오.
- 조리 용기와 조리 열판 사이에는 아무 것도 놓지 마십시오.
- 전기 레인지 위에 무거운 물체를 놓지 마십시오.

- 조리 중 또는 뚜껑을 여는 경우 용기에서 나오는 증기는 매우 뜨거우므로 주의하십시오.
- 작동 중에는 전기 레인지를 들거나 옮기지 마십시오.
- 용기가 변형되거나 코일이 가열되어 손상될 수 있으니 전원이 켜져 있는 전기 레인지 위에는 절대로 비어 있는 용기를 올려놓지 마십시오.
- 가연성 물질 및 용액을 전기 레인지 주변 또는 위에 보관하지 마십시오.
- 조리 열판이 조리 용기 또는 다른 물체에 긁히지 않도록 주의하십시오.
- 조리 중에는 용기를 항상 알맞은 조리 위치에 놓으십시오.
- 조리 중에는 바닥의 지름이 10cm~23cm인 용기만 사용하십시오.

자동 전원 차단

본 제품에는 자동 전원 차단 기능이 있습니다. 다음과 같은 상황에서 전원이 자동으로 꺼집니다.

- 바닥의 지름이 6cm 미만인 용기를 사용하거나 조리 중 나이프, 포크, 스푼 등을 열판 위에 올려 놓은 경우
- 전압이 120V보다 낮거나 280V보다 높은 경우
- 전기 레인지를 작동시킨 상태에서 조리 위치에 용기를 1 분 이상 올려놓지 않은 경우
- 용기가 비어 있는 상태로 3분 이상 가열된 경우
- 전기 레인지를 2시간 동안 사용하지 않은 경우
- 열판 중앙의 온도가 300° C 이상이거나 전기 레인지의 내부 온도가 너무 높은 경우

EMF(전자기장)

이 필립스 제품은 EMF(전자기장)와 관련된 모든 기준 및 규정을 준수합니다.