



EN
5

Important information leaflet

نشرة تتضمن معلومات مهمة

1
AR



English

Read this user manual carefully before you use the appliance, and save it for future reference.

Danger

- Do not let any liquid or flammable detergent enter the appliance, to avoid electric shock and/or a fire hazard.
- In order to avoid overheating and fire, do not cover the device.



Warning

- Some parts of this product can become very hot and cause burns. Continuously supervision has to be given where children and vulnerable people are present.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children shall not play with the appliance.
- Cleaning and maintenance shall not be made by children without supervision.
- When device working in heating mode, the surface temperature will gradually increase. Do not touch the air outlet to avoid being burn.
- To reduce the risk of fire, keep textiles, curtains, beddings or any other flammable material a minimum distance of 1 m from the air outlet. Do not block the air inlet and outlet, e.g. by placing items on the air outlet or in front of the air inlet.
- Do not insert fingers, sticks or other objects into the machine, in order to avoid electric shocks, physical injury or fire.
- Device has heating component. Do not use the appliance near gas appliances, fireplaces.
- Do not spray any flammable materials such as insecticides or fragrance around the appliance.
- Do not use if there are visible signs of damage to the device, the plug, the power cord.
- Do not use this device if it has been dropped.
- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips, or similarly qualified persons in order to avoid a hazard.

Caution

- Only use the original Philips filter, otherwise the filtration performance cannot be guaranteed.
- The device must not be located immediately below a socket outlet.
- Only plug in socket on the wall, do not use extension cord.
- Always place and use the appliance on a dry, stable, and horizontal surface.
- Do not use the appliance in surroundings with high humidity such as the bathroom, toilet, kitchen, swimming pool, or any outdoor environment.
- Do not sit or stand on the appliance. Do not knock against appliance. Do not place anything on top of the appliance.
- Always unplug the appliance when you want to move, clean appliance, replace the filter or carry out other maintenance.
- When you turn on device, always keep filter in it.
- The device operating temperature range (ta) is from -10°C to 40°C. It will stop working outside the recommended temperature range.
- The appliance is only intended for household use under normal operating conditions.
- Suggest to not use this appliance when you smoke, or use smoke type insect repellents or burning incense, etc. it would impact purification performance, and filter lifetime.
- The appliance does not remove carbon monoxide (CO) or radon (Rn). It cannot be used as a safety device in case of accidents with combustion processes and hazardous chemicals.
- Do not put the remote control (battery) in places where children can access it. Seek immediate medical attention if the battery is swallowed.
- If the remote control is idle for a long time, please remove the battery from the remote control to avoid battery leakage.
- If leaking fluid from the battery accidentally enters the eye, rinse the eye out with plenty of clean water, and then seek immediate medical attention.
- If leaking fluid from the battery comes into contact with the skin or clothes, please rinse with plenty of clean water immediately.
- This is a class 3R laser product, avoid direct eye exposure. The laser component is part of particle sensor, cannot be touched or saw in normal use.

- Max output 2.5mW, wavelength 650nm, continuous wave, beam divergence: 38*8



Hereby, Philips Consumer Lifestyle B.V. declares that the radio equipment type AMF220 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.philips.com.

Radio interface band is 433.92MHz with max transmit power 10mW e.r.p.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Recycling

Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

This product contains disposable batteries which shall not be disposed of with normal household waste.

Follow your country's rules for the separate collection of electrical and electronic products and batteries. Correct disposal helps prevent negative consequences for the environment and human health.

Removing disposable batteries

To remove disposable batteries, see the instructions for placing and/or removing batteries in the user manual.

Always remove empty disposable batteries from the product. Take any necessary safety precautions when you dispose of batteries.

Guarantee and service

If you need information or support, please visit www.philips.com or read the worldwide guarantee leaflet.

Order parts or accessories

If you have to replace a part or want to purchase an additional part, go to your Philips dealer or visit www.philips.com/support.

If you have problems obtaining the parts, please contact the Philips Consumer Care Center in your country (you can find its phone number in the worldwide guarantee leaflet).

الحقول الكهرومغناطيسية (EMF)

يتوافق جهاز Philips هذا مع كل المعايير والأنظمة المطبقة المتعلقة بالتعرض للحقول الكهرومغناطيسية.

إعادة التدوير

لا تتخلص من المنتج مع النفايات المنزلية لدى انتهاء فترة استهلاكه، بل سلمه إلى مركز تجميع رسمي لإعادة تدويره. من خلال القيام بذلك، أنت تساهم في المحافظة على البيئة. يحتوي هذا الجهاز على بطاريات غير قابلة لإعادة الاستعمال والتي يجب عدم التخلص منها مع النفايات المنزلية العادية. اتبع القوانين السارية في بلدك في ما يتعلق بالتجميع المنفصل للمنتجات الإلكترونية والكهربائية والبطاريات. يساعد التخلص من النفايات بطريقة صحيحة في منع العواقب السلبية على البيئة وصحة الأشخاص.

إزالة البطاريات غير القابلة لإعادة الاستعمال

لإزالة البطاريات غير القابلة لإعادة الاستعمال، راجع التوجيهات الخاصة بتركيب البطاريات و/أو إزالتها في دليل المستخدم. احرص دائماً على إزالة البطاريات غير القابلة لإعادة الاستعمال الفارغة من المنتج. خذ احتياطات السلامة الضرورية عند التخلص من البطاريات.

الضمان والخدمة

إذا كنت بحاجة إلى المعلومات أو الدعم، فنفضلُ بزيارة www.philips.com أو اقرأ كتيب الضمان العالمي.

طلب القطع أو الملحقات

إذا احتجت إلى تبديل قطعة أو إذا كنت ترغب في شراء قطعة إضافية، فتوجه إلى وكيل Philips لديك أو تفضلُ بزيارة www.philips.com/support. إذا كنت تجد صعوبة في الحصول على القطع، يُرجى الاتصال بمركز خدمة المستهلك التابع لشركة Philips في بلدك (يمكنك العثور على رقم الهاتف في نشرة الضمان العالمية).

- نقتراح عدم استخدام الجهاز أثناء التدخين أو استخدام المواد الطاردة للحشرات التي تصدر دخاناً أو بخور مشتعل، إلخ، إذ قد يؤثر ذلك في أداء التنقية وفترة استهلاك الفلتر.
- لا يزيل الجهاز أحادي أكسيد الكربون (CO) أو غاز الرادون (Run). لا يمكن استخدامه كجهاز إنذار في حال وقوع حوادث نتيجة لعمليات الاحتراق والمواد الكيميائية الخطرة.
- لا تضع جهاز التحكم عن بعد (البطارية) في أماكن يمكن للأطفال الوصول إليه. استشر طبيباً على الفور في حال ابتلاع البطارية.
- إذا كان جهاز التحكم عن بعد في وضع الخمول لفترة طويلة، فُرجى إزالة البطارية منه تفادياً لتسرب سائل البطارية.
- إذا دخل السائل المتسرب من البطارية في العين عن غير قصد، فاغسلها بكمية وافرة من المياه النظيفة ثم استشر طبيباً على الفور.
- إذا لامس السائل المتسرب من البطارية البشرة أو الملابس، فُرجى غسل هذه الأخيرة بكمية وافرة من المياه النظيفة على الفور.
- هذا منتج ليزر من الفئة 3R، فتفاداً توجيهه نحو العينين بشكل مباشر. يشكل مكوّن الليزر جزءاً من مستشعر الجسيمات، فلا يمكن لمسه أو رؤيته أثناء الاستخدام العادي.
- الحد الأقصى للإخراج هو 2,5 ملي فولت، الطول الموجي هو 650 نانومتراً، موجة مستمرة، تباعد الشعاع: 38*8



تُعلن Philips Consumer Lifestyle B.V. المستند إن الجهاز اللاسلكي من النوع AMF220 يتوافق مع التوجيه 2014/53/EU. يمكن العثور على النص الكامل لإعلان المطابقة الخاص بالاتحاد الأوروبي على العنوان التالي عبر الإنترنت: www.philips.com. يبلغ نطاق الواجهة اللاسلكية 433,92 ميغاهرتز مع قوة إرسال قصوى طاقة تبلغ 10 ملي واط بالقدرة المشعة الفعالة القصوى.

اقرأ دليل المستخدم هذا بعناية قبل استخدام الجهاز واحتفظ به للرجوع إليه مستقبلاً.

خطر

- احرص على عدم تسرب أي سائل أو مادة تنظيف قابلة للاشتعال إلى داخل الجهاز تفادياً لحدوث صدمة كهربائية و/أو نشوب حريق.
- لا تغط الجهاز تفادياً للإحماء بشكل مفرط أو نشوب حريق.



تحذير

- قد تصبح بعض أجزاء هذا المنتج ساخنة جداً وتتسبب بحروق. يجب الإشراف بشكل مستمر عند وجود أطفال وأشخاص عرضة للخطر.
- يمكن استخدام هذا الجهاز من قبل الأطفال الذين يبلغون 8 سنوات من العمر وما فوق والأشخاص الذين يعانون نقصاً في القدرات الجسدية أو الحسية أو العقلية أو أولئك الذين تنقصهم الخبرة أو المعرفة، في حال تم الإشراف عليهم أو إعطاؤهم إرشادات تتعلق باستخدام الجهاز بطريقة آمنة وإذا كانوا يفهمون المخاطر المرتبطة به.
- يجب إبقاء الجهاز بعيداً عن الأطفال دون عمر 3 سنوات ما لم يتم الإشراف عليهم بشكل مستمر.
- يمنع الأطفال من اللعب بالجهاز.
- لا يجوز للأطفال تنظيف الجهاز أو صيانته من دون مراقبة.
- عندما يعمل الجهاز في وضع التسخين، سترتفع درجة حرارة السطح. لا تلمس مخرج الهواء تفادياً للتعرض لحروق.
- لحد من خطر نشوب حريق، أبق الأقمشة والسائير ومفروشات السرير وأي مواد أخرى قابلة للاشتعال على مسافة متر واحد على الأقل من مخرج الهواء. لا تعرض مدخل/مخرج الهواء للانسداد، مثلاً، من خلال وضع أغراض على مخرج الهواء أو أمام مدخله.

- لا تدخل أصابعك أو الأعواد أو أي أجسام أخرى في الآلة تفادياً لحدوث صدمة كهربائية أو التعرض لأي إصابة جسدية أو نشوب حريق.
- يحتوي الجهاز على مكوّن تسخين. لا تستخدم الجهاز بالقرب من الأجهزة التي تعمل على الغاز أو المواقد.
- لا ترش أي مواد قابلة للاشتعال، مثل مبيدات الحشرات أو العطور بالقرب من الجهاز.
- لا تستخدم الجهاز في حال لاحظت آثار ضرر مرئية فيه أو في القابس أو سلك الطاقة.
- لا تستخدم هذا الجهاز في حال تم إسقاطه.
- إذا كان سلك الطاقة تالفاً، يجب استبداله من قبل Philips أو مركز خدمة معتمد من Philips أو أشخاص مؤهلين تفادياً لحدوث أي خطر.

تنبيه

- لا تستخدم سوى الفلتر الأصلي من Philips، وإلا سيتعذر ضمان أداء التصفية.
- يجب عدم وضع الجهاز تحت مخرج المآخذ مباشرة.
- قم بتوصيله بالمأخذ الموجود على الحائط فقط ولا تستخدم سلك تمديد.
- صّح الجهاز واستخدمه دائماً على سطح جاف ومستقر وأفقي.
- لا تستخدم الجهاز في أماكن عالية الرطوبة مثل الحمام أو المطبخ أو المرحاض أو حوض السباحة أو أي بيئة خارجية.
- لا تجلس أو تقف على الجهاز. لا تطرق على الجهاز. لا تضع أي أغراض على سطح الجهاز.
- افصل الجهاز دائماً عن مصدر الطاقة عندما تريد نقله أو تنظيفه أو استبدال الفلتر أو إجراء عمليات صيانة أخرى.
- أبق الفلتر داخل الجهاز دائماً عند تشغيله.
- تتراوح درجة حرارة تشغيل الجهاز (درجة الحرارة المحيطة) ما بين 10- درجات مئوية و40 درجة مئوية. سيتوقف عن التشغيل في حال الخروج عن نطاق درجات الحرارة الموصى بها.
- هذا الجهاز معدّ للاستخدام المنزلي فقط ضمن شروط تشغيل عادية.



© 2021 Koninklijke Philips N.V.
All rights reserved.
3000 063 30342

