

PHILIPS

เครื่องฟอกอากาศ

AC2220



ยินดีต้อนรับ
เริ่มใช้งานเลย!



home.id/welcome



การลงทะเบียนและ
สิทธิ์ประโยชน์



ดาวน์โหลดแอป



คู่มือดิจิทัล

Contents

1	Important	2
	Safety	2
	Electromagnetic fields (EMF)	3
	Recycling	3
2	Your air purifier	4
	Product overview	4
	Controls overview	5
3	Getting started	6
	Installing the filter	6
	Connecting power	6
	Understanding Wi-Fi indicator	7
	Wi-Fi connection	7
4	Using the air purifier	8
	Understanding the air quality light	8
	Turning on and off	8
	Changing the mode setting	9
	Using the light function	10
	Setting the child lock	11
5	Cleaning and maintenance	11
	Cleaning schedule	11
	Cleaning the body of the air purifier	11
	Cleaning the particle sensor	11
	Cleaning the filter	12
	Replacing the filter	13
	Filter reset	16
6	Storage	16
7	Troubleshooting	17
8	Warranty and support	18
	Order parts or accessories	18

1 Important

Safety

Read this user manual carefully before you use the appliance, and save it for future reference. To ensure the best performance, kindly suggest the firmware of your purifier is upgraded to the latest version. You can do this upgrade via the Air+ app.

Danger

- Do not let any liquid or flammable detergent enter the appliance, to avoid electric shock and/or a fire hazard.
- Do not spray any flammable materials such as insecticides or fragrance around the appliance.

Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips, or similarly qualified persons in order to avoid a hazard.
- Do not use the appliance if the plug, the power cord, or the appliance itself is damaged.
- Only to be used together with the adaptor provided with the appliance.
- This appliance can be used by children aged from 8 years and above under supervision.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not block the air inlet and outlet, e.g. by placing items on the air outlet or in front of the air inlet.
- Make sure that foreign objects do not fall into the appliance through the air outlet.
- Standard WiFi interface based on 802.11b/g/n/ax at 2.4GHz with a maximum output power of 72mW EIRP.
- Bluetooth version 5.2 (LE) at frequency 2.4 GHz with RF output less than 10mW EIRP.
- We recommend people who are allergic to dust, pollen, pets or mold, not to replace filters by themselves or to take protective measures, such as mask and gloves.

Caution

- This appliance is not a substitute for proper ventilation, regular vacuum cleaning, or use of an extractor hood or fan while cooking.
- Always place and use the appliance on a dry, stable, level, and horizontal surface.
- Leave at least 20cm free space around the appliance and leave at least 30cm free space above the appliance.
- Do not sit or stand on the appliance. Do not place anything on top of the appliance.
- Do not place the appliance directly below an air conditioner to prevent condensation from dripping onto the appliance.
- Only use the original Philips filters specially intended for this appliance. Do not use any other filters.
- Combustion of the filter may cause irreversible human hazard and/or jeopardize other lives. Do not use the filter as fuel or for similar purpose.
- Avoid knocking against the appliance (the air inlet and outlet in particular) with hard objects.
- Do not insert your fingers or objects into the air outlet or the air inlet to prevent physical injury or malfunctioning of the appliance.
- Do not use this appliance when you have used indoor smoke-type insect repellents or in places with oily residues, burning incense, or chemical fumes.
- Do not use the appliance near gas appliances, heating devices or fireplaces.
- Always unplug the appliance when you want to move, clean appliance, replace the filter or carry out maintenance.

- The appliance is only intended for household use under normal operating conditions.
 - Do not use the appliance in wet surroundings or in surroundings with high humidity or high ambient temperatures, such as the bathroom, or in a room with major temperature changes.
 - The appliance does not remove carbon monoxide (CO) or radon (Rn). It cannot be used as a safety device in case of accidents with combustion processes and hazardous chemicals.
-

Electromagnetic fields (EMF)

This appliance complies with the applicable standards and regulations regarding exposure to electromagnetic fields.

Recycling


Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

2 Your air purifier


Congratulations on your purchase, and welcome to Philips!
To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Product overview



A	Control panel	D	Filter (FY2200)
B	Air outlet	E	Base
C	Air quality sensor	F	Adapter (KA3601A-2401500TH)

Controls overview



Control buttons

	Power on/off		Mode switch button/WiFi reset button (long press 3 seconds)
	Light function button (short press)/Child lock button (long press 3 seconds)		Filter cleaning/replacement reset

Display panel

PM2.5	PM2.5 display		App-operated mode
	Child lock indicator		Auto mode
	Sleep mode		Medium mode
	Turbo speed		Filter cleaning alert
	Filter replament alert		

Note:

- The light sensor is located beneath the power button. Please ensure that it is not obstructed by any other objects.


3 Getting started

Installing the filter


Remove all packaging of the filter before first use.

Note: Make sure the air purifier is unplugged from the electrical outlet before installing the filter.


- 1 Turn the appliance upside down.




- 2 Rotate the base anti-clockwise to remove it from the appliance. Pull the filter out from the appliance.



- 3 Remove all packaging materials of the air purification filter.



- 4 Put the filter back into the appliance. Ensure the filter is level and aligned with the base (of the appliance). Reattach the base and rotate it clockwise to fasten the base.




Connecting power

Caution: Risk of electric shock! When you unplug the adaptor, always pull the plug from the socket. Never pull the cord.

Connect the power adapter to:

- First, the appliance.
- Then, the wall outlet.



Understanding Wi-Fi indicator

Wi-Fi icon status	Wi-Fi connection status
Blinking in orange	Connecting to the smartphone
Stable in orange	Connected to the smartphone
Blinking in white	Connecting to the server
Stable in white	Connected to the server
Off	Wi-Fi function disabled


Wi-Fi connection

Setting up the Wi-Fi connection for the first time


- 1 Download and install the Philips “Air+” app from the **App Store** or **Google Play**.



- 2 Put the adapter of the purifier in the power socket and press  to turn on the air purifier.
↳ The Wi-Fi indicator  blinks orange for the first time.



- 3 Make sure that your smartphone or tablet is successfully connected to your Wi-Fi network.



Note:

- Enable the Bluetooth feature on your smartphone to ensure smooth pairing.
- Please ensure your smartphone is connected to a 2.4GHz (home) Wi-Fi network instead of a 5GHz Wi-Fi network or public Wi-Fi. For a successful pairing, we suggest turning off your mobile data before initiating the pairing process.

- 4 Launch the “Air+” app and click on “Connect a New Device” or press the “+” button on the top of the screen. Follow the onscreen instructions to connect the air purifier to your network.




Note:

- This instruction is only valid when the air purifier is being set up for the first time. If the network has changed or the setup needs to be performed again, see Chapter “Reset the Wi-Fi connection” on page 8.
- If you want to connect more than one air purifier to your smartphone or tablet, you have to do this one by one.
- Make sure that the distance between your smartphone or tablet and the air purifier is less than 10 m without any obstructions.

Reset the Wi-Fi connection

Note:

- Reset the Wi-Fi connection when your default network has changed.
- 1 Put the plug of the air purifier in the power socket and press  to turn on the air purifier.
 - 2 Touch and hold  for 3 seconds until you hear a beep.
 - ↳ The air purifier goes to pairing mode.
 - ↳ The Wi-Fi indicator  blinks orange.



- 3 Follow steps 3-4 in “Setting up the Wi-Fi connection for the first time” section.

4 Using the air purifier

Understanding the air quality light

Once turned on, the air purifier will start scanning the air quality. After approximately 30 seconds, the particle sensor selects the color that corresponds to the surrounding air quality of airborne particles.

The color of the air quality light is determined by the PM2.5 reading.

PM2.5

AeraSense sensing technology accurately detects and quickly responds to even the slightest particle change in the air. It provides you with reassurance with realtime PM2.5 feedback. Most of the indoor air pollutants fall under PM2.5 – which refers to airborne particle pollutants smaller than 2.5 micrometers. Common indoor sources of fine particles are tobacco smoke, cooking, burning candles. Some airborne bacteria and the smallest mold spores, pet allergen and dust mite allergen particles also fall under PM2.5.


PM2.5 level	Air quality color	Air quality level
≤12	Blue	Good
13-35	Blue-purple	Fair
36-55	Purple-red	Poor
>55	Red	Very poor

Turning on and off

Note:

- For optimum purification performance, close doors and windows.
- Avoid foreign objects (such as curtains) from falling into or obstructing the air inlet or air outlet.

- 1 Put the plug of the air purifier in the power socket.



- 2 Press the  button to turn on the purifier.
 - ↳ The purifier beeps.
 - ↳ The "---" displays on the screen during warming up. Then the air purifier shows the PM2.5 level after measuring the air quality.
 - ↳ The air purifier operates in the Auto mode with PM2.5 displayed on the screen.



- 3 Press the  again to turn off the purifier.


Note: If the air purifier stays connected to the electrical outlet after turning OFF, the air purifier will operate under the previous settings when turned ON again.

Changing the mode setting


You can press the  button to select the Auto mode (), the sleep mode (), the medium mode (), or the Turbo mode (.

Additional operating modes () can be selected in the Air+ app.


- **Auto mode:** The appliance automatically adjusts the fan speed in accordance with the ambient air quality.




- **Sleep mode:** The appliance operates quietly at a low speed. After 3 seconds, the display lights turn off.




- **Medium mode:** The appliance operates on a medium mode.



- **Turbo speed:** The appliance operates on the highest speed.



- **App-operated mode:** The appliance is operating a mode that is only available through the app, such as additional manual fan speeds or other modes that were customized in the app.



- **Note:** The app-operated mode is available ONLY through the app after the Wi-Fi connection is successful.


Using the light function

With the light sensor, the control panel can automatically turn on, turn off or dim according to the ambient light.


The control panel will be off or dim when the ambient light is dark. You can press any button to wake up all lights. Then, if there is no further operation, all lights will be off or dim again to match with the ambient light.

You can press the  button to turn on air quality light, ambient light or turn off all lights and the control panel.


- 1 The purifier will turn on the air quality light by default. The air quality ring will change color based on the ambient air quality.



- 2 Press the  button to switch to the ambient light mode. Tailor the brightness and color of the cozy light in the Air+ app.




- 3 You can press the  button to turn off all lights and the control panel. Press the  button again to wake up all lights.




Setting the child lock

- 1 You can press and hold the  button for 3 seconds to activate the child lock.
↳ The  displays on the screen.



- 2 Press and hold the  button for 3 seconds to deactivate the child lock.
↳ The  disappears from the screen.



5 Cleaning and maintenance

Note:

- Always unplug the appliance before you clean it.
- Never immerse the appliance in water or any other liquid.
- Never use abrasive, aggressive, or flammable cleaning agents such as bleach or alcohol to clean any part of the appliance.
- Never use any liquids (including water) to clean the filter.
- Do not attempt to clean the particle sensor with a vacuum cleaner.

Cleaning schedule

Frequency	Cleaning method
When necessary	Wipe the plastic part of the appliance with a soft, dry cloth
	Clean the air outlet cover
Every two months	Clean the particle sensor with a dry cotton swab
The  displays on the screen.	Clean the surface of the filter

Cleaning the body of the air purifier

Regularly clean the inside and outside of the air purifier to prevent dust from collecting.

- Use a soft, dry cloth to clean both the interior and exterior of the air purifier and the air outlet.
- The air outlet can also be cleaned with a dry, soft cloth.


Cleaning the particle sensor

Clean the particle sensor every 2 months for optimal functioning of the appliance.

Note:

- If the air purifier is used in a dusty environment, it may need to be cleaned more often.
- If the humidity level in the room is very high, condensation may develop on the particle sensor and the air quality light may indicate a poorer air quality even though the air quality is actually good. If this occurs, clean the particle sensor.


- 1 Switch off the air purifier and unplug from the power socket.



- 2 Open the air quality sensor cover.



- 3 Clean the particle sensor with a damp cotton swab. Dry all parts thoroughly with a dry cotton swab.




- 4 Close the air quality sensor.



Cleaning the filter


When the filter cleaning alert  displays on the screen, clean the surface of the filter with a vacuum cleaner.




Note:

- We recommend people who are allergic to dust, pollen, pets or mold, not to replace filters by themselves or to take protective measures, such as wearing a mask and gloves.


- 1 Switch off the appliance and unplug from the power socket




- 2 Use a cloth, or a vacuum cleaner to clean the filter.




- 3 Put the filter back into the appliance. Ensure the filter is level and aligned with the base (of the appliance). Reattach the base and rotate it clockwise to fasten the base.



- 4 Put the adapter of the air purifier in the power socket.




- 5 Press the power button to switch on the appliance.




- 6 Press and hold the  and  button for 3 seconds to reset the filter cleaning time.
- ↳ You can also reset the filter cleaning time via the Air+ app.

- ↳ After the reset is successful, the filter cleaning alert disappears from the screen.



- 7 Wash your hands thoroughly after cleaning the filter.



Replacing the filter

Understanding the healthy protection lock

This air purifier is equipped with a filter replacement indicator to make sure that the air purification filter is in optimal condition when the air purifier is operating. When the filter needs to be replaced, the filter replacement alert  lights up red.


If the filter is not replaced in time, the air purifier will stop operating and automatically lock to protect the air quality in the room. Replace the filter as soon as possible.

Replacing the filter


Note:

- The filter is not washable or reusable.
- Always turn off the purifier and unplug from the electrical outlet before replacing the filter.
- We recommend people who are allergic to dust, pollen, pets or mold, not to replace filters by themselves or to take protective measures, such as wearing a mask and gloves.
- For installation guidance, please refer to the manual included in the filter box.


When the filter replacement alert  lights up, replace the filter (FY2200).




- 1 Switch off the air purifier and unplug from the power socket.




- 2 Turn the appliance upside down.




- 3 Rotate the base anti-clockwise to remove it from the appliance. Pull the filter out from the appliance.




- 4 Discard the used filter.




- 5 Remove all packaging materials of the new filter.




- 6 Put the filter back into the appliance. Ensure the filter is level and aligned with the base (of the appliance). Reattach the base and rotate it clockwise to fasten the base.




- 7 Put the adapter of the air purifier in the power socket.



- 8 Press the power button to switch on the appliance.




- 9 Press and hold the  and  button for 3 seconds to reset the filter lifetime counter.



- ↳ You can also reset the filter replacement time via the Air+ app.
- ↳ After the reset is successful, the filter replacing alert disappears from the screen.


- 10 Wash your hands thoroughly after replacing the filter.




Filter reset

You can replace the filter even before the filter replacement alert () displays on the screen. After replacing a filter, you need to reset the filter lifetime counter manually.


- 1 Press the power button to turn off the purifier, and unplug the appliance.



- 2 Make sure the appliance is completely unplugged, and then put the power plug in the power socket.



- 3 Within 15 seconds after power on, press and hold the  and  button for 3 seconds to reset the filter lifetime counter.



6 Storage

- 1 Turn off the air purifier and unplug from the power socket.
- 2 Clean the appliance, particle sensor and the surface of the filter (see chapter "Cleaning and maintenance").
- 3 Let all parts air dry thoroughly before storing.
- 4 Wrap the filter in air tight plastic bags.
- 5 Store the air purifier and filter in a cool, dry location.
- 6 Always thoroughly wash your hands after handling the filter.

7 Troubleshooting

This chapter summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Center in your country.

Problem	Possible solution
The appliance does not work properly.	• The filter replacement alert has been on continuously but you have not replaced the corresponding filter. As a result, the appliance is now locked. In this case, replace the filter and long press  and  to reset the filter lifetime counter.
The airflow that comes out of the air outlet is significantly weaker than before.	• The surface of the filter is dirty. Clean the surface of the filter (see the chapter "Cleaning and maintenance").
The air quality does not improve, even though the appliance has been operating for a long time.	• Check if the packing material is removed from the filter. • The filter has not been placed in the appliance. Make sure that the filter (FY2200) is properly installed. • The particle sensor is wet. The humidity level in your room is high and causes condensation. Make sure that the particle sensor is clean and dry (see the chapter "Cleaning and maintenance"). • Room size is large or the outdoor air quality is poor. For optimum purification performance, please close the doors and windows when operating the air purifier. • There are indoor pollution sources. For instances, smoking, cooking, incense, perfume or alcohol. • Filter reaches the end of life. Replace the filter with a new one.
The color of the air quality light always stays the same.	• The particle sensor is dirty. Clean the particle sensor (see the chapter "Cleaning and maintenance").
The appliance produces a strange smell.	• The first few times you use the appliance, it may produce a plastic smell. This is normal. However, if the appliance produces a burnt smell even if removing filters, contact your Philips dealer or an authorized Philips service center. The filter may produce smell after being used for a while because of the absorption of indoor gases. It's recommended that you reactivate the filter by putting it in direct sunlight for repeated use. If odor still exists, replace the filter.
The appliance is extra loud.	• It's normal if the appliance runs at the Turbo mode. • In the Auto mode, if the appliance is too loud, maybe the appliance runs at high speed because air quality becomes worse, or your personalized setting in App triggers a higher fan speed. You can choose the Sleep mode, or change the settings in the App. • If there is abnormal sound, contact the Consumer Care Center in your country. • If anything drops into the air outlet, it may also cause abnormal loud sound. Immediate turn off appliance, turn appliance upside down, to get foreign objectives out of appliance.

Problem	Possible solution
The appliance still indicates that I need to replace a filter, but I already did.	Perhaps you did not reset the filter lifetime counter. Switch on the appliance. Then press and hold the  and  for 3 seconds.
Error code "E1" displays on the screen.	The motor has a malfunctions. Contact the Consumer Care Center in your country.
The Wi-Fi setup is not successful.	- If the router your purifier is connected to is dual – band and currently it is not connecting to a 2.4GHz network, please switch to another band of the same router (2.4GHz) and try to pair your purifier again. 5GHz networks are not supported. - Web authentication networks are not supported. - Check if the purifier is within range of the Wi-Fi router. You can try to locate the air purifier closer to the Wi-Fi router. - Check if the network name is correct. The network name is case-sensitive. - Check if the Wi-Fi password is correct. The password is case-sensitive. - Retry the setup with the instructions in section "Reset the Wi-Fi connection". - The Wi-Fi connectivity can be interrupted by electromagnetic or other interferences. Keep the appliance away from other electronic devices that may cause interferences. - Check if the mobile device is in airplane mode. Make sure to have the airplane mode deactivated when connecting to the Wi-Fi network. - Consult the help section in the App for extensive and up-to-date troubleshooting tips.

8 Warranty and support

Versuni offers a two-year warranty after purchase on this product. This warranty is not valid if a defect is due to incorrect use or poor maintenance. Our warranty does not affect your rights under law as a consumer. For more information or for invoking the warranty, please visit our website www.philips.com/support.

Order parts or accessories

If you have to replace a part or want to purchase an additional part, go to your Philips dealer or visit www.philips.com/support.

If you have problems obtaining the parts, please contact the Philips Consumer Care Center in your country.

สารบัญ

1	ข้อสำคัญ	20
	ความปลอดภัย	20
	คลื่นแม่เหล็กไฟฟ้า (EMF)	22
	การรีไซเคิล	22
2	เครื่องฟอกอากาศของคุณ	23
	ภาพรวมของผลิตภัณฑ์	23
	ภาพรวมของการควบคุม	24
3	การเริ่มต้นใช้งาน	25
	การติดตั้งแผ่นกรอง	25
	ต่อสายไฟ	25
	ทำความเข้าใจกับไฟสัญญาณ Wi-Fi	26
	การเชื่อมต่อ Wi-Fi	26
4	การใช้เครื่องฟอกอากาศ	27
	ทำความเข้าใจไฟแสดงคุณภาพอากาศ	27
	การเปิดและปิดเครื่อง	28
	การเปลี่ยนการตั้งค่าโหมดการตั้งค่า	29
	การใช้ฟังก์ชันแสง	30
	การตั้งค่าการล็อกกันเปิด	30
5	การทำความสะอาดและดูแลรักษา	31
	กำหนดการทำความสะอาด	31
	การทำความสะอาดตัวเครื่องฟอกอากาศ	31
	การทำความสะอาดเซนเซอร์ตรวจจับอนุภาค	31
	การทำความสะอาดแผ่นกรอง	32
	การเปลี่ยนแผ่นกรอง	34
	รีเซ็ตแผ่นกรอง	36
6	การจัดเก็บ	37
7	การแก้ไขปัญหา	38
8	การรับประกันและการสนับสนุน	41
	สั่งซื้อชิ้นส่วนหรืออุปกรณ์เสริม	41

1 ข้อสำคัญ

ความปลอดภัย

โปรดอ่านคู่มือการใช้งานนี้อย่างละเอียดก่อนใช้งานเครื่อง และเก็บไว้สำหรับการอ้างอิงในอนาคต เพื่อให้มั่นใจถึงประสิทธิภาพการทำงานที่ดีที่สุด โปรดอัปเดตเฟิร์มแวร์ของเครื่อง ฟล็กอากาศของคุณให้เป็นเวอร์ชันล่าสุด คุณสามารถทำการอัปเดตนี้ได้ผ่านแอป Air+

อันตราย

- ห้ามไม่ให้ของเหลวอื่นๆ หรือน้ำยาที่ติดไฟได้เข้าเครื่องเป็นอันตราย เพื่อหลีกเลี่ยงไฟฟ้าช็อตและ/หรือการเกิดเพลิงไหม้
- ห้ามพ่นวัสดุที่ติดไฟง่าย เช่น ยาฆ่าแมลง หรือน้ำหอมบริเวณใกล้กับตัวเครื่อง

คำเตือน

- ก่อนใช้งานโปรดตรวจสอบแรงดันไฟที่ระบุบนผลิตภัณฑ์ว่าตรงกับแรงดันไฟที่ใช้ภายในบ้านหรือไม่
- หากสายไฟชำรุด คุณต้องให้ช่างผู้ชำนาญของ Philips ศูนย์บริการที่ได้รับอนุญาตจาก Philips หรือผู้ที่ผ่านการฝึกอบรม ดำเนินการเปลี่ยนให้เพื่อหลีกเลี่ยงอันตรายที่อาจเกิดขึ้น
- ห้ามใช้งานเครื่องหากปลั๊กไฟ สายไฟ หรือตัวเครื่องเกิดการชำรุด
- ใช้ร่วมกับอะแดปเตอร์ที่มาพร้อมกับเครื่องเท่านั้น
- เด็กที่มีอายุตั้งแต่ 8 ปีขึ้นไปสามารถใช้งานเครื่องใช้ไฟฟ้านี้ได้ โดยต้องมีผู้ดูแลควบคุมอย่างใกล้ชิด
- ผู้ที่มีสภาพร่างกายไม่สมบูรณ์ ประสาทสัมผัสไม่สมบูรณ์หรือสภาพจิตใจไม่ปกติ หรือขาดประสบการณ์และความรู้ความเข้าใจ สามารถใช้เครื่องนี้ได้ หากอยู่ในการควบคุมดูแลหรือได้รับคำแนะนำในการใช้งานที่ปลอดภัยและเข้าใจถึงอันตรายที่เกี่ยวข้องในการใช้งาน
- ห้ามเด็กเล่นเครื่อง
- ห้ามไม่ให้เด็กทำความสะอาดและดูแลรักษาเครื่องโดยปราศจากการควบคุมดูแล
- ห้ามปิดกั้นช่องอากาศเข้าและออก เช่น โดยการวางสิ่งของไว้ที่ช่องระบายอากาศหรือด้านหน้าช่องลมเข้า
- ตรวจสอบให้แน่ใจว่าไม่มีวัตถุแปลกปลอมหล่นลงไปในเครื่องผ่านทางลมออก
- อินเทอร์เน็ต WiFi มาตรฐานที่ใช้ 802.11b/g/n/ax ที่ 2.4GHz พร้อมกำลังเอาต์พุตสูงสุด 72mW EIRP
- Bluetooth เวอร์ชัน 5.2 (LE) ที่ความถี่ 2.4 GHz พร้อมเอาต์พุต RF น้อยกว่า 10mW EIRP

- เราแนะนำให้ผู้ที่แพ้ฝุ่น ละอองเกสร สัตว์เลี้ยง หรือเชื้อรา ไม่ควรเปลี่ยนแผ่นกรองด้วยตนเองหรือใช้มาตรการป้องกัน เช่น หน้ากากและถุงมือ

ข้อควรระวัง

- อุปกรณ์นี้ไม่ใช่อุปกรณ์ทดแทนการถ่ายเทอากาศให้ดีขึ้น การทำความสะอาดด้วยระบบสูญญากาศ หรือการใช้พัดลมดูดอากาศขณะปรุงอาหาร
- วางและใช้งานอุปกรณ์บนพื้นที่แห้ง มั่นคง เรียบ และมีพื้นผิวในแนวราบเสมอกันเสมอ
- เว้นระยะด้านหลังและทั้งสองด้านของเครื่องอย่างน้อย 20 ซม. และเว้นระยะเหนือเครื่อง 30 ซม.
- ห้ามนั่งหรือยืนบนเครื่อง ห้ามวางสิ่งของใดๆ ที่ด้านบนของเครื่อง
- ห้ามวางเครื่องไว้ใต้เครื่องปรับอากาศ ทั้งนี้เพื่อป้องกันการกลั่นตัวเป็นหยดน้ำหยดลงบนตัวเครื่อง
- โปรดใช้เฉพาะแผ่นกรองแท้ของ Philips ที่ผลิตมาเพื่อใช้งานกับเครื่องนี้เท่านั้น อย่าใช้แผ่นกรองอื่น
- การเผาไหม้ของแผ่นกรองอาจทำให้เกิดอันตรายที่ไม่สามารถแก้ไขได้ต่อชีวิตมนุษย์ และ/หรือเป็นอันตรายต่อสิ่งมีชีวิตอื่น ห้ามใช้แผ่นกรองเป็นเชื้อเพลิงหรือใช้เพื่อวัตถุประสงค์ที่คล้ายกัน
- หลีกเลี่ยงการกระแทกเครื่อง (โดยเฉพาะอย่างยิ่งทางลมเข้าและออก) ด้วยวัตถุที่มีความแข็ง
- ห้ามสอดนิ้วของคุณ หรือวัตถุอื่นๆ เข้าไปในทางลมออก หรือทางลมเข้า เพื่อป้องกันการบาดเจ็บทางร่างกาย หรือป้องกันเครื่องขัดข้อง
- ห้ามใช้เครื่องนี้หากคุณมีการใช้ยาไอบuprofen แบบควันทายในอาคาร หรือห้ามใช้ในสถานที่ที่มีเศษตกค้างที่มีลักษณะเหมือนน้ำมัน บริเวณที่มีการจัดรูป หรือควันทของสารเคมี
- ห้ามใช้งานใกล้กับอุปกรณ์ที่เกี่ยวข้องกับก๊าซเชื้อเพลิง อุปกรณ์ให้ความร้อน หรือเตาไฟ
- ถอดปลั๊กอุปกรณ์ออกเสมอเมื่อคุณต้องการเคลื่อนย้าย ทำความสะอาดเครื่อง เปลี่ยนแผ่นกรอง หรือทำการบำรุงรักษาอื่นๆ
- เครื่องนี้เหมาะสำหรับการใช้งานในครัวเรือน ภายใต้สภาพแวดล้อมการทำงานที่ปกติเท่านั้น
- ห้ามใช้งานเครื่องนี้ในที่เปียกชื้น หรือในที่ที่มีความชื้นสูง หรือในที่ที่มีอุณหภูมิสูง เช่น ห้องน้ำหรือในห้องที่มีการเปลี่ยนแปลงของอุณหภูมิสูง

- เครื่องจะไม่ขจัดคาร์บอนมอนอกไซด์ (CO) หรือเรดอน (Rn) ไม่ควรใช้เครื่องเป็นอุปกรณ์ความปลอดภัยในกรณีที่เกิดอุบัติเหตุที่มีความเกี่ยวข้องกับการเผาไหม้และสารเคมีที่เป็นอันตราย

คลื่นแม่เหล็กไฟฟ้า (EMF)

เครื่องนี้สอดคล้องตามมาตรฐานและกฎข้อบังคับที่บังคับใช้เกี่ยวกับการได้รับคลื่นแม่เหล็กไฟฟ้า


การรีไซเคิล

ห้ามทิ้งผลิตภัณฑ์นี้รวมกับขยะในครัวเรือนทั่วไปเมื่อเครื่องหมดอายุการใช้งานแล้ว แต่ควรนำไปทิ้งที่จุดรวบรวมขยะเพื่อการนำกลับไปใช้ใหม่ เพื่อช่วยรักษาภาวะสิ่งแวดล้อมที่ดี ปฏิบัติตามกฎระเบียบของประเทศของคุณสำหรับการแยกเก็บผลิตภัณฑ์ไฟฟ้าและอิเล็กทรอนิกส์ การกำจัดอย่างถูกต้องช่วยป้องกันผลสืบเนื่องทางลบที่อาจเกิดขึ้นกับสิ่งแวดล้อมและสุขภาพของมนุษย์

2 เครื่องฟอกอากาศของคุณ


ขอแสดงความยินดีที่คุณเลือกซื้อผลิตภัณฑ์ของเรา และยินดีต้อนรับสู่ Philips เพื่อรับสิทธิประโยชน์จากบริการที่ Philips มอบให้อย่างเต็มที่ โปรดลงทะเบียนผลิตภัณฑ์ของคุณที่ www.philips.com/welcome

ภาพรวมของผลิตภัณฑ์



A	แผงควบคุม	D	ตัวกรอง (FY2200)
B	ทางลมออก	E	ฐาน
C	เซนเซอร์ตรวจวัดคุณภาพอากาศ	F	อะแดปเตอร์ (KA3601A-2401500TH)

ภาพรวมของการควบคุม



ปุ่มควบคุม

	ปุ่มเปิดปิดการทำงาน		ปุ่มเปลี่ยนโหมด/ปุ่มรีเซ็ต Wi-Fi (กดค้าง 3 วินาที)
	ปุ่มควบคุมไฟ (กดสั้นๆ)/ปุ่มล็อคป้องกันเด็ก (กดค้าง 3 วินาที)		รีเซ็ตการทำความสะอาด/เปลี่ยนแผ่นกรอง

แผงการแสดงผล

PM2.5	การแสดงผล PM2.5		โหมดการทำงานของแอป
	สัญลักษณ์แสดงระบบป้องกันเด็ก		โหมดอัตโนมัติ
	โหมดนอนหลับ		โหมดปานกลาง
	ความเร็วเทอร์โบ		การแจ้งเตือนการทำความสะอาดแผ่นกรอง
	การแจ้งเตือนการเปลี่ยนแผ่นกรอง		

หมายเหตุ:

- เซ็นเซอร์วัดแสงอยู่ที่ปุ่มเปิด/ปิด โปรดตรวจสอบว่าไม่มีวัตถุอื่นกีดขวาง


3 การเริ่มต้นใช้งาน

การติดตั้งแผ่นกรอง


แกะบรรจุภัณฑ์ทั้งหมดของแผ่นกรองออกก่อนใช้งานครั้งแรก

หมายเหตุ: ตรวจสอบให้แน่ใจว่าได้ถอดปลั๊กเครื่องฟอกอากาศออกจากเต้าเสียบก่อนติดตั้งแผ่นกรอง


- 1 ปลั๊กเครื่อง Airfryer ควาลง




- 2 หมุนฐานทวนเข็มนาฬิกาเพื่อนำออกจากตัวเครื่อง ดังแผ่นกรองออกจากตัวเครื่อง



- 3 แกะบรรจุภัณฑ์ทั้งหมดของแผ่นกรองเครื่องฟอกอากาศ



- 4 ใส่แผ่นกรองกลับเข้าไปในเครื่อง ประกอบฐานกลับเข้าไปใหม่แล้วหมุนตามเข็มนาฬิกาเพื่อให้ฐานแน่น




ต่อสายไฟ

คำเตือน: ระวังไฟดูด เมื่อคุณถอดปลั๊กอะแดปเตอร์ไฟฟ้า ให้ดึงที่ตัวปลั๊กจากช่องเสียบเสมอ ห้ามดึงที่สายไฟ

เชื่อมต่ออะแดปเตอร์ไฟฟ้าเข้ากับ:

- เริ่มจากเครื่องก่อน
- จากนั้นจึงต่อเข้ากับเต้าเสียบบนผนัง



ทำความเข้าใจกับไฟ สัญญาณ Wi-Fi

สถานะไอคอน Wi-Fi	สถานะการเชื่อมต่อ Wi-Fi
กระพริบเป็นสีส้ม	กำลังเชื่อมต่อกับสมาร์ทโฟน
ไฟสีส้มติดสว่าง	เชื่อมต่อกับสมาร์ทโฟนแล้ว
กระพริบเป็นสีขาว	กำลังเชื่อมต่อกับเซิร์ฟเวอร์
ไฟสีขาวติดสว่าง	เชื่อมต่อกับเซิร์ฟเวอร์แล้ว
ปิด	ปิดการใช้งานฟังก์ชัน Wi-Fi


การเชื่อมต่อ Wi-Fi

การตั้งค่าการเชื่อมต่อ Wi-Fi เป็นครั้งแรก


- 1 ดาวน์โหลดและติดตั้งแอป Philips “Air+” จาก App Store หรือ Google Play



- 2 เสียบปลั๊กของเครื่องฟอกอากาศในช่องเสียบปลั๊กไฟและกด  เพื่อเปิดเครื่องฟอกอากาศ
 - ➔ ไฟแสดงสัญญาณ Wi-Fi  จะกระพริบขึ้นมาเป็นสีส้มเมื่อใช้งานครั้งแรก



- 3 ตรวจสอบให้แน่ใจว่าคุณเชื่อมต่อสมาร์ทโฟนหรือแท็บเล็ตเข้ากับเครือข่าย Wi-Fi สำเร็จ



หมายเหตุ:

- เปิดใช้งานคุณสมบัติ Bluetooth บนสมาร์ทโฟนของคุณเพื่อให้การจับคู่ราบรื่น
- โปรดตรวจสอบว่าสมาร์ทโฟนของคุณเชื่อมต่อกับเครือข่าย Wi-Fi 2.4GHz (ในบ้าน) แทนที่จะเป็นเครือข่าย Wi-Fi 5GHz หรือ Wi-Fi สาธารณะ เพื่อการจับคู่ที่ประสบความสำเร็จ เราขอแนะนำให้ปิดข้อมูลมือถือของคุณก่อนเริ่มกระบวนการจับคู่

4. เปิดใช้แอป **"Air+"** แล้วคลิก **"เชื่อมต่อกับอุปกรณ์ใหม่"** หรือกดปุ่ม **"+"** ที่ด้านบนของหน้าจอ ทำตามคำแนะนำบนหน้าจอเพื่อเชื่อมต่อเครื่องฟอกอากาศเข้ากับเครือข่ายของคุณ



หมายเหตุ:


- สามารถใช้งานคำแนะนำนี้ได้กับเครื่องฟอกอากาศที่ติดตั้งเป็นครั้งแรกเท่านั้น หากมีการเปลี่ยนแปลงเครือข่ายหรือต้องตั้งค่าอีกครั้ง โปรดดูบท "รีเซ็ตการเชื่อมต่อ Wi-Fi" ในหน้า 27
- หากต้องการเชื่อมต่อเครื่องฟอกอากาศเข้ากับอุปกรณ์อัจฉริยะของคุณมากกว่าหนึ่งเครื่อง โปรดปฏิบัติตามขั้นตอนเหล่านี้ทีละขั้นตอน
- ตรวจสอบให้แน่ใจว่าระยะห่างระหว่างสมาร์ทโฟนหรือแท็บเล็ตของคุณอยู่ห่างจากเครื่องฟอกอากาศไม่เกิน 10 เมตร และไม่มีสิ่งกีดขวาง

รีเซ็ตการเชื่อมต่อ Wi-Fi

หมายเหตุ:

- รีเซ็ตการเชื่อมต่อ Wi-Fi เมื่อเครือข่ายเริ่มต้นของคุณมีการเปลี่ยนแปลง
1. เสียบปลั๊กของเครื่องฟอกอากาศในช่องเสียบปลั๊กไฟและกด  เพื่อเปิดเครื่องฟอกอากาศ

2. แตะค้างไว้  เป็นเวลา 3 วินาทีจนกว่าจะได้ยินเสียงบี๊บ
- ➔ เครื่องฟอกอากาศจะเข้าสู่โหมดจับคู่
 - ➔ ไฟแสดงสัญญาณ Wi-Fi  สีส้มจะกะพริบ



3. ปฏิบัติตามขั้นตอนที่ 3-4 ในหัวข้อ **"การตั้งค่าการเชื่อมต่อ Wi-Fi เป็นครั้งแรก"**

4 การใช้เครื่องฟอกอากาศ

ทำความเข้าใจไฟแสดงคุณภาพอากาศ

เมื่อเปิดเครื่องแล้ว เครื่องฟอกอากาศจะเริ่มสแกนคุณภาพอากาศ หลังจากผ่านไปประมาณ 30 วินาที เซนเซอร์ตรวจจับอนุภาคจะเลือกสีเพื่อแสดงถึงคุณภาพอากาศโดยรอบของอนุภาคที่ลอยอยู่ในอากาศ

สีของไฟแสดงคุณภาพอากาศถูกกำหนดโดยการอ่านค่า PM2.5

PM2.5

AeraSense เทคโนโลยีการตรวจสอบสัมพัทธ์ที่ตรวจจับได้อย่างแม่นยำ และตอบสนองกับความเปลี่ยนแปลงของอนุภาคในอากาศเพียงเล็กน้อยได้อย่างรวดเร็ว ซึ่งจะทำให้ความมั่นใจกับคุณด้วยการรายงานผล PM2.5 แบบเรียลไทม์ มลพิษทางอากาศภายในอาคารส่วนใหญ่อยู่ภายใต้ PM2.5 ซึ่งหมายถึงมลพิษของอนุภาคในอากาศที่มีขนาดเล็กกว่า 2.5 ไมครอนเมตร แหล่งที่มาในอาคารของอนุภาคที่พบได้ทั่วไปคือควันบุหรี่, การปรุงอาหาร, เปลวเทียนแบบที่เรียในอากาศและสปอร์ของเชื้อราที่เล็กที่สุด สารก่อภูมิแพ้ในสัตว์เลี้ยง และอนุภาคสารก่อภูมิแพ้ไรฝุ่นก็อยู่ภายใต้ PM2.5


ระดับ PM2.5	สีแสดงคุณภาพอากาศ	ระดับคุณภาพอากาศ
≤12	สีฟ้า	ดี
13-35	น้ำเงิน-ม่วง	กลาง
36-55	ม่วง-แดง	ไม่ดี
>55	สีแดง	แย่มาก

การเปิดและปิดเครื่อง

หมายเหตุ:

- เพื่อประสิทธิภาพการฟอกอากาศที่ดีที่สุด ให้ปิดประตูและหน้าต่าง
- หลีกเลี่ยงไม่ให้วัตถุแปลกปลอม (เช่น ผ้า ม่าน) บดบังหรือกีดขวางช่องรับลมหรือช่องปล่อยลม

- 1 เสียบปลั๊กไฟของเครื่องฟอกอากาศเข้ากับเต้ารับ



- 2 กดปุ่ม  เพื่อเปิดเครื่องฟอกอากาศ
 - ↳ เครื่องฟอกอากาศส่งเสียง 'บีบ'
 - ↳ "---" แสดงขึ้นบนหน้าจอระหว่างการอุ่นเครื่อง จากนั้นเครื่องฟอกอากาศจะแสดงระดับ PM2.5 หลังจากการวัดคุณภาพอากาศ
 - ↳ เครื่องฟอกอากาศทำงานในโหมดอัตโนมัติโดยมีค่า PM2.5 แสดงบนหน้าจอ




- 3 กดปุ่ม  อีกครั้งเพื่อปิดเครื่องฟอกอากาศ

หมายเหตุ: หากเครื่องฟอกอากาศจะยังคงเชื่อมต่อกับเต้าเสียบที่ผนังหลังจากปิดเครื่อง เครื่องฟอกอากาศจะทำงานภายใต้การตั้งค่าก่อนหน้าเมื่อเปิดเครื่องอีกครั้ง


การเปลี่ยนการตั้งค่าโหมดการตั้งค่า

คุณสามารถกดปุ่ม  เพื่อเลือกโหมดอัตโนมัติ () โหมด Sleep () โหมดกลาง () หรือโหมดเทอร์โบ () ได้สามารถเลือกโหมดการทำงาน () เพิ่มเติมได้ในแอป Air+


- **โหมดอัตโนมัติ:** เครื่องจะเลือกความเร็วพัดลมตามคุณภาพอากาศแวดล้อมโดยอัตโนมัติ




- **โหมด Sleep:** เครื่องจะทำงานอย่างเงียบสงบเครื่องจะทำงาน หลังจากผ่านไป 3 วินาที ไฟจอแสดงผลจะดับลง




- **โหมดกลาง:** เครื่องจะทำงานในโหมดระดับกลาง



- **โหมดเทอร์โบ:** เครื่องจะทำงานที่ความเร็วสูงสุด



- **โหมดการทำงานของแอป:** เครื่องกำลังใช้งานโหมดที่ใช้งานได้ผ่านแอปเท่านั้น เช่น ความเร็วพัดลมเพิ่มเติมแบบแมนนวลหรือโหมดอื่นๆ ที่ปรับแต่งในแอป



- **หมายเหตุ:** โหมดการทำงานของแอปจะใช้งานได้ผ่านแอปเท่านั้นหลังจากการเชื่อมต่อ Wi-Fi สำเร็จแล้ว


การใช้ฟังก์ชันแสง

ด้วยเซนเซอร์ตรวจจับแสง แฝงควบคุมสามารถเปิด ปิด หรือหรี่แสงไฟลงอัตโนมัติตามสภาพความสว่างรอบๆ


แฝงควบคุมจะปิดหรือลดความสว่างลงเมื่อความสว่างโดยรอบมืด คุณสามารถกดปุ่มใดก็ได้เพื่อให้แสงไฟทั้งหมดสว่าง จากนั้น หากไม่มีการใช้งานใดๆ ไฟทั้งหมดจะดับหรือลดความสว่างลงอีกครั้งเพื่อให้ตรงกับความต้องการโดยรอบ

คุณสามารถกดปุ่ม **☀** เพื่อเปิดไฟแสดงคุณภาพอากาศ ความสว่างโดยรอบ หรือปิดไฟทั้งหมดและแฝงควบคุม


- 1 เครื่องฟอกอากาศจะเปิดไฟแสดงคุณภาพอากาศโดยอัตโนมัติ วงแหวนแสดงคุณภาพอากาศจะเปลี่ยนสีตามคุณภาพอากาศในสภาพแวดล้อม



- 2 กดปุ่ม **☀** ปุ่มสำหรับสลับไปยังโหมดความสว่างโดยรอบ ปรับแต่งความสว่างและสีของแสงอันอบอุ่นในแอป Air+




- 3 คุณสามารถกดปุ่ม **☀** เพื่อปิดแสงไฟทั้งหมดและแฝงควบคุม กด **☀** ปุ่มอีกครั้งเพื่อให้แสงไฟทั้งหมดสว่าง




การตั้งค่าการล็อกกันเปิด

- 1 กดปุ่ม **☀** ค้างไว้ 3 วินาทีเพื่อเปิดใช้งานระบบล็อกป้องกันเด็ก
→ **🔒** แสดงขึ้นบนหน้าจอ



- 2 กดปุ่ม  ค้างไว้ 3 วินาทีเพื่อปิดใช้งานระบบล็อกป้องกันเด็ก
 ↳  หายไปจากหน้าจอ



5 การทำความสะอาดและดูแลรักษา

หมายเหตุ:

- ถอดปลั๊กออกทุกครั้งก่อนทำความสะอาดเครื่อง
- ห้ามนำเครื่องจุ่มลงในน้ำหรือของเหลวอื่นๆ
- ห้ามใช้สารทำความสะอาดที่มีฤทธิ์กัดกร่อน รุนแรง หรือติดไฟได้ เช่น สารฟอกขาวหรือแอลกอฮอล์ทำความสะอาดส่วนต่างๆ ของเครื่อง
- ห้ามใช้ของเหลวทุกชนิด (รวมถึงน้ำ) ในการทำความสะอาดแผ่นกรอง
- ห้ามทำความสะอาดเซนเซอร์ตรวจจับอนุภาคด้วยเครื่องดูดฝุ่น

กำหนดการทำความสะอาด

ความถี่	วิธีการทำความสะอาด
เมื่อจำเป็น	เช็ดชิ้นส่วนพลาสติกของเครื่องด้วยผ้าที่นุ่มและแห้ง
	ทำความสะอาดฝาครอบทางลมออก
ทุกสองเดือน	ทำความสะอาดเซนเซอร์ตรวจจับอนุภาคด้วยก้านสำลีแห้ง
 แสดงขึ้นบนหน้าจอ	ทำความสะอาดพื้นผิวของแผ่นกรอง

การทำความสะอาดตัวเครื่องฟอกอากาศ

ทำความสะอาดด้านในและด้านนอกของตัวเครื่องฟอกอากาศเป็นประจำเพื่อป้องกันการสะสมของฝุ่น

- ใช้ผ้าแห้งที่อ่อนนุ่มในการทำความสะอาดทั้งด้านในและด้านนอกเครื่องฟอกอากาศและทางลมออก
- สามารถทำความสะอาดทางลมออกด้วยผ้าแห้งที่อ่อนนุ่ม


การทำความสะอาดเซนเซอร์ตรวจจับอนุภาค

ทำความสะอาดเซนเซอร์ตรวจจับอนุภาคทุกๆ 2 เดือน เพื่อประสิทธิภาพการทำงานที่เป็นเยี่ยมของเครื่อง


หมายเหตุ:

- หากใช้งานเครื่องฟอกอากาศในสภาพแวดล้อมที่มีฝุ่นปริมาณมาก อาจต้องทำความสะอาดบ่อยขึ้น
- หากมีระดับความชื้นสูงในห้อง อาจมีไอน้ำกลั่นตัวบนเซนเซอร์ตรวจจับอนุภาค ทำให้เครื่องแสดงค่าว่ามีคุณภาพอากาศแย่ แม้ว่าอากาศจะมีคุณภาพดี หากเกิดเหตุการณ์นี้ขึ้น ให้ทำความสะอาดเซนเซอร์ตรวจจับอนุภาค


- 1 ปิดเครื่องฟอกอากาศและถอดปลั๊กจากช่องเสียบปลั๊กไฟ




- 2 เปิดฝาครอบเซนเซอร์ตรวจวัดคุณภาพอากาศ



- 3 ทำความสะอาดเซนเซอร์ตรวจจับอนุภาคด้วยก้านสำลีหลายๆ เช็ดชิ้นส่วนต่างๆ ด้วยก้านสำลีแห้ง




- 4 ปิดเซนเซอร์ตรวจวัดคุณภาพอากาศ



การทำความสะอาดแผ่นกรอง

เมื่อการแจ้งเตือนการทำความสะอาดแผ่นกรอง ปรากฏขึ้นบนหน้าจอ ให้ทำความสะอาดพื้นผิวของแผ่นกรองด้วยเครื่องดูดฝุ่น




หมายเหตุ:


- เราขอแนะนำผู้ที่แพ้ฝุ่น ละอองเกสร สัตว์เลี้ยง หรือเชื้อรา ไม่ควรเปลี่ยน

แผ่นกรองด้วยตนเองหรือใช้มาตรการป้องกัน เช่น การสวมหน้ากากและถุงมือ


- 1 ปิดเครื่องและถอดปลั๊กจากเต้าเสียบบนผนัง




- 2 ใช้เครื่องดูดฝุ่นในการทำสะอาดแผ่นกรอง




- 3 ใส่แผ่นกรองกลับเข้าไปในเครื่อง ตรวจสอบให้แน่ใจว่าแผ่นกรองอยู่ในแนวเดียวกับฐาน (ของเครื่อง) ประกอบฐานกลับเข้าไปใหม่แล้วหมุนตามเข็มนาฬิกาเพื่อให้ฐานแน่น




- 4 เสียบอะแดปเตอร์ของเครื่องฟอกอากาศเข้ากับปลั๊กไฟ




- 5 กดปุ่มเปิด/ปิดเครื่องเพื่อเปิดสวิตช์เครื่อง



- 6 กดปุ่ม และ ค้างไว้ 3 วินาทีเพื่อรีเซ็ตเวลาทำความสะอาดแผ่นกรอง
 - ➡ คุณยังสามารถรีเซ็ตเวลาทำความสะอาดแผ่นกรองผ่านแอป Air+ ได้อีกด้วย
 - ➡ หลังจากรีเซ็ตสำเร็จ การแจ้งเตือนการทำความสะอาดแผ่นกรองจะหายไปจากหน้าจอ



7 ทำความสะอาดมือของคุณให้ทั่วถึง หลังการทำความสะอาดแผ่นกรอง



การเปลี่ยนแผ่นกรอง

การทำความเข้าใจกับลือค ปกป้องอากาศดี

เครื่องฟอกอากาศนี้มีไฟเตือนให้เปลี่ยน
แผ่นกรอง เพื่อให้แน่ใจว่าแผ่นกรอง
ฟอกอากาศสามารถทำงานได้อย่างเต็ม
ประสิทธิภาพ เมื่อถึงเวลาต้องเปลี่ยนแผ่น
กรอง ไฟแจ้งเตือนการเปลี่ยนแผ่นกรอง
จะเป็นสีแดง


หากไม่เปลี่ยนแผ่นกรองภายในเวลาที่
กำหนด เครื่องฟอกอากาศจะหยุดทำงาน
และจะลือคโดยอัตโนมัติเพื่อปกป้อง
คุณภาพอากาศในห้อง เปลี่ยนแผ่นกรอง
โดยเร็วที่สุด

การเปลี่ยนแผ่นกรอง


หมายเหตุ:

- แผ่นกรองไม่สามารถล้างทำความสะอาดหรือนำกลับมาใช้ใหม่ได้
- ให้ปิดเครื่องฟอกอากาศและถอดปลั๊ก
จากเต้าเสียบไฟบนผนังก่อนเปลี่ยนแผ่น
กรอง


- เราขอแนะนำผู้ที่แพ้ฝุ่น ละอองเกสร
สัตว์เลี้ยง หรือเชื้อรา ไม่ควรเปลี่ยน
แผ่นกรองด้วยตนเองหรือใช้มาตรการ
ป้องกัน เช่น การสวมหน้ากากและถุงมือ
 - สำหรับคำแนะนำในการติดตั้ง โปรดดู
คู่มือที่แนบมาในกล่องแผ่นกรอง
- เมื่อสัญญาณแจ้งเตือนการเปลี่ยนแผ่น
กรอง  สว่างขึ้น ให้เปลี่ยนแผ่นกรอง
(FY2200).




- 1 ปิดเครื่องฟอกอากาศและถอดปลั๊ก
จากช่องเสียบปลั๊กไฟ




- 2 พลิกเครื่อง Airfryer คว่ำลง




- 3 หมุนฐานทวนเข็มนาฬิกาเพื่อนำออก
จากตัวเครื่อง ดังแผ่นกรองออกจาก
ตัวเครื่อง




- 4 ถึงแผ่นกรองที่ใช้แล้ว




- 5 แคะบรรจุก้นที่ทั้งหมดออกจากแผ่น
กรองใหม่




- 6 ใส่แผ่นกรองกลับเข้าไปในเครื่อง
ตรวจสอบให้แน่ใจว่าแผ่นกรองอยู่ในแนว
เดียวกับฐาน (ของเครื่อง) ประกอบ
ฐานกลับเข้าไปใหม่แล้วหมุนตามเข็
มนาฬิกาเพื่อให้ฐานแน่น




- 7 เสียบอะแดปเตอร์ของเครื่องฟอก
อากาศเข้ากับปลั๊กไฟ



- 8 กดปุ่มเปิด/ปิดเครื่องเพื่อเปิดสวิตซ์
เครื่อง




- 9 กดปุ่ม  และ  ค้างไว้ 3 วินาทีเพื่อรีเซ็ตตัวนับอายุการใช้งานของแผ่นกรอง



- ➔ คุณยังสามารถรีเซ็ตเวลาการเปลี่ยนแผ่นกรองผ่านแอป Air+ ได้อีกด้วย
- ➔ หลังจากรีเซ็ตสำเร็จ การแจ้งเตือนการเปลี่ยนแผ่นกรองจะหายไปจากหน้าจอ


- 10 ทำความสะอาดมือของคุณให้ทั่วถึงหลังเปลี่ยนแผ่นกรอง




รีเซ็ตแผ่นกรอง

คุณสามารถเปลี่ยนแผ่นกรองได้ก่อนที่การแจ้งเตือนการเปลี่ยนแผ่นกรอง () จะปรากฏขึ้นบนหน้าจอ หลังจากการเปลี่ยนแผ่นกรอง คุณต้องรีเซ็ตตัวนับอายุการใช้งานแผ่นกรองด้วยตัวเอง


- 1 กดปุ่มเปิด/ปิดเพื่อปิดเครื่องฟอกอากาศ และถอดปลั๊กเครื่องออก



- 2 ตรวจสอบให้แน่ใจว่าเครื่องถูกถอดปลั๊กออกอย่างสมบูรณ์แล้ว จากนั้นเสียบปลั๊กไฟเข้ากับช่องเสียบไฟ



- 3 ภายใน 15 วินาทีหลังจากเปิดเครื่องให้กดปุ่ม  และ  ค้างไว้เป็นเวลา 3 วินาทีเพื่อรีเซ็ตตัวนับอายุการใช้งานแผ่นกรอง



6 การจัดเก็บ

- 1 ปิดเครื่องฟอกอากาศและถอดปลั๊กจากเต้าเสียบบนผนัง
- 2 ทำความสะอาดเครื่องฟอกอากาศ เช่น เซอร์จิรจบบนภาค และพื้นผิวของแผ่นกรอง (ดูบท "การทำความสะอาดและการบำรุงรักษา")
- 3 ตากชิ้นส่วนทุกชิ้นให้แห้งสนิทก่อนนำไปจัดเก็บ
- 4 ห่อแผ่นกรองไว้ในถุงพลาสติกที่กันอากาศออก
- 5 จัดเก็บเครื่องฟอกอากาศและแผ่นกรองในที่แห้งและเย็น
- 6 ล้างมือให้สะอาดหลังจากหยิบจับแผ่นกรอง

7 การแก้ไขปัญหา

ในบทนี้ เราได้รวบรวมปัญหาต่างๆ ที่อาจเกิดขึ้นกับเครื่องได้ หากคุณไม่สามารถแก้ปัญหาด้วยข้อมูลด้านล่างได้ กรุณาติดต่อที่ศูนย์บริการลูกค้าในประเทศของคุณ

ปัญหา	วิธีแก้ปัญหที่อาจใช้ได้
เครื่องทำงานผิดปกติ	ไฟแสดงสถานะการเปลี่ยนแผ่นกรองติดสว่างต่อเนื่อง แต่คุณไม่ได้เปลี่ยนแผ่นกรองที่เกี่ยวข้อง ด้วยเหตุนี้เครื่องจึงถูกล็อก ในกรณีนี้ ให้เปลี่ยนแผ่นกรองและกดปุ่ม  และ  ค้างไว้ เพื่อรีเซ็ตตัวนับอายุการใช้งานของแผ่นกรอง
อากาศหมุนเวียนที่ออกมาจากทางลมออกเบาบางกว่าที่เคย อย่างเห็นได้ชัด	พื้นผิวของแผ่นกรองสกปรก ทำความสะอาดพื้นผิวของแผ่นกรอง (ดูที่บท “การทำความสะอาดและการบำรุงรักษา”)
คุณภาพอากาศไม่ดีขึ้น แม้ว่าเครื่องจะทำงานมาระยะเวลาหนึ่งแล้ว	- ตรวจสอบว่าได้แกะบรรจุภัณฑ์ออกจากแผ่นกรองแล้ว - ไม่ได้ติดตั้งแผ่นกรองในเครื่อง ตรวจสอบว่าได้ติดตั้งแผ่นกรอง (FY2200) อย่างถูกต้องแล้ว - เซนเซอร์ตรวจจับอนุภาคเปียก ระดับความชื้นในห้องของคุณสูง และทำให้เกิดหยดน้ำ ตรวจสอบว่าเซนเซอร์ตรวจจับอนุภาคสะอาดและแห้งดี (ดูที่บท “การทำความสะอาดและการบำรุงรักษา”) - ขนาดห้องใหญ่หรือคุณภาพอากาศภายนอกแย่ เพื่อประสิทธิภาพในการฟอกอากาศระดับสูงสุด โปรดปิดประตูและหน้าต่างในขณะที่ใช้งานเครื่องฟอกอากาศ - ภายในอาคารมีแหล่งมลพิษต่างๆ ตัวอย่างเช่น การสูบบุหรี่ การทำอาหาร ควันท่อป น้ำหอม หรือแอลกอฮอล์ - แผ่นกรองหมดอายุการใช้งานแล้ว เปลี่ยนแผ่นกรองเป็นอันใหม่
สีของไฟแสดงคุณภาพอากาศเป็นเหมือนเดิมตลอด	เซนเซอร์ตรวจจับอนุภาคสกปรก ทำความสะอาดเซนเซอร์ตรวจจับอนุภาค (ดูบท “การทำความสะอาดและการบำรุงรักษา”)

ปัญหา	วิธีแก้ปัญหาที่อาจใช้ได้
เครื่องส่งกลืน แปลกๆ	• คุณอาจได้กลืนพลาสติก เมื่อใช้เครื่องสองสามครั้งแรก ซึ่งเป็นเหตุการณ์ปกติ อย่างไรก็ตาม หากเครื่องส่งกลืนไหม้แม็กคอดแผ่นกรองออกแล้ว ให้ติดต่อตัวแทนจำหน่าย Philips หรือศูนย์บริการ Philips ที่ได้รับอนุญาต แผ่นกรองอาจมีกลิ่นที่ไม่พึงประสงค์ได้หลังจากถูกใช้งานไปสักระยะหนึ่งเนื่องจากการดูดซับแก๊สภายในอาคาร ขอแนะนำให้คุณนำแผ่นกรองกลับมาใช้ใหม่โดยการนำไปผึ่งไว้กับแสงแดดโดยตรงเพื่อใช้ซ้ำ หากยังมีกลิ่นไม่พึงประสงค์เหลืออยู่ ให้เปลี่ยนแผ่นกรอง
เครื่องทำงานเสียงดังผิดปกติ	• ถือว่าเป็นเรื่องปกติหากอุปกรณ์ทำงานที่โหมดเทอร์โบ • ในโหมดอัตโนมัติ หากเครื่องมีเสียงดังเกินไป เครื่องอาจทำงานที่ความเร็วสูงเนื่องจากคุณภาพอากาศแย่ง หรือการตั้งค่าส่วนบุคคลของคุณในแอปทำให้ความเร็วพัดลมสูงขึ้น คุณสามารถเลือกโหมด Sleep หรือเปลี่ยนการตั้งค่าในแอป • หากมีเสียงที่ผิดปกติ โปรดติดต่อศูนย์บริการดูแลลูกค้าในประเทศของคุณ • หากมีสิ่งใดตกลงไปในทางลมออก อาจทำให้เครื่องส่งเสียงผิดปกติขึ้นได้ ปิดเครื่องทันที คว่ำเครื่องลง เพื่อนำสิ่งแปลกปลอมออกจากเครื่อง
เครื่องยังแสดงสัญญาณว่าจำเป็นต้องเปลี่ยนแผ่นกรอง แต่ฉันได้เปลี่ยนไปแล้ว	• คุณอาจไม่ได้รีเซ็ตตัวนับอายุการใช้งานของแผ่นกรอง เปิดสวิตช์เครื่อง แล้วกดปุ่ม  และ  ค้างไว้ 3 วินาที
รหัสแสดงข้อผิดพลาด "E1" ปรากฏบนหน้าจอ	• มอเตอร์ทำงานผิดปกติ โปรดติดต่อศูนย์บริการดูแลลูกค้าในประเทศของคุณ

ปัญหา	วิธีแก้ปัญหาที่อาจใช้ได้
การตั้งค่า Wi-Fi ไม่ประสบความสำเร็จ	• หากเราเตอร์ที่เครื่องฟอกอากาศของคุณเชื่อมต่ออยู่เป็นแบบแบนด์คู่ และไม่ได้เชื่อมต่อเข้ากับเครือข่าย 2.4Ghz โปรดสลับไปแบนด์อื่นในเราเตอร์เดียวกัน (2.4Ghz) แล้วลองจับคู่เข้ากับเครื่องฟอกอากาศของคุณอีกครั้ง ไม่รองรับเครือข่าย 5GHz • ไม่รองรับเครือข่ายการตรวจสอบเว็บ • ตรวจสอบว่าเครื่องฟอกอากาศอยู่ในระยะของเราเตอร์ Wi-Fi หรือไม่ คุณสามารถลองหาตำแหน่งของเครื่องฟอกอากาศที่อยู่ใกล้กับเราเตอร์ Wi-Fi ได้ • ตรวจสอบว่าชื่อเครือข่ายถูกต้องหรือไม่ ชื่อเครือข่ายจะต้องมีตัวอักษรเล็กใหญ่ตรงกัน • ตรวจสอบว่ารหัสผ่าน Wi-Fi ถูกต้องหรือไม่ รหัสผ่านต้องมีตัวอักษรเล็กใหญ่ตรงกัน • ลองตั้งค่าอีกครั้งด้วยคำแนะนำในส่วน “Reset the Wi-Fi connection” • การเชื่อมต่อ Wi-Fi อาจถูกรบกวนได้จากคลื่นแม่เหล็กไฟฟ้าหรือสัญญาณรบกวนอื่นๆ เก็บเครื่องใช้ให้ห่างจากอุปกรณ์อิเล็กทรอนิกส์อื่นๆ ที่อาจมีสัญญาณรบกวน • ตรวจสอบว่าอุปกรณ์มือถืออยู่ในโหมดเครื่องบินหรือไม่ ตรวจสอบให้แน่ใจว่าปิดการใช้งานโหมดเครื่องบินแล้วเมื่อทำการเชื่อมต่อเครือข่าย Wi-Fi • ดูที่ส่วนสนับสนุนช่วยเหลือในแอปสำหรับคำแนะนำในการแก้ไขปัญหาล่าสุดและคำแนะนำเพิ่มเติม

8 การรับประกันและการสนับสนุน

Versuni มีการรับประกันสองปีหลังจากซื้อผลิตภัณฑ์นี้ การรับประกันนี้จะไม่สามารถใช้ได้ หากข้อบกพร่องนั้นเกิดจากการใช้งานไม่ถูกต้องหรือการบำรุงรักษาที่ไม่ดี การรับประกันของเราไม่มีผลต่อสิทธิ์ของคุณภายใต้กฎหมายในฐานะผู้บริโภค สำหรับข้อมูลเพิ่มเติมหรือการเรียกใช้การรับประกัน โปรดไปที่เว็บไซต์ของเรา www.philips.com/support

สั่งซื้อชิ้นส่วนหรืออุปกรณ์เสริม

หากคุณต้องเปลี่ยนชิ้นส่วนหรือต้องการสั่งซื้อชิ้นส่วนเพิ่มเติมโปรดไปที่ตัวแทนจำหน่ายของ Philips หรือไปที่ www.philips.com/support

หากคุณประสบปัญหาในการรับชิ้นส่วน โปรดติดต่อศูนย์ดูแลผู้บริโภคของ Philips ในประเทศของคุณ



PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Versuni Holding B.V., and Versuni Holding B.V. is the warrantor in relation to this product.

2025 © Versuni Holding B.V.

642001023438 (26/06/2025)

