


Quick Start Guide Intelial One Touch Cappuccino - HD8753


Register your product to receive tips and tricks and descaling reminder at www.philips.com/welcome




FIRST INSTALLATION





FIRST ESPRESSO




"MY" ESPRESSO




Length Selection: MEMO



FIRST CAPPUCCINO



HOT WATER



Please refer to user manual for more informations or go to www.philips.com/support

Quick Start Guide Intelial One Touch Cappuccino - HD8753



DESCALING - 30 min.

Keep the machine at its best
The advanced electronics tells you on the display of the machine (in clear symbols) when descaling is needed.

If you don't descale regularly, your appliance will ultimately stop working. This is not covered by your warranty.

Підтримуйте найкращий стан кавоварки
Сучасна електронна система за допомогою зрозумілих позначень на дисплеї кавоварки повідомляє про необхідність видалення накипу.

Якщо видалення накипу не виконується регулярно, прилад зрештою вийде з ладу. Таку несправність не передбачено гарантією.


Należy utrzymywać urządzenie w jak najlepszym stanie.

Zaawansowana elektronika wskazuje na wyświetlaczu urządzenia (przy pomocy czytelnych symboli), kiedy należy wykonać odwapnianie.


Jeżeli użytkownik nie będzie wykonywał odwapniania regularnie, urządzenie przestanie działać prawidłowo. W tym wypadku gwarancja nie obejmuje naprawy.

Поддерживайте наилучшее состояние кофеварки
Современная электронная система с помощью понятных обозначений на дисплее кофеварки сообщает о необходимости удаления накипи.

Если очистка от накипи не выполняется регулярно, прибор в конечном счете выйдет из строя. Такая неисправность не предусматривается гарантией.




MENU FOR CUSTOMIZATION AND MAINTENANCE




Coffee Temperature Stand-by time set Display contrast Water hardness Water filter "INTENZA+" Descaling Menu Default setting machine

MILK CARAFE CLEANING



BREWING UNIT CLEANING



For more information on installation or usage please contact the Philips consumer care help line :

PL: 22 397 15 06
RU: 8 800 200-0880
HU: (061) 700 8152
CS: 228880896

SK: 2 332 155 70
UA: 0-800-500-697
SL: 01 888 83 13

RO: 031 6300043
CR: +385 (01) 777 66 02
BG: +359 02 4916274

For other phone numbers, please refer to the Warranty booklet or go to
www.philips.com/support