PHILIPS

AC5660

EN User manual 1

ZH-T 使用手冊 19

© 2017 Koninklijke Philips N.V.
All rights reserved.

4241 210 97822

1



2

Control buttons



Display panel


3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22


23
24
25
26
27
28
29
30
31

Contents

1 Important 2
Safety 2

2 Your air purifier 5
Product overview (fig.①) 5
Controls overview (fig.②) 5

3 Getting started 6
Installing the filter 6
Wi-Fi connection 6

4 Using the air purifier 7
Understanding the air quality light 7
Turning on and off 8
Changing the Auto mode setting 8
Changing the fan speed 9
Using the light on/off function 9
Switching the display indicator 9
Setting the child lock 10

5 Cleaning 10
Cleaning the body of the air purifier 10
Cleaning the air outlet cover 10
Cleaning the air quality sensor 11
Cleaning the pre-filter 11

6 Replacing the filters 12
Filter replacement indicator 12
Replacing the filter 12

7 Storage 13

8 Troubleshooting 14

9 Guarantee and service 17
Order parts or accessories 17

10 Notices 17
Electromagnetic fields (EMF) 17
Recycling 18
Notice 18

Environmental friendly paper used. Thanks for your contribution to save trees.

1 Important

Safety

Read this user manual carefully before you use the appliance, and save it for future reference.

Danger

- Do not let water or any other liquid or flammable detergent enter the appliance to avoid electric shock and/or a fire hazard.
- Do not clean the appliance with water, any other liquid, or a (flammable) detergent to avoid electric shock and/or a fire hazard.
- Do not spray any flammable materials such as insecticides or fragrance around the appliance.

Warning

- Check if the voltage indicated on the appliance corresponds to the local power voltage before you connect the appliance.
- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips, or similarly qualified persons in order to avoid a hazard.
- Do not use the appliance if the plug, the power cord, or the appliance itself is damaged.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Child shall not play with the appliance. Cleaning and maintenance shall not be made by children without supervision.
- Do not block the air inlet and outlet, e.g. by placing items on the air outlet or in front of the air inlet.
- Make sure that foreign objects do not fall into the

appliance through the air outlet.
- Standard WiFi interface based on 802.11b/g/n at 2.4 GHz with a maximum output power of 31.62 mW EIRP.

Caution

- This appliance is not a substitute for proper ventilation, regular vacuum cleaning, or use of an extractor hood or fan while cooking.
- If the power socket used to power the appliance has poor connections, the plug of the appliance becomes hot. Make sure that you plug the appliance into a properly connected power socket.
- Always place and use the appliance on a dry, stable, level, and horizontal surface.
- Leave at least 20cm free space behind and on both sides of the appliance and leave at least 30cm free space above the appliance.
- Do not place anything on top of the appliance.
- Do not sit or stand on the appliance. Sitting or standing on the appliance may lead to potential injury.
- Do not place the appliance directly below an air conditioner to prevent condensation from dripping onto the appliance.
- Make sure all filters are properly installed before you switch on the appliance.
- Only use the original Philips filters specially intended for this appliance. Do not use any other filters.
- Combustion of the filter may cause inreversible human hazard and/or jeopardize other lives. Do not use the filter as fuel or for similar purpose.
- Avoid knocking against the appliance (the air inlet and outlet in particular) with hard objects.
- Always lift or move the appliance by the handle on back side of the appliance.

- Do not insert your fingers or objects into the air outlet or the air inlet to prevent physical injury or malfunctioning of the appliance.
- Do not use this appliance when you have used indoor smoke-type insect repellents or in places with oily residues, burning incense, or chemical fumes.
- Do not use the appliance near gas appliances, heating devices or fireplaces.
- Always unplug the appliance after use and before cleaning, or carrying out other maintenance or replacing the filters.
- Do not use the appliance in a room with major temperature changes, as this may cause condensation inside the appliance.
- To prevent interference, place the appliance at least 2 meters away from electrical appliances that use airborne radio waves such as TVs, radios, and radio-controlled clocks.
- The appliance is only intended for household use under normal operating conditions.
- Do not use the appliance in wet surroundings or in surroundings with high ambient temperatures, such as the bathroom, toilet, or kitchen.
- The appliance does not remove carbon monoxide (CO) or radon (Rn). It cannot be used as a safety device in case of accidents with combustion processes and hazardous chemicals.
- If you need to move the appliance, disconnect the appliance from the power supply first.
- Do not move the appliance by pulling its power cord.
- Always cleanse your hands after changing the filters.

2 Your air purifier

Congratulations on your purchase, and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Product overview (fig.1)

A	Control buttons
B	Air outlet cover
C	Air quality sensor
D	Display panel
E	NanoProtect filter Pro S3 (**FY5186**)
F	Pre-filter
G	Side covers

Controls overview (fig.2)

Control buttons

H	Power on/off button
I	Light on/off button
J	Auto mode button
K	Fan speed button
L	Child lock button
M	Reset button

Display panel:

	Sleep mode
	Speed 1
	Speed 2
	Speed 3
	Turbo mode
	Filter replacement alert
	Pre-filter cleaning alert
	Wi-Fi indicator
Gas	Gas display
PM2.5	PM2.5 display
IAI	Indoor Allergen Index display
	Pollution mode
	Allergen mode
	Bacteria & Virus mode
	Child lock indicator

3 Getting started

Installing the filter

Remove all packaging of the filters before using the appliance. Unpack them and place them into the appliance described as follows:

Note

- Make sure the air purifier is unplugged from the electrical outlet before installing the filters.
- Make sure the side of the filter with the tag is pointing towards you.

1 Pull the top part of the side panel to remove it from the air purifier (fig.③).
2 Press the two clips down (1) and pull the pre-filter towards you (2) (fig.④).
3 Remove all filters (fig.⑤).
4 Remove all packaging materials from the filter (fig.⑥).
5 Place the filter (**FY5186**) into the air purifier. The model numbers are shown on each filter (fig.⑦).
6 Attach the pre-filter back into the air purifier (fig.⑧).

Note

- Make sure the side with the two clips is pointing towards you, and that all hooks of the pre-filter are properly attached to the purifier.

7 Reattach the front panel by pressing the top part of the panel onto the top of the air purifier (1). Then, gently push the panel against the body of the air purifier (2) (fig.⑨).
8 Repeat the above steps and assemble the filter for the other side of the air purifier.
9 Wash your hands thoroughly after installing filters.

Wi-Fi connection

Setting up the Wi-Fi connection for the first time

1 Download and install the '**Air Matters**' app the **App Store** or **Google Play**.

2 Put the plug of the air purifier in the power socket and touch ⏻ to turn on the air purifier.
   ↪ The Wi-Fi indicator blinks orange for the first time.
3 Make sure that your mobile device is successfully connected to your Wi-Fi network.
4 Launch the '**Air Matters**' app and click on the '+' on the top right of the screen. Follow the onscreen instructions to connect the air purifier to your network.
5 After the successful pairing and connection, the Wi-Fi indicator will light up white. If pairing is not successful, consult the troubleshooting section, or the help section in the '**Air Matters**'

App for extensive and up-to-date troubleshooting tips.

Note

- This instruction is only valid when the air purifier is being set up for the first time. If the network has changed or the setup needs to be performed again, consult section “Setting up the Wi-Fi connection when the network has changed” on page 7.
- If you want to connect more than one air purifier to your smart device, you have to do this successively. Complete the set up of one air purifier before you turn on the other air purifier.
- Make sure that the distance between your mobile device and the air purifier is less than 10 m without any obstructions.
- This App supports the latest versions of Android and iOS. Please check www.philips.com/purifier-compatibility for the latest update of supported operating systems and devices.

Setting up the Wi-Fi connection when the network has changed

Note

- This applies when the default network to which your purifier is connected has changed.

1 Put the plug of the air purifier in the power socket and touch ⏻ to turn on the air purifier.

2 Touch ⏻ and 💡 simultaneously for 3 seconds until you hear a beep.
   ↳ The air purifier goes to pairing mode.
   ↳ The Wi-Fi indicator 📶 blinks orange.

3 Follow the steps 4-5 in **"Setting up the Wi-Fi connection for the first time"** section.

4 Using the air purifier

Understanding the air quality light

PM2.5 level	Air quality light color	Air quality level
≤12	Blue	Good
13-35	Blue-Purple	Fair
36-55	Purple-Red	Poor
>55	Red	Very poor

The air quality light automatically goes on when the air purifier is switched on, and lights up all colors in sequence. After approximately 30 seconds, the air quality sensors select the color that corresponds to the surrounding air quality of airborne particles.

PM2.5

AeraSense sensing technology accurately detects and quickly respond to even the slightest particle change in the air. It provides you with reassurance with real-time PM2.5 feedback.

IAI

The professional-grade **AeraSense** sensor detects the level of indoor air allergen and with numerical feedback from 1 to 12 the potential risk level of indoor air allergens can be displayed. 1 indicates best air quality.

GAS

With an advanced as sensor, a display ranging from L1 to L4 shows the density level of potential harmful gases (incl. VOC, odor, etc.) detected. L1 indicates best air quality.

Turning on and off

Note

- Always place the air purifier on a stable, horizontal, and level surface with the front of the unit facing away from walls or furniture.
- For optimum purification performance, close doors and windows.
- Keep curtains away from the air inlet or air outlet.

1 Put the plug of the air purifier in the power socket.

2 Touch ⏻ to switch on the air purifier (fig.⑩).
   ↳ The air purifier operates under the Pollution mode (PM2.5) by default.
   ↳ When the air purifier is warming up, "---" displays on the screen.
   ↳ After 30 seconds, the air purifier shows the PM2.5 level on the screen. The air quality sensor automatically selects the appropriate air quality light color. (fig.⑪).

3 Touch and hold ⏻ for 3 seconds to switch off the air purifier.

Note

- If the air purifier stays connected to the electrical outlet after turning OFF, the air purifier will operate under the previous settings when turned ON again.

Changing the Auto mode setting

You can choose the Allergen mode ( ), the Pollution mode (PM2.5)or the Bacteria & Virus mode ( ).

Pollution mode

The specially designed pollution mode can effectively remove airborne pollutants such as PM2.5.

- Touch the Auto mode button Ⓐ to select Pollution mode (fig.⑫) .
   ↳ Auto (A) and PM2.5 display on the screen.

Allergen mode

The extra-sensitive allergen mode is designed to react to even a small change in allergen levels in the surrounding air.

- Touch the Auto mode button Ⓐ to select the Allergen mode (fig.⑬).
   ↳ Auto (A) and display on the screen.

Bacteria & Virus mode

The Bacteria & Virus mode boosts the airflow to quickly reduce bacteria & viruses.

- Touch the Auto mode button Ⓐ to select the Bacteria & Virus mode (fig.⑭).
   ↳ Auto (A) and display on the screen.

Changing the fan speed

In addition to the Auto modes, there are several fan speeds available.

When using the manual fan speed settings, the purifier will still monitor the air quality, but it will not automatically adjust the fan speed if it detects changes in the air quality.

Sleep mode ( )

In sleep mode, the air purifier operates quietly at a very low speed.

- Touch the fan speed button to select the sleep mode (**SL**) (fig.15).
  - ↳ The "SL" displays on the screen.
  - ↳ The sleep mode indicator goes on.

Manual

- Touch the fan speed button repeatedly to select the fan speed you need (fig.16):
  (Speed 1)
  (Speed 2)
  (Speed 3)

Tip

- If the air quality light lights up blue, it indicates that the air quality is good, and you can select a lower fan speed. On the other hand, if the air quality light lights up red-purple or red, it indicates that the air quality is unhealthy, and you can select a higher fan speed to purify the air more quickly.

Turbo (t)

In turbo mode, the air purifier operates on the highest speed.

- Touch the fan speed button to select the turbo mode (t) (fig.17).
  - ↳ The "t" displays on the screen.
  - ↳ The turbo speed indicator goes on.

Using the light on/off function

With the light on/off button, you can switch on or off the air quality light, the display screen and the function indicator if desired.

1. Touch the light on/off button once, the air quality light will be dimmed.
2. Touch the light on/off button again, the air quality light will go off.
3. Touch the light on/off button for the third time, all lights will be on again.

Switching the display indicator

The air purifier has three display indicators, IAI index, PM2.5 index, and Gas level.

Note

- The air purifier operates in PM2.5 index by default.

1. Touch the light on/off button for 3 seconds to switch to IAI index (fig.18).
   - ↳ The IAI indicator and the actual IAI index display on the screen.

2 Touch the light on/off button for 3 seconds again to switch to PM2.5 index (fig.⑲).
   ↳ The PM2.5 indicator and the actual PM2.5 index display on the screen.

3 Touch the light on/off button for 3 seconds again to switch to Gas level display (fig.⑳).
   ↳ The Gas indicator and the actual Gas level display on the screen.

Note

- It is possible that the air quality light may still be red even if the PM2.5 index is very low. It's normal. This is because that at least one of the index (the IAI index or Gas level) is high that turns the air quality light to red. The appliance real-time displays the air quality index with the highest risk.

Setting the child lock

1 Touch and hold the child lock button for 3 seconds to activate child lock (fig.㉑).
   ↳ The child lock icon displays on the screen.
   ↳ When the child lock is on, all the other buttons are not responsive.

2 Touch and hold the child lock button for 3 seconds again to deactivate child lock.
   ↳ The child lock icon disappears.

Note

- You can still control the appliance through the App even child lock is activated.

5 Cleaning

Note

- Always turn the air purifier off and unplug from the electrical outlet before cleaning.
- Never immerse the air purifier in water or any other liquid.
- Never use abrasive, aggressive, or flammable cleaning agents such as bleach or alcohol to clean any part of the air purifier.
- Only the pre-filter is washable. The air filters are not washable.
- Do not attempt to clean the filters or air quality sensor with a vacuum.

Cleaning the body of the air purifier

Regularly clean the inside and outside of the air purifier to prevent dust from collecting.

1 Use a soft, dry cloth to clean both the interior and exterior of the air purifier.

2 The air outlet can also be cleaned with a dry, soft cloth.

Cleaning the air outlet cover

1 To unlock the air outlet cover, grab the handle on the cover and pull the cover up (fig.㉒).

2 Clean the cover with a brush (fig.㉓).

3 To reattach the cover properly (fig.㉔).

Cleaning the air quality sensor

Clean the air quality sensor every 2 months for optimal functioning of the purifier.

Note

- If the air purifier is used in a dusty environment, it may need to be cleaned more often.
- If the humidity level in the room is very high, condensation may develop on the air quality sensor and the air quality light may indicate a poorer air quality even though the air quality is actually good. If this occurs, clean the air quality sensor or use the air purifier on a manual speed setting.

1. Clean the air quality sensor inlet and outlet with a soft brush (fig.25).
2. Open the air quality sensor cover (fig.26).
3. Clean the air quality sensor, the dust inlet and the dust outlet with a damp cotton swab (fig.27).
4. Dry all parts thoroughly with a dry cotton swab.
5. Reattach the air quality sensor cover (fig.28).

Cleaning the pre-filter

Clean the pre-filter when **F0** is displayed on the screen and the pre-filter cleaning indicator is on (fig.29).

1. Switch off the air purifier and unplug from the power socket.
2. Pull the top part of the side panel to remove it from the air purifier (fig.3).
3. Press the two clips down (1) and pull the pre-filter towards you (2) (fig.4).
4. If the pre-filter is very dirty, use a soft brush to brush away the dust. Then wash the pre-filter under running tap water (fig.30).
5. Allow the pre-filter to air dry thoroughly before placing back in the air purifier.
6. Put the pre-filter back into the air purifier (fig.8).

Note

- To optimize the lifetime of the pre-filter, make sure it air dries completely after cleaning.
- Wash your hands after handling the filter.
- Make sure the side with the two clips is pointing towards you, and that all hooks of the pre-filter are properly attached to the air purifier.

7. To reattach the front panel, press the top part of the panel onto the top of the air purifier (1). Then, gently push the panel against the body of the air purifier (2) (fig.9).
8. Put the plug of the air purifier in the power socket.
9. Touch the ⏻ button to switch on the appliance.
10. Touch and hold the reset button ⮌ for 3 seconds to reset the pre-filter cleaning time.
11. Wash your hands thoroughly after installing filters.

6 Replacing the filters

Filter replacement indicator

This air purifier is equipped with a filter replacement indicator to make sure that the air purification filter is in optimal condition when the air purifier is operating. When the filters need to be replaced, the filter code displays on the screen (see Filter alert chart).

If the filters are not replaced in time, the air purifier will stop operating and automatically lock to protect the air quality in the room. Replace the filters as soon as possible according to the filter code.

Replacing the filter

Note

- The air filter is not washable or reusable.
- Always turn off the air purifier and unplug from the electrical outlet before replacing the filters.
- Do not clean the filters with a vacuum.
- If the pre-filter is damaged, worn or broken, do not use. Visit www.philips.com/support or contact the Consumer Care Center in your country.

Filter alert light status	Action
A3 displays on the screen and the filter replacement alert goes on	Replace the NanoProtect filter Pro S3 (**FY5186**)

1 Turn off the air purifier and unplug from the power socket.

2 Take out the used air filter according to the filter alert light status displayed on the screen. Discard used filter (fig.31).

Note

- Do not touch the pleated filter surface, or smell the filters as they have collected pollutants from the air.

3 Remove all packaging material from the new filter (fig.6).

4 Place the new filter into the air purifier (fig.7).

5 Put the plug of the air purifier in the power socket.

6 Touch and hold the reset button for 3 seconds to reset the filter lifetime counter.

Note

- Wash your hands after changing a filter.
- This air purifier has no other user-serviceable parts. For assistance, contact the Consumer Care Center in your country.

7 Storage

1. Turn off the air purifier and unplug from the power socket.
2. Clean the air purifier, air quality sensor and pre-filter (see chapter ‘Cleaning’).
3. Let all parts air dry thoroughly before storing.
4. Wrap the filters and pre-filters separately in air tight plastic bags.
5. Store the air purifier, filters and pre-filters in a cool, dry location.
6. Always thoroughly wash hands after handling filters.

8 Troubleshooting

This chapter summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Center in your country.

Problem	Possible solution
The air purifier does not work even though it is switched on.	• Check if the top cover is properly installed. • The filter replacement light has been on continuously but you have not replaced the corresponding filter. As a result, the appliance is now locked. In this case, replace the filter and reset the filter lifetime counter.
The airflow that comes out of the air outlet is significantly weaker than before.	• The pre-filter is dirty. Clean the pre-filter (see chapter "Cleaning").
The air quality does not improve, even though the air purifier has been operating for a long time.	• Check if the packing material is removed from the filters. • One of the filters has not been placed in the air purifier or a filter is not placed properly. Make sure that all filters are properly installed in the following order, starting with the innermost filter: 1) NanoProtect filter Pro S3 (**FY5186**); 2) pre-filter. • The air quality sensor is wet. Make sure that the air quality sensor is clean and dry (see chapter "Cleaning").
The color of the air quality light always stays the same.	• The air quality sensor is dirty. Clean the air quality sensor (see chapter "Cleaning").
The air purifier produces a unpleasant smell.	• The first few times you use the appliance, it may produce a plastic smell. This is normal. However, if the appliance produces a burnt smell, contact your Philips dealer or an authorized Philips service center. The filter may produce smell after being used for a while because of the absorption of indoor air. Remove the filter and place it where it has direct sunlight and ventilation for several hours. Re-install and try using it again. If the odor remains, please replace the filter.
The air purifier is loud.	• If the air purifier is too loud, change the fan speed to a lower fan speed level. When using the air purifier in a bedroom at night, choose the Sleep mode.

Problem	Possible solution
The air purifier still indicates that I need to replace a filter, but I already did.	• Perhaps you did not reset the filter lifetime counter. Plug in the air purifier, touch ⏻ to switch on the air purifier, and touch and hold the reset button ⮌ for 3 seconds (see Replacing the filters section).
Error code "E1" displays on the screeen.	• The motor has malfunctions. Contact the Consumer Care Center in your country.
Error codes "E2", "E3", "E4" or "E5" displays on the screen.	• The sensor has malfunctions. Contact the Consumer Care Center in your country.
Which App I should download?	• Please download and install the 'Air Matters' App developed by Air Matters Network Pty Ltd from the App Store or Google Play.
The Wi-Fi setup is not successful.	• If the router your purifier is connected to is dual-band and currently it is not connecting to a 2.4GHz network, please switch to another band of the same router (2.4GHz) and try to pair your purifier again. 5GHz networks are not supported. • Web authentication networks are not supported. • Check if the purifier is within range of the Wi-Fi router. You can try to locate the air purifier closer to the Wi-Fi router. • Check if the network name is correct. The network name is case-sensitive. • Check if the Wi-Fi password is correct. The password is case-sensitive. • Retry the setup with the instructions in section 'Set up the Wi-Fi connection when the network has changed'. • The Wi-Fi connectivity can be interrupted by electromagnetic or other interferences. Keep the appliance away from other electronic devices that may cause interferences. • Check if the mobile device is in airplane mode. Make sure to have the airplane mode deactivated when connecting to the Wi-Fi network. • Consult the help section in the App for extensive and up-to-date troubleshooting tips.

9 Guarantee and service

If you need information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Consumer Care Center in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

Order parts or accessories

If you have to replace a part or want to purchase an additional part, go to your Philips dealer or visit www.philips.com/support.

If you have problems obtaining the parts, please contact the Philips Consumer Care Center in your country (you can find its phone number in the worldwide guarantee leaflet).

10 Notices

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Compliance with EMF

Koninklijke Philips N.V. manufactures and sells many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals.

One of Philips' leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products.

Philips is committed to develop, produce and market products that cause no adverse health effects. Philips confirms that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today.

Philips plays an active role in the development of international EMF and safety standards, enabling Philips to anticipate further developments in standardization for early integration in its products.

Recycling

Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

Notice

This Philips appliance and Air Matters app applied multiple open source softwares, Copies of open source software license text used in this product can be derived from website- www.philips.com/purifier-compatibility.

App Store is a service mark of Apple Inc. Google Play is a trademark of Google Inc.

目錄

1 重要事項 20
安全 20

2 您的空氣淨化器 22
產品簡介（圖 ①） 22
控制鍵概覽（圖 ②） 22

3 使用入門 23
安裝濾網 23
Wi-Fi 連接 23

4 使用空氣淨化器 24
瞭解空氣質素燈 24
開關 25
更改自動模式設定 25
改變風速 25
使用光源開/關功能 26
切換空氣指數顯示 26
設定童鎖 26

5 清潔 27
清潔空氣淨化器機身 27
清潔通風口蓋 27
清潔空氣質素感應器 27
清潔預過濾網 27

6 更換過濾網 28
過濾網替換指示燈 28
更換過濾網 28

7 存放 29

8 疑難排解 30

9 保養及服務 32
訂購零件或配件 32

10 注意 32
電磁場（EMF） 32
環保 32
注意 32

使用環保紙張。感謝您為保護森林作出的貢獻。

1 重要事項

安全

使用本產品前請先閱讀本用戶手冊，並保管以作將來參考。

危險事項

- 請勿讓水或任何液體或易燃清潔劑進入此產品，以避免觸電和/或火災的危險。
- 請勿用水或任何液體或（易燃）清潔劑清潔此產品，以避免觸電和/或火災的危險。
- 請勿在本產品周圍噴射殺蟲劑或芳香劑等易燃物品。

警告

- 在連接本產品前，請檢查產品註明的指示電壓與當地電源電壓是否對應。
- 如果電源軟線損壞，為避免危險，必須由製造廠或其維修部或類似的專職人員來更換。
- 若插頭、電線或產品本身已受損，請勿使用。
- 此產品可供八歲及以上兒童，體能、感官或心智能力低下人仕，或缺乏知識及經驗人仕使用，如該等人仕已就使用本產品給予監督或有關安全使用本產品的指導及明白本產品的使用所涉及的危險。請勿讓孩童將本產品當成玩具。兒童不應於沒有監督情況下對產品進行清潔及維護。
- 請勿阻塞進氣口和排氣口，例如在排氣口上面或進氣口前面放置物件。
- 確保異物不會通過排氣口掉入裝置內部。
- WiFi 介面採用標準 802.11b/g/n 制式、2.4 Ghz 頻段，最大輸出功率為 31.62 mW EIRP。

注意

- 本產品並不是適當通風設備、正規吸塵器或煮食時使用的抽油煙機或風扇的代替品。
- 若為本產品提供電力的電源插座沒有妥善連接，本產品的插頭便會發熱。請確保您已妥善連接電源插座。
- 在乾燥、穩定、平滑和水平表面上使用產品。
- 在本產品的後面和兩側至少留出 20 厘米的自由空間，本產品上方至少留出 30 厘米空間。
- 請勿在裝置上放置任何物品。
- 請勿坐或站立在裝置上。坐在或站立在裝置上可能會導致受傷。

- 請勿在冷氣機正下方放置產品，以避免冷凝滴水到產品上。
- 在開啟產品前，確保已正確安裝所有濾網。
- 僅使用專門針對本產品的原裝 Philips 濾網。請勿使用任何其他濾網。
- 燃燒過濾器可能造成對健康無可挽回的危害及/或危及他人生命。不要使用濾網作為燃料或類似用途。
- 避免以硬物碰撞產品 (尤其是產品的通風口和排氣口)。
- 請使用裝置背面的手柄來提起或移動裝置。
- 請勿將您的手指或其他物件放入通風口或排氣口，以免造成身體傷害或產品故障。
- 若您使用室內煙型驅蚊劑，或該地方有油跡、香火或化學煙霧，請勿使用本產品。
- 請勿在煤氣用具、暖氣設備或壁爐旁邊使用本產品。
- 使用後，清潔或進行其他保養或更換濾網前，務必拔除本產品的插頭。
- 請勿在溫度變化較大的房間內使用本產品，這可能導致產品內產生冷凝物。
- 為了防止干擾，請與使用空中無線電波的電器如電視機、收音機及收音機鬧鐘距離 2 米的地方使用本產品。
- 本產品只適合一般操作環境下的家居使用。
- 請勿在洗手間或廚房等濕潤環境或高溫環境使用本產品。
- 本產品不會去除一氧化碳 (CO) 或氡 (Rn)。在發生燃燒過程和危險化學物質的事故中，不能將本產品作為安全裝置使用。
- 如果您需要移動本產品，請先拔除其電源供應。
- 不要拉扯電源線來移動裝置。
- 每次更換濾網後都請清潔雙手。

2 您的空氣淨化器

感謝您購買 Philips 產品，歡迎來到 Philips 世界！

要享受 Philips 為您提供的全面支援，請在以下網站 www.philips.com/welcome 註冊您的產品。

產品簡介（圖 ①）

A	控制按鈕
B	通風口蓋
C	空氣質素感應器
D	顯示面板
E	納米級防護複合甲醛HEPA濾網 – 專業S3型 (**FY5186**)
F	預過濾網
G	側蓋

控制鍵概覽（圖 ②）

控制按鈕

H	電源開/關按鈕
I	光源開/關按鈕
J	自動模式按鈕
K	風扇速度按鈕
L	童鎖按鈕
M	重設按鈕

顯示面板：

	睡眠模式
	風速 1
	風速 2
	風速 3
	特強模式
	濾網更換警示
	預過濾網清潔警示
	Wi-Fi 指示燈
Gas	異味指數
PM2.5	PM2.5 指數
IAI	室內過敏原指數
	除污模式
	防敏模式
	防菌模式
	童鎖指示燈

3 使用入門

安裝濾網

使用裝置前，請取出所有的濾網的包裝。從包裝中取出，並將濾網放入裝置中，如下所示：

提示

- 安裝濾網前，請確保空氣淨化器已經從電源插座拔除。
- 確保濾網有標籤的一面是向著您。

1 拉出側邊面板的頂部，並從空氣淨化器中取出（圖 ③）。
2 按下兩個夾子（1），將預過濾網向您的方向拉動（2）（圖 ④）。
3 移除所有濾網（圖 ⑤）。
4 移除濾網的所有包裝物料（圖 ⑥）。
5 將濾網 (FY5186) 放入空氣淨化器。型號已在各個濾網上列明（圖 ⑦）。
6 將預過濾網裝回空氣淨化器上（圖 ⑧）。

提示

- 確保有兩個夾的一邊正向著您，且所有預過濾網的鉤已妥善連接本產品。

7 將前面板的上方往空氣淨化器（1）的上方按壓即可重新安裝。然後輕輕將面板往空氣淨化器的機身按壓（2）（圖 ⑨）。
8 重覆以上步驟，並將濾網安裝到空氣淨化器的另一邊。
9 安裝濾網後，必須徹底洗淨雙手。

Wi-Fi 連接

首次設定 Wi-Fi 連線

1 從 App Store 或 Google Play 下載並安裝「在意空氣」應用程式。

2 將空氣淨化器的插頭插入電源插座，輕按 ⏻ 以啟動空氣淨化器。
↳ Wi-Fi 指示燈 首次閃爍橙色燈光。
3 請確保您的流動裝置已成功連線至 Wi-Fi 網絡。
4 啟動「在意空氣」應用程式，然後點擊螢幕右上方的「+」，依照畫面上的指示將本產品連線至您的網絡。
5 成功配對並連接後，Wi-Fi 指示燈 即會亮白燈。如未能成功配對，請參閱疑難排解部分，或「在意空氣」應用程式中的說明部分，以獲取最新的詳細疑難排解貼士。

提示

- 本指示僅適用於首次設定空氣淨化器。如網絡有變或需要重新設定，請參閱第 24 頁的「網絡改變後設定 Wi-Fi 連線」部分。
- 如您要將多於一部空氣淨化器連接至智能裝置，您必須逐一連接。啟動另一部空氣淨化器前，請完成設定當前的空氣淨化器。
- 請確保流動裝置和空氣淨化器的距離在 10米 以內，而且沒有任何障礙物。
- 本應用程式支援最新版本的 Android 和 iOS。請查閱 www.philips.com/purifier-compatibility，以了解支援的作業系統和裝置的最新資料。

網絡改變後設定 Wi-Fi 連線

提示

- 本提示只在空氣淨化器已連接的預設網絡改變時適用。

1 將空氣淨化器的插頭插入電源插座，輕按 ⏻ 以啟動空氣淨化器。

2 同時按下 ⏻ 和 3 秒，直至聽到「嗶」聲為止。
↳ 空氣淨化器進入配對模式。
↳ Wi-Fi 指示燈 閃爍橙色燈光。

3 請按照「首次設定 Wi-Fi 連線」部分的步驟 4-5 操作。

4 使用空氣淨化器

瞭解空氣質素燈

PM2.5 水平	空氣質素指示燈的顏色	空氣質素水平
≤12	藍色	良好
13-35	藍紫色	一般
36-55	紫紅色	差
>55	紅色	非常差

開啟空氣淨化器時，空氣質素燈將自動亮起，並順序顯示所有顏色。約 30 秒後，空氣質素感應器會根據周遭空中粒子的空氣質素，選擇相應的顏色。

PM2.5

AeraSense 感應技術能夠準確地偵測並快速回應，即使對空氣中最微小的粒子變化也不例外。確保可為您提供即時的 PM2.5 反應的保證。

IAI

專業級的 AeraSense 感應器可偵測室內空氣過敏原的水平，透過 1 至 12 的數值反應顯示室內空氣過敏原的潛在危險等級。1 代表最佳的空氣質素。

氣體

裝置設有先進的感應器，從螢幕上 L1 到 L4 的數值顯示偵測到的潛在有害氣體密度（包括 VOC、臭氣等）。L1 代表最佳的空氣質素。

開關

提示

- 空氣淨化器必須放置在穩定、平坦及水平的表面上，淨化器前方不得面向牆壁或家具。
- 請關閉門窗，以獲得最佳的空氣淨化效果。
- 窗簾必須遠離進氣口或排氣口。

1 將空氣淨化器插頭插入電源插座。
2 按下 ⏻ 以啟動空氣淨化器（圖 ⑩）。
↳ 空氣淨化器默認以污染模式（PM2.5）運行。
↳ 空氣淨化器正準備運作時，「---」便會在螢幕上顯示。
↳ 30 秒後，空氣淨化器螢幕將顯示 PM2.5 水平。空氣質素感應器可自動選擇相應的空氣質素指示燈顏色。（圖 ⑪）。
3 按住 ⏻ 3 秒關閉空氣淨化器。

提示

- 如空氣淨化器在「關閉」後繼續連接至電源插座，空氣淨化器在再次「啟動」時，將按之前的設定操作。

更改自動模式設定

您可以選擇防敏模式（）、除污模式（PM2.5）或防菌模式（）。

除污模式

特別設計的過濾污染模式可以有效消除空氣中的污染物，如 PM2.5。

- 按下自動模式按鈕 Ⓐ，選擇除污模式（圖 ⑫）。
↳ 自動（A）及 PM2.5 將顯示在螢幕上。

防敏模式

設有特別靈敏的防敏模式，採用特別設計，可對周圍空氣中尤其輕微的致敏原水平變化作出反應。

- 點按自動模式按鈕 Ⓐ，選擇防敏模式（圖 ⑬）。
↳ 自動（A）及 將顯示在螢幕上。

防菌模式

過濾細菌和病毒模式可提高氣流，快速地減少細菌和病毒滋生。

- 點按自動模式按鈕 Ⓐ，選擇防菌模式（圖 ⑭）。
↳ 自動（A）及 將顯示在螢幕上。

改變風速

除自動模式外，還設有幾種風速可供選擇。

當使用手動風速設定時，空氣淨化器仍然會監控空氣質素，但如果偵測到空氣質素有變化，也不會自動調節風速。

睡眠模式（）

在睡眠模式下，空氣淨化器以非常低的速度安靜地運作。

- 按下風速按鈕 以選擇休眠模式 (SL)（圖 ⑮）。
↳ 「SL」將顯示在螢幕上。
↳ 睡眠模式指示燈 將會亮起。

手動式

- 重覆按下風速按鈕 選擇您需要的風速（圖 ⑯）：
～（風速 1）
≈（風速 2）
≋（風速 3）

貼士

- 如果空氣質素燈亮起藍色，表示空氣質素為良好，您可以選擇較低的風速。另一方面，如果空氣質素燈亮起紅紫色或紅色，表示空氣質素為不健康，您可以選擇較高的風速來更快地淨化空氣。

特強模式 (t)

在特強模式中，空氣淨化器以最高速度運作。

- 按下風速按鈕 以選擇特強模式 (t)（圖 ⑰）。
  - ↳ 「t」將顯示在螢幕上。
  - ↳ 特強模式指示燈 將會亮起。

使用光源開/關功能

透過光源開/關按鈕，在需要時可以開啟或關閉空氣質素顯示燈、螢幕及功能指示燈。

1. 點按光源開/關按鈕 一次，空氣質素顯示燈將會變暗。
2. 再次點按光源開/關按鈕 ，空氣質素顯示燈將會關閉。
3. 第三次按下光源開/關按鈕 ，所有燈將會再次亮起。

切換空氣指數顯示

空氣淨化器有三種空氣指數顯示：室內過敏原指數、PM2.5 指數和異味指數。

提示

- 空氣淨化器默認以 PM2.5 指數運行。

1. 按下光源開/關按鈕 3 秒，以切換至室內致敏原指數（IAI）指數（圖 ⑱）
   - ↳ IAI 指示燈和實際 IAI 指數顯示在螢幕上。
2. 再次按下光源開/關按鈕 3 秒，以切換至 PM2.5 指數（圖 ⑲）。
   - ↳ PM2.5 指示燈和實際 PM2.5 指數顯示在螢幕上。
3. 再次按下光源開/關按鈕 3 秒，以切換至異味指數顯示（圖 ⑳）。
   - ↳ 異味指示燈和實際異味指數顯示在螢幕上。

提示

- 即使 PM2.5 指數非常低，空氣質素指示燈也可能依然是紅色。這是正常的情況。這是因為即使只有一個指數（室內過敏原指數或異味指數）偏高，空氣質素指示燈亦會轉為紅色。裝置可即時顯示風險最高的空氣質素指標。

設定童鎖

1. 按住童鎖按鈕 3 秒，以啟動童鎖（圖 ㉑）。
   - ↳ 童鎖圖示 顯示在屏幕上。
   - ↳ 當童鎖處於開啟狀態時，所有其他按鈕均不響應。
2. 按住童鎖按鈕 3 秒，取消兒童安全模式。
   - ↳ 童鎖圖示 便會消失。

提示

- 即使啟用童鎖功能，您仍然可以透過應用程式控制裝置。

5 清潔

提示

- 清潔之前，請務必關閉空氣淨化器，並從電源插座上拔走插頭。
- 請勿將空氣淨化器浸入水中或任何液體中。
- 請勿使用磨蝕性、刺激性或易燃清潔劑（如漂白劑或酒精）清洗空氣淨化器的任何一部分。
- 只有預過濾網是可清洗的。請勿清洗濾網。
- 請勿以吸塵機清潔濾網或空氣質素感應器。

清潔空氣淨化器機身

請定時清潔本空氣淨化器的內部和外部，以避免積聚塵埃。

1 使用柔軟乾爽的抹布清潔空氣淨化器的內部和外部。
2 排氣口亦可以柔軟乾爽的抹布清潔。

清潔通風口蓋

1 要解除鎖定通風口蓋，請拿穩蓋子上的手柄，並將蓋子向上拉（圖 ㉒）。
2 使用刷子清潔通風口蓋（圖 ㉓）。
3 重新將蓋子安裝好（圖 ㉔）。

清潔空氣質素感應器

每兩個月清潔空氣質素感應器，讓本產品發揮出最佳功能。

提示

- 如在多塵的環境內使用空氣淨化器，則可能需要更常清潔。
- 如房間濕度非常高，水滴便會凝結在空氣質素感應器上，即使實際空氣質素良好，空氣質素燈仍可能會顯示較差的空氣質素。在此情況下，請清潔空氣質素感應器或以人手設置空氣淨化器的速度。

1 使用柔軟毛刷清潔空氣質素感應器進氣口及排氣口（圖 ㉕）。
2 打開空氣質素感應器護蓋（圖 ㉖）。
3 使用稍為濕潤的棉花棒清潔空氣質素感應器和塵埃的出入口（圖 ㉗）。
4 使用乾爽的棉花棒徹底擦乾所有部件。
5 重新裝上空氣質素感應器護蓋（圖 ㉘）。

清潔預過濾網

當 F0 顯示在螢幕上，預過濾網清潔指示燈亮起（圖 ㉙）時清潔預過濾網。

1 關閉空氣淨化器，並將其從電源插座拔出。
2 拉出後面板的頂部，並從裝置中取出（圖 ③）。
3 按下兩個夾子（1），將預過濾網向您的方向拉動（2）（圖 ④）。
4 如果預過濾網內部十分骯髒，可用軟刷將塵埃刷走。然後利用自來水沖洗預過濾網（圖 ㉚）。
5 先徹底風乾預過濾網，然後將其裝回空氣淨化器內。
6 將預過濾網裝回空氣淨化器上（圖 ⑧）。

提示

- 確保預過濾網在清潔後徹底風乾，這有助延長其使用壽命。
- 清潔濾網後，必須洗手。
- 確保有兩個夾的一邊正向著您，且所有預過濾網的鉤已妥善連接空氣淨化器。

7 將前面板的上方往空氣淨化器（1）的上方按壓即可重新安裝。然後輕輕將面板往空氣淨化器的機身按壓（2）（圖 ⑨）。

8 將空氣淨化器插頭插入電源插座。

9 按下 ⏻ 按鈕開啟本產品。

10 按住重設按鈕 ⮌ 3 秒以重新設定預過濾網清潔時間。

11 安裝濾網後，必須徹底洗淨雙手。

6 更換過濾網

過濾網替換指示燈

空氣淨化器設有過濾網替換指示燈，以確保空氣淨化濾網在空氣淨化器運作時處於良好狀態。需要更換濾網時，螢幕會顯示濾網代碼（請參閱 濾網警示說明表）。

如果您沒有及時更換濾網，本產品將停止運作及自動鎖定，以保障房間的空氣質素。請根據濾網代碼儘快更換濾網。

更換過濾網

提示

- 請勿清洗或重用濾網。
- 更換濾網前，必須關閉空氣淨化器，並將其從電源插座拔除。
- 請勿以吸塵機清潔濾網。
- 如果預過濾網已損壞、磨損或破裂，請勿使用。請瀏覽 www.philips.com/support 或聯絡您所在國家/地區的客戶服務中心。

過濾網警示燈狀態	動作
螢幕上顯示 A3，而且濾網更換警示 亮起	更換納米級防護複合甲醛HEPA濾網 – 專業S3型 (FY5186)

1 關閉空氣淨化器，並將其從電源插座拔出。

2 根據螢幕上的濾網警示燈狀態，取出舊的濾網。丟棄使用過的濾網（圖 ㉛）。

提示

- 請勿觸摸折疊的過濾網表面，或聞過濾網上的氣味，因為過濾網上聚集了空氣中的污染物。

3 拆去新濾網上的所有包裝物料（圖 ⑥）。

4 將新的過濾器安裝到空氣淨化器（圖 ⑦）。

5 將空氣淨化器插頭插入電源插座。

6 按住重設按鈕 ⮌ 3 秒以重新設定濾網使用時間。

提示

- 更換濾網後，必須洗手。
- 此空氣淨化器沒有其他用戶可以自行維修的部件。如需協助，請聯絡您所在國家/地區的客戶服務中心。

7 存放

1 關閉空氣淨化器，並將其從電源插座拔出。

2 清潔空氣淨化器、空氣質素感應器和預過濾網（請參閱「清潔」章節）。

3 必須讓所有部件風乾方可存放。

4 將濾網和預過濾網分開放入密封的膠袋中。

5 將空氣淨化器、濾網和預過濾網存放於陰涼乾爽的地方。

6 處理濾網後，必須徹底洗淨雙手。

8 疑難排解

本章節總結一些您在本產品上最常見的問題。如果您按照以下資料仍未能解決問題，請聯絡您的國家的 Philips 顧客服務中心。

問題	可行解決方案
空氣淨化器即使開啟了也沒有正常運作。	• 檢查是否上蓋已正確安裝。 • 濾網替換指示燈持續亮起，但您沒有更換相關濾網，空氣淨化器現已鎖上。在這情況，請更換該濾網並重設濾網使用時間。
從排氣口排出的氣流比以前顯著減弱。	• 預過濾網處於骯髒的狀態。清潔預過濾網（請查看「清潔」一章）。
本空氣淨化器經過長時間運作，空氣質素仍沒有改善。	• 請檢查濾網的包裝袋是否拆除。 • 其中一個濾網沒有安裝到空氣淨化器中，或某個濾網沒有安裝妥當。請確認所有濾網均按正確次序裝上，從最內部數起：1) 納米級防護複合甲醛HEPA濾網 – 專業S3型 (**FY5186**)；2) 預過濾網。 • 空氣質量感測器變濕。確保空氣質素感應器清潔和保持乾燥（請參閱「清潔」一章）。
空氣質素光環的顏色永遠保持同一顏色。	• 空氣質量感測器處於骯髒的狀態。清潔空氣質素感應器（請參閱「清潔」一章）。
空氣淨化器發出異味。	• 在您最初數次使用本產品時，它可能會發出一點塑膠氣味。此為正常。可是，如果本產品發出燒焦的氣味，請聯絡您的 Philips 經銷商或認可的 Philips 顧客服務中心。開始使用後的濾網因吸收了室內空氣，可能會產生少許異味。移除濾網，將其放置在陽光直射和通風的地方幾個小時。重新裝上，並再次嘗試使用濾網。如果仍然有氣味，請更換濾網。
空氣淨化器聲浪太大。	• 如果空氣淨化器太吵，可調低風扇速度。如晚上在睡房使用空氣淨化器，請選擇睡眠模式。
即使我已更換過濾網，空氣淨化器仍表示需要更換。	• 可能您沒有重置濾網的使用時間。插入空氣淨化器電源，按下 ⏻ 開啟空氣淨化器，然後按住重設按鈕 ⮌ 3 秒（請參閱「更換過濾網」章節）。
螢幕顯示「E1」的錯誤代碼 。	• 馬達發生故障。請聯絡您所在國家/地區的顧客服務中心。

問題	可行解決方案
螢幕上顯示了「E2」、「E3」、「E4」或「E5」的錯誤代碼。	• 傳感器發生故障。請聯絡您所在國家/地區的顧客服務中心。
我應該下載哪一個應用程式？	• 請從 App Store 或 Google Play 下載並安裝 Air Matters Network Pty Ltd 研發的「在意空氣」應用程式。
未能成功設定 Wi-Fi。	• 如果本產品所連接的路由器為雙頻，而目前不是連接 2.4GHz 網絡的話，請將該路由器的頻段切換至 2.4GHz，然後再次嘗試進行配對。不支援 5GHz 網絡。 • Web 驗證網絡不受支援。 • 檢查本產品是否在 Wi-Fi 路由器所覆蓋的範圍內。您可以嘗試將空氣淨化器移近 Wi-Fi 路由器。 • 請檢查網絡名稱是否正確。網絡名稱有大小寫之分。 • 請檢查 Wi-Fi 密碼是否正確。密碼有大小寫之分。 • 根據「網絡改變後設定 Wi-Fi 連線」部分的指示，嘗試重新設定。 • Wi-Fi 連線可能被電磁場或其他干擾而中斷。讓本產品遠離可能會造成干擾的其他電子裝置。 • 請檢查流動裝置是否處於飛行模式。連接至 Wi-Fi 網絡時，請確保已停用飛行模式。 • 請參閱應用程式中的說明部分，以獲取最新的詳細疑難排解貼士。

9 保養及服務

如果您需要資料或有疑問，請前往 Philips 網站 www.philips.com 或聯絡您的國家的 Philips 顧客服務中心（您會在全球保障小冊子上找到其電話號碼）。如果您的國家沒有顧客服務中心，請前往當地的 Philips 經銷商。

訂購零件或配件

如果您需要更換零件或想訂購額外配件，請前往您的 Philips 經銷商或瀏覽 www.philips.com/support。

如果您索取有關零件時遇上問題，請聯絡您的國家/地區 Philips 顧客服務中心（您可在全球保障小冊子上找到其電話號碼）

10 注意

電磁場（EMF）

這款 Philips 產品符合一切有關電磁場暴露的適用安全標準及條例。

符合 EMF 標準

Koninklijke Philips N.V. 專為消費者製造及銷售許多產品 (例如任何電器用品)，而這些產品都能發出與接收電磁訊號。

Philips 貫徹執行的一項主要商業準則是對我們的產品採取所有必要的健康和安全措施，遵循一切可行的法律規定，並在產品生產期間嚴格遵守 EMF 標準。

Philips 致力於開發、生產及銷售對健康無害的產品。Philips 確認如果產品在目標用途中操作得當，根據當今權威科學論證，將不會存在任何安全隱患。

Philips 在開發國際 EMF 和安全標準中扮演著積極作用，有助其預見未來標準化的發展趨勢以便盡早融入至產品中。

環保

請勿在本產品使用壽命結束後當作一般家庭垃圾廢棄，應交給官方回收站作循環再用。這樣做有助保護環境。

請遵守您的國家/地區回收電器和電子產品的法則。正確處理廢棄產品有助避免對環境和人體造成負面影響。

注意

本 Philips 裝置及 Air Matters 應用程式使用多個開放源碼軟件，本產品使用的開放源碼軟件許可證文本可以由 www.philips.com/purifier-compatibility 網站取得。

App Store 是 Apple Inc. 的服務商標。Google Play 是 Google Inc. 的商標。