






Quick Start Guide – HD4907, HD4908, HD4909

<p>Insert the plug firmly into socket and switch “ON”. The Philips Induction Cooker starts up with a beep and the LED display blinks once.</p>	
<p>Touch the “ON/OFF” Button once, the “ON/OFF” indicator will blink continuously with a single beep</p>	
<p>Place the vessel at the center of the ceramic or glass plate within the red circle</p>	
<p>Ensure you use the recommended cookware</p> <ul style="list-style-type: none">a. Cookware with a bottom made of iron or stainless steelb. Cookware with a flat bottomc. Cookware with a bottom diameter of 12-20 cmd. Ensure that the total weight of the vessel plus the ingredients is not more than 8 kg.	
<p>Use the presets specified on the control panel or the manual settings to control the time and temperature for cooking</p>	
<p>Keep all the ingredients ready before you start cooking</p>	