

## ENGLISH

### Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](http://www.philips.com/welcome). This user manual contains information about the surprising features of this iron and some tips to make ironing easier and more enjoyable.

This iron is equipped with a special sensor-controlled handle and automatic energy-saving technology.

While you iron, the sensor in the handle ensures that the iron produces the optimal amount of steam. As 90% of the energy consumption of an iron is used to create steam, energy consumption is optimised by optimising the steam output. When you intuitively put more force on the handle to remove stubborn creases, the iron automatically produces more steam.

When you do not press the handle, when you lift the iron and when the iron is standing on its heel or on its soleplate without any movement, the automatic energy-saving technology limits the steam output to reduce energy consumption.

We hope you enjoy using this iron.

**Important**  
Read this user manual carefully before you use the appliance and save it for future reference.

### Danger

- Never immerse the iron in water.

### Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the mains cord or the appliance itself shows visible damage, or if the appliance has been dropped or leaks.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- Never leave the appliance unattended when it is connected to the mains.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not let the mains cord come into contact with the hot soleplate of the iron.
- Do not use the appliance if the flexible rubber handle parts show visible damage.

### Caution

- Only connect the appliance to an earthed wall socket.
- Check the mains cord regularly for possible damage.
- The soleplate of the iron can become extremely hot and may cause burns if touched.
- When you have finished ironing, when you clean the appliance, when you fill or empty the water tank and also when you leave the iron even for a short while: set the steam control to position 0, put the iron on its heel and remove the mains plug from the wall socket.
- Always place and use the iron on a stable, level and horizontal surface.
- Do not put perfume, vinegar, starch, descaling agents, ironing aids or other chemicals in the water tank.
- This appliance is intended for household use only.

### Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

### General description (Fig. 1)

- A Spray nozzle
- B Filling opening
- C Cap of filling opening
- D Steam boost button (φ)
- E Steam control
- CALC CLEAN = Calc-Clean function
- 0 = no steam
- ↔ = minimum steam
- ⊕ = maximum steam
- F Spray button (φ)
- G Red auto-off light (GC3660 only)
- H Temperature dial
- I Temperature light
- J Mains cord
- K Flexible rubber handle part
- L Anti-Calc tablet
- M Water tank
- N Heel
- Not shown: filling cup

### Before first use

1 Remove any sticker, protective foil or plastic from the soleplate (Fig. 2).

### Preparing for use

#### Filling the water tank

Do not put perfume, vinegar, starch, descaling agents, ironing aids or other chemicals in the water tank.

1 Make sure the appliance is unplugged.

2 Set the steam control to position 0 (= no steam) (Fig. 3).

3 Open the cap of the filling opening.

#### Filling the water tank

Do not put perfume, vinegar, starch, descaling agents, ironing aids or other chemicals in the water tank.

1 Make sure the appliance is unplugged.

4 Use the filling cup to fill the water tank with tap water up to the maximum level. Tilt the iron backwards to check if the water level has reached the MAX indication (Fig. 4).

Do not fill the water tank beyond the MAX indication.

5 Close the cap of the filling opening ('click').

### Setting the temperature

#### Temperature and steam settings

Fabric type	Temperature setting	Steam setting	Steam boost
Linen	MAX	⊕	Yes
Cotton	•••	⊕	Yes
Wool	••	↔	N.A.
Silk	•	0	N.A.
Synthetic fabrics (e.g. acrylic, nylon, polyamide, polyester)	•	0	N.A.

Check the laundry care label for the required ironing temperature.

If you do not know what kind or kinds of fabric an article is made of, determine the right ironing temperature by ironing a part that is not visible when you wear or use the article.

Silk, woolen and synthetic materials: iron the reverse side of the fabric to prevent shiny patches. To prevent stains, do not use the spray function.

Start ironing the articles that require the lowest ironing temperature, such as those made of synthetic fibers.

1 Put the iron on its heel.

2 Set the required ironing temperature, turn the temperature dial to the appropriate position (Fig. 5).

See table 'Temperature and steam settings'.

3 Put the mains plug in an earthed wall socket.

The temperature light goes on (Fig. 6).

4 When the temperature light goes out, wait a while before you start ironing.

Note: The temperature light goes on from time to time during ironing.

### Using the appliance

Note: The iron may give off some smoke when you use it for the first time. This stops after a short while.

### Sensor-controlled handle with energy-saving technology

While you iron, the sensor in the handle ensures that the iron produces the optimal amount of steam. As 90% of the energy consumption of an iron is used to create steam, energy consumption is optimised by optimising the steam output. When you intuitively put more force on the handle to remove stubborn creases, the iron automatically produces more steam.

When you do not press the handle, when you lift the iron and when the iron is standing on its heel or on its soleplate without any movement, the automatic energy-saving technology limits the steam output to reduce energy consumption (Fig. 7).

### Steam ironing

1 Make sure that there is enough water in the water tank.

2 Set the recommended ironing temperature (see chapter 'Preparing for use', table 'Temperature and steam settings').

3 Set the appropriate steam setting. Make sure that the steam setting is suitable for the set ironing temperature (see chapter 'Preparing for use', table 'Temperature and steam settings') (Fig. 8).

Note: The iron is ready for steam ironing as soon as it has reached the set ironing temperature.

Note: If the set ironing temperature is too low (MIN to ••), water may drip from the soleplate (see chapter 'Features', section 'Drip stop').

### Ironing without steam

1 Set the steam control to position 0 (= no steam) (Fig. 3).

2 Set the recommended ironing temperature (see chapter 'Preparing for use', table 'Temperature and steam settings').

3 Features

#### Spray function

You can use the spray function to remove stubborn creases at any temperature.

- 1 Make sure that there is enough water in the water tank.
- 2 Press the spray button several times to moisten the article to be ironed (Fig. 9).
- 3 Steam boost

A powerful steam boost helps to remove very stubborn creases. The steam boost function can only be used at temperature settings between ••• and MAX.

1 Press and release the steam boost button (Fig. 10).

#### Concentrated steam boost from the special Steam Tip (GC3640/GC3660 only)

The concentrated steam boost from the long vents in the Steam Tip enhances the distribution of steam into every part of your garment. The concentrated steam boost function can only be used at temperature settings between ••• and MAX.

1 Press and release the steam boost button (Fig. 11).

#### Vertical steam boost

You can also use the steam boost function when you hold the iron in vertical position. This is useful for removing creases from hanging clothes, curtains etc.

1 Hold the iron in vertical position and press and release the steam boost button (Fig. 12).

#### Drip stop

This iron is equipped with a drip-stop function: the iron automatically stops producing steam when the temperature is too low to prevent water from dripping out of the soleplate. When this happens, you may hear a sound.

#### Automatic shut-off function (specific types only)

The automatic shut-off function automatically switches off the iron if it has not been moved for a while.

1 The red auto-off light flashes to indicate that the iron has been switched off by the automatic shut-off function (Fig. 13).

To let the iron heat up again:

1 Pick up the iron or move it slightly.

2 The red auto-off light goes out.

3 If the temperature of the soleplate has dropped below the set ironing temperature, the temperature light goes on.

2 If the temperature light goes on after you have moved the iron, wait for it to go out before you start ironing.

Note: If the temperature light does not go on after you move the iron, the soleplate still has the right temperature and the iron is ready for use.

#### Cleaning and maintenance

##### Cleaning

1 Set the steam control to position 0, remove the mains plug from the wall socket and let the iron cool down.

2 Wipe flakes and any other deposits off the soleplate with a damp cloth and a non-abrasive (liquid) cleaning agent.

To keep the soleplate smooth, avoid hard contact with metal objects. Never use a scouring pad, vinegar, starch, descaling agents, ironing aids or other chemicals to clean the soleplate.

3 Clean the upper part of the iron with a damp cloth.

4 Regularly rinse the water tank with water. Empty the water tank after you have rinsed it (Fig. 14).

#### Double-Active Calc System

The Double-Active Calc System consists of an Anti-Calc tablet inside the water tank combined with the Calc-Clean function.

1 The Anti-Calc tablet prevents scale clogging the steam vents. This tablet is constantly active and does not need to be replaced (Fig. 15).

2 The Calc-Clean function removes the scale particles from the iron.

#### Calc-Clean function

Use the Calc-Clean function once every two weeks. If the water in your area is very hard (i.e. when flakes come out of the soleplate during ironing), use the Calc-Clean function more frequently.

1 Set the steam control to position 0 and remove the mains plug from the wall socket.

2 Fill the water tank to the maximum level.

Do not pour vinegar or other descaling agents in the water tank.

3 Set the temperature dial to MAX.

4 Put the mains plug in an earthed wall socket.

5 Unplug the iron when the temperature light goes out.

6 Hold the iron over the sink. Push the steam control to the CALC CLEAN position and hold it. Gently shake the iron to and fro (Fig. 16).

7 Steam and boiling water come out of the soleplate. Impurities and flakes (if any) are flushed out.

8 Release the steam control as soon as all the water in the tank has been used up.

9 Repeat the Calc-Clean process if the iron still contains a lot of impurities.

#### After the Calc-Clean process

1 Put the plug back into the wall socket and let the iron heat up to let the soleplate dry.

2 Do not pour vinegar or other descaling agents in the water tank.

3 Set the temperature dial to MAX.

4 Put the mains plug in an earthed wall socket.

5 Unplug the iron when the temperature light goes out.

6 Move the iron gently over a piece of used cloth to remove any water stains that may have formed on the soleplate.

7 Let the iron cool down before you store it.

#### Storage

1 Set the steam control to position 0, remove the mains plug from the wall socket and let the iron cool down.

2 Wind the mains cord round the cord storage facility (Fig. 17).

Note: Make sure that the mains cord does not press down the handle during storage.

3 Store the iron on its heel and dry place.

#### Environment

Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 18).

#### Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at [www.philips.com](http://www.philips.com) or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

#### Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Centre in your country.

#### Problem

#### Possible cause

#### Solution

The iron is plugged in, but the soleplate stays cold.

The temperature dial is set to MIN.

The iron does not produce any steam.

The steam control is set to position 0.

The iron is not hot enough and/or the drip-stop

