

Warranty and Service

For any information or problem, contact your local Philips dealer or authorized service center. For a list of authorized Philips service centers visit: www.philips.co.in or contact our consumer care at 1800 102 2929 (Toll free) or 1860 180 1111 (standard call rates apply)

Warranty Card

This apparatus is covered under warranty against any defect due to defective material or workmanship for TWO YEARS from the date of purchase. Should a defect develop during the period of warranty, Philips Domestic Appliances India Ltd. undertakes to repair the apparatus FREE OF CHARGE through the dealer from whom it has been purchased or at any of the Philips authorized Service Centres.

The warranty is not valid in case:

- 1.Apparatus is not used according to user manual.
- 2. Defects caused by improper or reckless use.
- 3. Repairs done by persons other than Philips Authorized service centre.
- 4. Modifications of any nature made in the apparatus.
- 5. Tampered serial number.
- 6. Incomplete warranty card after purchase.
- 7. Product if used for commercial purpose (i.e. other than domestic use).
- 8. Usage of parts not recommended by Philips or those made by other manufacturers.

All consumables and parts susceptible to normal wear and tear are not covered under warranty.

Week/S.No.
Date of Purchase _____
Dealer's Name: _____
Dealer's Stamp: _____
Customer's Name and Address: _____
Model No.: _____
Dealer's Signature: _____



www.philips.co.in



HL 7575



HL 7576

Juicer Mixer Grinder

Please read the guidelines provided in this DFU on Important instructions, Appliance Usage & Warranty before using the product.

PHILIPS

Always there to help

Register your product for further support at www.philips.co.in
Or Call 1800 102 2929(Toll free)
1860 180 1111 "Standard call rates apply"

Question? Contact Philips

In case these measures do not work, contact the nearest PHILIPS service center or call at customer care numbers. 1800 102 2929 (Toll free) or 1860 180 1111 "standard call rates apply"

Problem	Cause	Solution
1 Appliance does not work.	No electricity supply.	Ensure that the plug is plugged in well.
2 Appliance suddenly stops working while in use.	The appliance is equipped with an 'Over Load Protector' (OLP) switch. If appliance overheats, it automatically cuts off power supply.	Unplug the appliance and let it cool for 2-3 minutes. Remove jar from base unit. At the bottom of base unit there is a red coloured switch (OLP). Reset OLP by pressing it. Put plug back into wall socket and switch on appliance again (see heading 'Overload Protection').
3 Blade unit is blocked.	There may be fruit pieces stuck in the juicing unit or the sieve	Unplug the appliance, remove the juicer lid and remove any pieces of fruit that may have been lodged in the juicing unit or the sieve
	The quantity being processed is probably too large.	Switch off appliance. Remove ingredients that are blocking the blade unit. Refer the maximum capacity of jars table.
4 Base unit gives an unpleasant smell during first few times of use.	This is normal for the first few times.	If appliance continues to smell after using a few times: • Ensure that jars are clean and there are no ingredients stuck inside it. • Ensure that appliance has been assembled correctly.
5 Appliance makes a lot of noise.	Jars have not been properly locked. Blade is loose.	Make sure jar has been properly and tightly locked. Remove ingredients from jar and tighten the blade in anti-clockwise direction with spatula.
6 There are fumes from the appliance.	The sieve may not be properly fixed on the unit.	Unplug the appliance, remove the juicer cover and fix the sieve properly on the base unit.
	Clogging of sieve with pulp or fiber.	Unplug the appliance, remove the sieve, clean and reuse.
	Appliance may have been used for too long.	Switch off appliance and let it cool for 60 minutes.
7 Unsatisfactory grinding/ blending/ mixing performance.	Incorrect jar selection. Ingredients overloading in jar.	Use correct jar as per the application. Refer the maximum capacity of jars table.
8 Leakage from jar lid.	Large size of ingredients.	Cut ingredients into appropriate size.
	Gasket has not been fit properly.	Unplug appliance. Remove jar from base unit. Remove lid to check if gasket has been assembled correctly.

Trouble shooting

Introduction


Philips brings to you a range of juicer mixer grinders with 1 multipurpose jar and 1 blender jar (HL7575); and added chutney jar (only with HL7576)

Technical Specifications

Model No.	HL 7575 & HL 7576
Voltage	230V~50Hz
Wattage	600W max.
Motor	Universal motor
No load at max. speed	3 1900 rpm (approx.)
With load at max. speed	3 11500 rpm (approx.)
Speed Control	Rotary switch with 3 speed and incher
Insulation	Class F
Protection	Class II
Rating	Ordinary Total rated ON time 30 minutes (max.) Continuous ON for 5 minutes (max.) and Off for 2 minutes (min.)
Rest time	45 minutes

General description

- 1. Base unit:** The motor, speed switch, mains cord and overload protector switch through the chute while juicing.
- 10. Juicer cover:**
- 11. Online pulp chamber:** to collect the pulp left from the fruits.
- 12. Chutney jar with fixed blade:** for small quantity grinding such as chutney, pepper & dry masalas (only with HL7576).
- 5. Overload protection switch*:** red colored switch located at the base of the unit.
- 6. Sieve :** detachable for cleaning.
- 7. Spout:** detachable cleaning.
- 8. Juicer chamber :** provided with lock arrangement at both sides.



* red coloured switch located below the base of the unit

Important instructions

We recommend that you read the following instructions carefully, before using the appliance.

1. Check if the voltage indicated on the base of the appliance, corresponds to the local electrical mains voltage before connecting the appliance.

2. Do not use the appliance when the mains cord, the plug or other components are damaged. Only the company or a service centre authorized by Philips must replace it.

3. Always unplug the appliance after use.

4. Never immerse the motor unit in water.

5. Always unplug the appliance before reaching into the jar with your fingers or an object e.g. spatula.

6. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
9. Handle the blades carefully. Wash them under running water and do not rub with your hand.

10. Do not use appliance on wet surface

11. Do not run appliance for more than 30 minutes continuously.

12. Keep appliance away from hot gas burner, electric hot plate or similar appliances.

13. This appliance is strictly for household use.

14. Do not drop the main unit or jars.

15. Warranty will become invalid incase accessories or parts not recommended by Philips or those made by other manufacturers are used.

16. Do not use the jars as storage containers.

17. Do not leave unit unattended while in operation.




fig.1

7. Always ensure that speed selector knob is at '0' position before fixing accessories.


8. Do not operate the mixer without the lid in place or with an empty jar.

Quick Clean Guide for Juicer

1. Ensure all parts are cleaned immediately after use. Take out pulp chamber and empty it.

2. Disassemble the juicer clean juicer cover juicer chamber individually by using a soft brush or sponge under running water. Wipe the motor unit with a wet cloth. Note that spout can be detached.

3. Place cutter sieve under running water and clean using a soft brush. 'Do not rub with fingers'



How to assemble juicer

1. Set the base unit on a dry surface. Place the base unit with the control switch facing you.

2. Place the juicer housing on the base unit as shown in the unit

3. Press the cutter sieve on the motor coupler and push down until firmly in place.

4. Place the juicer cover onto the juicer housing with feeding chute positioned over the stainless steel cutter sieve and fit into position.

5. Secure the juicer cover by raising the twin locking handles and clip the tops of the juicer cover. Place your fingers on the top & the bottom of the lock & press firmly on the lower part till 'click' sound is heard to lock into place.

6. Slightly tilt the pulp chamber and slide into place under the juice chamber. Refer fig.2

7. Place a container under the spout for collecting the juice.




fig.2

Tips for good juicing

- Maximum juice extraction can be done with fresh fruits and vegetables. As far as possible, use fresh ingredients to make juice.

• For maximum juice extraction, clean the sieve and remove the pulp after 1 to 2 glasses of juice especially in case of hard fruits and vegetables like beetroot, apple and leafy vegetables like spinach.

• The thickness and amount of juice extracted also depends on the variety of fruits and vegetables. Example: the juicier the apple, the thinner the juice.

• You may remove the seeds from citrus fruits as they may give bitter taste to the juice when crushed in the juicer.

• When making mixed fruit or vegetable juice, juice the softer fruit/ vegetable first followed by the harder fruit/ vegetable.

- Example while making mix fruit juice, juice orange first followed by apple. Similarly while making mix vegetable juice, put tomato first, followed by carrots.

• If you want to add mint leaves or ginger to the juice, add it along with another fruit or vegetable for maximum output. For instance if you want to add mint, add it along with carrots or tomato.

• To get the maximum amount of juice, always press the pusher down firmly but slowly.

• Drink the juice immediately after extracting. Avoid keeping it for a long time.

• Your juicer is not suitable for processing very hard, fibrous or starchy fruits and vegetables.

Important instructions for juicer

1. Do not push fruit or vegetables into the feed chute with your fingers or spatula. Always use the food pusher provided.

2. If any fruit or vegetable lodges in the feed chute, use the food pusher or turn off the juicer, remove the plug from the power outlet and disassemble to remove the lodged fruit or vegetables.

3. Never operate without assembling the entire unit.

4. Ensure the juicer is correctly and completely assembled before turning the appliance "On". Do not unlock the twin locking handles while the juicer is in operation.

5. Cutter sieve blades are very sharp. Never run your fingers on the cutting edges of the cutter sieve, even while cleaning.

6. Do not use the appliance if the rotating sieve is damaged for centrifugal juices.

For blending/liquidizing/pureeing, use 'whip' on speed knob. This will activate the whipping till you release the button.

3. Multipurpose jar/Chutney jar/ Blender jar
After assembling the jar on the base unit, run the appliance on Juicing speed, II & III

4. Juicer

Always use juicer at speed Juicing. Cut fruits into smaller pieces to help pass through chute. Use pusher for pushing the fruits through the chute for juicing. For continued juicing, repeat the above mentioned procedure.

Overload protection

The juicer mixer is fitted with an automatic power shut off mechanism to avoid motor burning due to overloading. If juicer mixer stops due to overloading, the red knob at the bottom will come out. Switch off the mixer. Remove excess load from jar. Wait for 2-3 minutes. Press red knob and start juicer mixer grinder again.

How to fit jar to base unit

After fitting the blades carefully
Step 1 : Fit the jar on the base unit
Step 2 : Rotate clockwise
Step 3 : The appliance is ready to use when you hear a 'CLICK' sound.

Operation

1. Before the first use
Thoroughly clean parts that come in contact with food.

2. Preparation for use
Never use hot ingredients. Cool them down to 40°C before putting in the jar.

Cut large ingredients into small pieces of approx 2cm before processing.
Check speed selector knob is at '0' Connect mains plug to wall socket after fixing jar. Switch on main supply. Turn speed selector knob to required speed. After operation, turn selector knob '0' and check. Repeat till desired results are obtained.

Maximum jar capacities

No.	Type of jar	Rated capacity	Wet capacity (rated)	Dry capacity (rated)
1	Multipurpose jar	0.75L	0.30L	0.40L
2	Chutney jar (Only for HL7576)	0.30L	NA	0.17L
3	Blender jar	1.5L	0.50L (for all blending/pureeing)	NA

Standard recipes

No.	Recipe	Quantity	Procedure	Time
1	Urad dal (Multipurpose jar)	175g+400ml water (soaked for 6-8 hours)	Add the soaked ingredients to the jar with the water. Add 50ml water during grinding	1.5 min
2	Garam Masala (Multipurpose jar)	150 grams of assorted spices roasted and cooled	Heat ingredients in microwave at 600W for 1 + 1 + 1 minute. Toss ingredients between each heating	2 min
3	Tomato Onion paste (Wet masala) (Multipurpose jar)	100g tomatoes + 150g onions	Cut tomatoes and onions into 4s	1.5 min
4	Ginger garlic paste (Chutney jar) (Only for HL7576)	50g ginger + 50g garlic	Peel ginger and garlic. Cut ginger into 1 inch pieces	1.5 min
5	Banana/Cheeku/ Strawberry Milkshake (Blender jar)	300ml milk + 100g banana + 3tbsp sugar	Cut fruit and add it to the milk along with sugar	1 min
6	Pomegranate	500gms	Remove the peel and de-seed the pomegranate	Run on speed1'Juicing' for 2.5-3 min. until you finish juicing
7	Carrot/Beetroot	500gms	Peel and cut into small pieces to fit through the chute	Run on speed1'Juicing' for 2.5-3 min. until you finish juicing

Note:

1. Use Speed I (JUICING) for juicing for fruits and vegetables

2. You can use a wide range of fruits and vegetables in this juicer. However, it is not possible to juice fibrous, starchy or very hard fruits and vegetables like mango, cheeku, banana, amla, aloe vera, sugarcane and wheatgrass. After juicing once, let the appliance cool down before you use it again.

3. Recommended speed: for Wet/dry/chutney grinding/blending, liquidizing, pureeing, start with Speed I (Juicing) and Speed II for 10-15 sec and continue on Speed III till you finish grinding

4. If you need to process more than 500gms of any fruit/vegetable, Switch off the unit and empty the pulp chamber and then continue juicing.

5. Recommend removing seeds from citrus fruits like Orange/Sweet lime to avoid any bitterness in the juice

6. Other fruits recommended for Juicing – Apple, Pineapple, Watermelon, Bittergourd, Bottlegourd, Spinach