



PHILIPS
HD3030

EN User manual MY အသုံးပြုမှု လမ်းညွှန်စာတမ်း
HI अन्वेषण निर्देश TH คู่มือการใช้งาน
ID Buku Petunjuk Pengguna VI Hướng dẫn sử dụng
MN Хэрэглэхийн гарам засах ZH-S 用户手册
MS Manual pengguna



©2019 Koninklijke Philips N.V. All rights reserved.
HD3030_UJ_Asean_v6.0

English

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.Philips.com/welcome.

1 What's in the box

Fuzzy rice cooker main unit Steam basket
Rice scoop Soup ladle
Measuring cup User manual
Safety leaflet Warranty card
Power cord

Overview	
① Fuzzy rice cooker main unit	⑩ Lid release button
② Power cord	⑪ Control panel
③ Rice scoop	⑫ Main body
④ Soup ladle	⑬ Power plug
⑤ Steam basket	⑭ Heating element
⑥ Measuring cup	⑮ Water level Indicators
⑦ Top lid	⑯ Cooker handle
⑧ Sealing ring	⑰ Inner lid
⑨ Inner pot	⑱ Detachable steam vent cap

Controls overview	
① Preset time	⑫ Cook time
② Time adjust	⑬ Reheat
③ Quick cook	⑭ Off/Warm
④ Congee/Soup	⑮ Standard cook

Before first use

- Take out all the accessories from the inner pot. Remove the sheet between the inner pot and the heating element.
- Clean the parts of the rice cooker thoroughly before using the rice cooker for the first time (see chapter "Cleaning and Maintenance").

Note	
<ul style="list-style-type: none"> Make sure all parts are completely dry before you start using the rice cooker. 	

Preparations before use

- Measure the rice using the measuring cup provided.
- Wash the rice thoroughly.
- Put the pre-washed rice in the inner pot.
- Add water to the level indicated on the scale inside the inner pot. This corresponds to the number of cups of rice used. Then smooth the rice surface.
- Press the leveler to open the lid.
- Put the inner pot in the rice cooker. Check if the inner pot is in proper contact with the heating element.
- Close the lid of the rice cooker, put the plug in the power socket.

Note	
<ul style="list-style-type: none"> Each cup of uncooked rice normally gives 2 bowls of cooked rice. Do not exceed the quantities indicated on the inside of the inner pot. The level marked inside the inner pot is just an indication. You can always adjust the water level for different types of rice and your own preference. If the voltage is unstable at the area you live in, it is possible that the rice cooker overflows. Besides following the water level indicators, you can also add rice and water at 1:1-1.2 ratio for rice cooking. Do not exceed the quantities indicated on the inside of the inner pot. Make sure that the outside of the inner pot is dry and clean, and that there is no foreign residue on the heating element or the magnetic switch. 	

Rice cooking

There are two rice cooking functions for HD3030.

Cooking function	Estimated cooking time for 6 cups of rice
Standard cook (☰)	50 minutes
Quick cook (⊕)	38 minutes

Note	
<ul style="list-style-type: none"> Follow the same steps for Quick cook (⊕). Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. 	

Cooking function	Estimated cooking time
Cooking congee (⊕)	1 hour (for 1 cup of rice)

Note	
<ul style="list-style-type: none"> Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. It is normal to find the congee more stickier if it left in keep warm mode for too long. 	

Tip	
<ul style="list-style-type: none"> Default cooking time is 1 hour. 	

Cooking function	Estimated cooking time
Reheating (⊕)	25 minutes

What's in the box
Apa dalam kotak ini

എന്താണ് ബോക്സിലുള്ളത്
എന്താണ് ബോക്സിലുള്ളത്

Apa saja isi kemasaannya
mahlisatiasa'na

Хайрцаг юу байна эх
Төвөг ний юу байна

包装盒内物品

PHILIPS

Pre-set time

Time adjust

Quick cook

Congee/Soup

Cook time

Off Warm

Reheat

PHILIPS

Note	
<ul style="list-style-type: none"> You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. 	

Pre-set time for delayed cooking
You can preset the delayed cooking time for rice, congee, and soup. The preset timer is available up to 24 hours.

Note	
<ul style="list-style-type: none"> Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. Once the rice cooker enters preset mode, the preset time button (☰) will not respond. You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. 	

2 Cleaning and Maintenance

Note	
<ul style="list-style-type: none"> Unplug the rice cooker before starting to clean it. Wait until the rice cooker has cooled down sufficiently before cleaning it. 	

Interior

- Inside of the outer lid and the main body.
- Wipe with wrung out and damp cloth.
- Make sure to remove all the food residues stuck to the rice cooker.
- Use a soft brush to clean the inner pot.
- Remove food residues with wrung out and damp cloth or toothpicks.

Note	
<ul style="list-style-type: none"> Unplug the rice cooker before starting to clean it. ONLY use soft and dry cloth to wipe the control panel. Make sure to remove all the food residues around the control buttons. 	

Accessories

- Rice scoop, soup ladle, inner pot, steam basket, and steam vent cap.
- Soak in hot water and clean with sponge.

3 Environment

- Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.
- Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

4 Guarantee and service

If you need service or information, or if you have a problem, visit the Philips website at www.philips.com or contact the Philips Customer Care Center in your country. You can find its phone number in the worldwide guarantee leaflet. If there is no "Customer Care Center in your country, go to your local Philips dealer.

Problem	Solution
The lights on the buttons does not go on.	There is a connection problem. Check if the power cord is connected to the cooker properly and if the plug is inserted firmly into the power outlet.
The light is defective.	Take the appliance to your Philips dealer or a service center authorized by Philips.
The display shows error message.	The rice cooker is not connected to the power supply. If there is no power supply, the power failure backup function does not work and the display does not function.
The display shows error message.	The battery for the display runs out of power. Take the appliance to your Philips dealer or a service center authorized by Philips to have the battery replaced.
The rice is not cooked.	Make sure that there is no foreign residue on the heating element and the outside of the inner pot after switching the rice cooker on.
The cooker does not switch to keep warm mode automatically.	The temperature control is defective. Take the appliance to your Philips dealer or a service center authorized by Philips.
The rice is scorched.	You have not rinsed the rice properly. Rinse the rice until water runs clear.
Water spills out of the rice cooker during cooking.	<ul style="list-style-type: none"> Make sure that you add water to the level indicated on the scale inside the inner pot that corresponds to the number of cups of rice used. Make sure the water does not exceed the next level on the scale, as this may cause the rice cooker to overflow during cooking.
Rice smells bad after cooking.	Clean the inner pot with some washing detergent and warm water.
Error message (E1, E2, E3, or E4) appears on the display.	After cooking, make sure the steam vent cap, inner lid and inner pot is clean, and there is no foreign residue on the display.

Note	
<ul style="list-style-type: none"> Follow the same steps for Quick cook (⊕). Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. It is normal to find the congee more stickier if it left in keep warm mode for too long. 	

Tip	
<ul style="list-style-type: none"> Default cooking time is 1 hour. 	

Cooking function	Estimated cooking time
Reheating (⊕)	25 minutes

Using the fuzzy rice cooker
Menggunakan pem masak nasi fuzzy
Menganalisis pem masak nasi fuzzy
使用模糊控制电饭煲

உயர்வாக ஊதாபருவியை பயன்படுத்தி அரிசி சமைக்கவும்
Указав режим варки ариши, вы получите более вкусный результат

What's in the box
Apa dalam kotak ini

Fuzzy rice cooker main unit Steam basket
Rice scoop Soup ladle
Measuring cup User manual
Safety leaflet Warranty card
Power cord

Overview	
① Fuzzy rice cooker main unit	⑩ Lid release button
② Power cord	⑪ Control panel
③ Rice scoop	⑫ Main body
④ Soup ladle	⑬ Power plug
⑤ Steam basket	⑭ Heating element
⑥ Measuring cup	⑮ Water level Indicators
⑦ Top lid	⑯ Cooker handle
⑧ Sealing ring	⑰ Inner lid
⑨ Inner pot	⑱ Detachable steam vent cap

Note	
<ul style="list-style-type: none"> Make sure all parts are completely dry before you start using the rice cooker. 	

Before first use

- Take out all the accessories from the inner pot. Remove the sheet between the inner pot and the heating element.
- Clean the parts of the rice cooker thoroughly before using the rice cooker for the first time (see chapter "Cleaning and Maintenance").

Note	
<ul style="list-style-type: none"> Make sure all parts are completely dry before you start using the rice cooker. 	

Preparations before use

- Measure the rice using the measuring cup provided.
- Wash the rice thoroughly.
- Put the pre-washed rice in the inner pot.
- Add water to the level indicated on the scale inside the inner pot. This corresponds to the number of cups of rice used. Then smooth the rice surface.
- Press the leveler to open the lid.
- Put the inner pot in the rice cooker. Check if the inner pot is in proper contact with the heating element.
- Close the lid of the rice cooker, put the plug in the power socket.

Note	
<ul style="list-style-type: none"> Each cup of uncooked rice normally gives 2 bowls of cooked rice. Do not exceed the quantities indicated on the inside of the inner pot. The level marked inside the inner pot is just an indication. You can always adjust the water level for different types of rice and your own preference. If the voltage is unstable at the area you live in, it is possible that the rice cooker overflows. Besides following the water level indicators, you can also add rice and water at 1:1-1.2 ratio for rice cooking. Do not exceed the quantities indicated on the inside of the inner pot. Make sure that the outside of the inner pot is dry and clean, and that there is no foreign residue on the heating element or the magnetic switch. 	

Cooking function	Estimated cooking time for 6 cups of rice
Standard cook (☰)	50 minutes
Quick cook (⊕)	38 minutes

Note	
<ul style="list-style-type: none"> Follow the same steps for Quick cook (⊕). Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. It is normal to find the congee more stickier if it left in keep warm mode for too long. 	

Cooking function	Estimated cooking time
Cooking congee (⊕)	1 hour (for 1 cup of rice)

Note	
<ul style="list-style-type: none"> Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. It is normal to find the congee more stickier if it left in keep warm mode for too long. 	

Cooking function	Estimated cooking time
Reheating (⊕)	25 minutes

Rice cooking
Rice cooking
Rice cooking

உயர்வாக ஊதாபருவியை பயன்படுத்தி அரிசி சமைக்கவும்
Указав режим варки ариши, вы получите более вкусный результат

Using the fuzzy rice cooker
Menggunakan pem masak nasi fuzzy
Menganalisis pem masak nasi fuzzy
使用模糊控制电饭煲

உயர்வாக ஊதாபருவியை பயன்படுத்தி அரிசி சமைக்கவும்
Указав режим варки ариши, вы получите более вкусный результат

What's in the box
Apa dalam kotak ini

Fuzzy rice cooker main unit Steam basket
Rice scoop Soup ladle
Measuring cup User manual
Safety leaflet Warranty card
Power cord

Overview	
① Fuzzy rice cooker main unit	⑩ Lid release button
② Power cord	⑪ Control panel
③ Rice scoop	⑫ Main body
④ Soup ladle	⑬ Power plug
⑤ Steam basket	⑭ Heating element
⑥ Measuring cup	⑮ Water level Indicators
⑦ Top lid	⑯ Cooker handle
⑧ Sealing ring	⑰ Inner lid
⑨ Inner pot	⑱ Detachable steam vent cap

Note	
<ul style="list-style-type: none"> Make sure all parts are completely dry before you start using the rice cooker. 	

Before first use

- Take out all the accessories from the inner pot. Remove the sheet between the inner pot and the heating element.
- Clean the parts of the rice cooker thoroughly before using the rice cooker for the first time (see chapter "Cleaning and Maintenance").

Note	
<ul style="list-style-type: none"> Make sure all parts are completely dry before you start using the rice cooker. 	

Preparations before use

- Measure the rice using the measuring cup provided.
- Wash the rice thoroughly.
- Put the pre-washed rice in the inner pot.
- Add water to the level indicated on the scale inside the inner pot. This corresponds to the number of cups of rice used. Then smooth the rice surface.
- Press the leveler to open the lid.
- Put the inner pot in the rice cooker. Check if the inner pot is in proper contact with the heating element.
- Close the lid of the rice cooker, put the plug in the power socket.

Note	
<ul style="list-style-type: none"> Each cup of uncooked rice normally gives 2 bowls of cooked rice. Do not exceed the quantities indicated on the inside of the inner pot. The level marked inside the inner pot is just an indication. You can always adjust the water level for different types of rice and your own preference. If the voltage is unstable at the area you live in, it is possible that the rice cooker overflows. Besides following the water level indicators, you can also add rice and water at 1:1-1.2 ratio for rice cooking. Do not exceed the quantities indicated on the inside of the inner pot. Make sure that the outside of the inner pot is dry and clean, and that there is no foreign residue on the heating element or the magnetic switch. 	

Cooking function	Estimated cooking time for 6 cups of rice
Standard cook (☰)	50 minutes
Quick cook (⊕)	38 minutes

Note	
<ul style="list-style-type: none"> Follow the same steps for Quick cook (⊕). Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. It is normal to find the congee more stickier if it left in keep warm mode for too long. 	

Cooking function	Estimated cooking time
Cooking congee (⊕)	1 hour (for 1 cup of rice)

Note	
<ul style="list-style-type: none"> Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. You can press the cancel button (⊖) or unplug the rice cooker to turn off the keep warm function or when not in use. It is normal to find the congee more stickier if it left in keep warm mode for too long. 	

Cooking function	Estimated cooking time
Reheating (⊕)	25 minutes

Rice cooking
Rice cooking
Rice cooking

உயர்வாக ஊதாபருவியை பயன்படுத்தி அரிசி சமைக்கவும்
Указав режим варки ариши, вы получите более вкусный результат

Using the fuzzy rice cooker
Menggunakan pem masak nasi fuzzy
Menganalisis pem masak nasi fuzzy
使用模糊控制电饭煲

உயர்வாக ஊதாபருவியை பயன்படுத்தி அரிசி சமைக்கவும்
Указав режим варки ариши, вы получите более вкусный результат

What's in the box
Apa dalam kotak ini

Fuzzy rice cooker main unit Steam basket
Rice scoop Soup ladle
Measuring cup User manual
Safety leaflet Warranty card
Power cord

Overview	
① Fuzzy rice cooker main unit	⑩ Lid release button
② Power cord	⑪ Control panel
③ Rice scoop	⑫ Main body
④ Soup ladle	⑬ Power plug
⑤ Steam basket	⑭ Heating element
⑥ Measuring cup	⑮ Water level Indicators
⑦ Top lid	⑯ Cooker handle
⑧ Sealing ring	⑰ Inner lid
⑨ Inner pot	⑱ Detachable steam vent cap

Note	
<ul style="list-style-type: none"> Make sure all parts are completely dry before you start using the rice cooker. 	

Before first use

- Take out all the accessories from the inner pot. Remove the sheet between the inner pot and the heating element.
- Clean the parts of the rice cooker thoroughly before using the rice cooker for the first time (see chapter "Cleaning and Maintenance").

Note	
<ul style="list-style-type: none"> Make sure all parts are completely dry before you start using the rice cooker. 	

Preparations before use

- Measure the rice using the measuring cup provided.
- Wash the rice thoroughly.
- Put the pre-washed rice in the inner pot.
- Add water to the level indicated on the scale inside the inner pot. This corresponds to the number of cups of rice used. Then smooth the rice surface.
- Press the leveler to open the lid.
- Put the inner pot in the rice cooker. Check if the inner pot is in proper contact with the heating element.
- Close the lid of the rice cooker, put the plug in the power socket.

Note	
<ul style="list-style-type: none"> Each cup of uncooked rice normally gives 2 bowls of cooked rice. Do not exceed the quantities indicated on the inside of the inner pot. The level marked inside the inner pot is just an indication. You can always adjust the water level for different types of rice and your own preference. If the voltage is unstable at the area you live in, it is possible that the rice cooker overflows. Besides following the water level indicators, you can also add rice and water at 1:1-1.2 ratio for rice cooking. Do not exceed the quantities indicated on the inside of the inner pot. Make sure that the outside of the inner pot is dry and	

