

Quick Start Card

HD4763 / HD4761

Start cooking



1. Turn the lid lock lever to LOCK position.
2. Press the MENU/TASTE CONTROL button.
3. Select 'Plain rice'.
4. Press the START/REHEAT button.



The cooking icon and the remaining cooking time appear on the display.



3 minutes before the cooking process ends, the appliance beeps and then steam is released.




At the end of the cooking process the appliance beeps. The KEEP WARM light goes on.

Taste selection (Rice menu)



Press the MENU/TASTE button. Select a rice menu.



Press the START/REHEAT button to start cooking (1). Press the MENU/TASTE CONTROL button within 10 seconds to change the taste (2).



Select a taste (soft, regular or hard). It will not be activated in Quick plain rice, keep-warm mode, timer mode or reheate mode.



Press the START/REHEAT button to confirm.


Cancel - Interrupting a cooking process



Press and hold the KEEP WARM/CANCEL button for 3 seconds.



The KEEP WARM/CANCEL light starts to flash and the cooling down time of 30 minutes appears on the display.



At the end of these 30 minutes the rice cooker beeps and the steam is released.



Turn the lid lock lever to UNLOCK position and press the lid release button to open the lid.

Auto Clean - Cleans the steam vent and the pressure regulator



Pour 2 cups of water into the inner pot. Close the lid and turn the lid lock lever to LOCK position.



Press the AUTO CLEAN button.
Press the START/REHEAT button.



During the Auto Clean process the appliance beeps and then steam is released. The START light goes on, the text 'Auto Clean' and the remaining cleaning time appear on the display.



At the end of the Auto Clean process the appliance beeps again and switches off.

Adjust cooking time for various menus (congee, soup, stew and steam menu)



Press the MENU/TASTE CONTROL button to select the cooking mode. The default cooking time appears on the display.



Press the HR button once to move the hour indication forward by 1 hour. Press the MIN button once to put the minute indication forward by 1 minute. Press and hold the MIN button to move the minute indication forward in steps of 5 minutes.



Press the START/REHEAT button to start cooking.