

ENGLISH

General description (Fig. 1)

- 1 Spray nozzle
- 2 Cap of filling opening
- 3 Steam control
- **CALC CLEAN** = Calc-Clean function
- ☂ = dry ironing
- **ECO** = optimal steam
- ☁ = maximum steam
- ☀ = turbo steam
- 4 Steam boost button
- 5 Spray button
- 6 Temperature dial
- 7 Temperature light (specific types only: with safety-auto off indication)
- 8 Mains cord
- 9 Type plate
- 10 Water tank with MAX water level indication
- 11 Soleplate

Using the appliance

Filling the water tank

Note: Your appliance has been designed to be used with tap water. If you live in an area with very hard water, fast scale build-up may occur. In this case, it is recommended to mix 50% distilled water and 50% tap water to prolong the lifetime of your appliance.

Note: Do not put perfume, vinegar, starch, descaling agents, ironing aids, chemically descaled water or other chemicals in the water tank.

1 Set the steam control to position ☂ (dry ironing). (Fig. 2)

2 Fill the water tank up to the MAX indication (Fig. 3).

3 Close the cap of the filling opening.

Selecting temperature and steam setting

Table 1

| Fabric type | Temperature setting | Steam setting | Steam boost | Spray |
|--|---------------------|---------------|-------------|-------|
| Linen | MAX | ☁, ☀ | Yes | Yes |
| Cotton | ●●● | ☁, ☀ | Yes | Yes |
| Wool | ●● | ECO | No | Yes |
| Silk | ● | ☒ | No | No |
| Synthetic fabrics (e.g. acrylic, nylon, polyamide, polyester) | ● | ☒ | No | No |

1 Consult table 1 to set the temperature dial to the appropriate setting for your garment (Fig. 4).

2 Put the iron on its heel and plug it in. The temperature light goes on to indicate that the iron is heating up (Fig. 5).

3 When the temperature light goes out, the iron has reached the correct temperature.

4 Consult table 1 to select a steam setting that corresponds to the temperature you have set (Fig. 6).

Note: To use turbo steam ☀, keep the steam control pressed to the turbo steam position ☀ continuously.

Caution: Do not set the steam control to a steam setting if the set temperature is below ●● or when the iron is still heating up (when the temperature light is on). Otherwise water may leak from the iron.

Features

Spray function

- Press the spray button to moisten the article to be ironed. This helps remove stubborn creases (Fig. 7).

Steam boost function

- Press and release the steam boost button for a powerful boost of steam to remove stubborn creases (Fig. 8).

Vertical steam

- You can use the steam boost function when you hold the iron in vertical position for removing creases from hanging clothes, curtains etc (Fig. 9).

Safety auto-off function (specific types only)

- The iron switches off automatically if it has not been moved for 30 seconds in horizontal position or 8 minutes in vertical position. The auto-off light starts flashing (Fig. 10).
- To let the iron heat up again, pick up the iron or move it slightly until the auto-off light goes out.

EKO steam setting

- Select the **ECO** steam setting instead of the maximum steam setting ☁ to save energy, yet to achieve satisfactory ironing results. (Fig. 11)

Dry ironing

- Set the steam control to ☂ (dry ironing) to iron without steam. (Fig. 2)

Cleaning and maintenance

Cleaning

1 Set the steam control to ☂ (dry ironing), unplug the iron and let it cool down. (Fig. 2)

2 Pour any remaining water out of the water tank.

3 Wipe flakes and any other deposits off the soleplate with a damp cloth and a non-abrasive (liquid) cleaning agent.

Caution: To keep the soleplate smooth, avoid hard contact with metal objects. Never use a scouring pad, vinegar or other chemicals to clean the soleplate.

Note: Regularly rinse the water tank with tap water. Empty the water tank after rinsing it.

Calc-Clean function

IMPORTANT: To prolong the lifetime of your appliance and to maintain good steaming performance, use the Calc-Clean function once every two weeks. If the water in your area is very hard (i.e. when flakes come out of the soleplate during ironing), use the Calc-Clean function more frequently.

1 Make sure the appliance is unplugged and the steam control is set to ☂ (dry ironing). (Fig. 2)

2 Fill the water tank to the MAX indication (Fig. 3).

Do not pour vinegar or other descaling agents into the water tank.

3 Plug in the iron and set the temperature dial to MAX (Fig. 12).

4 Unplug the iron when the temperature light goes out.

5 Hold the iron over the sink. Push the steam control to the Calc-Clean position and hold it (Fig. 13).

6 Gently shake the iron until all water in the water tank has been used up (Fig. 14).

Caution: While scale is flushed out, steam and boiling water also come out of the soleplate.

7 Set the steam control back to ☂ (dry ironing). (Fig. 2)

Note: Repeat the Calc-Clean process if the water that comes out of the iron still contains scale particles.

After the Calc-Clean process

1 Plug in the iron. Let the iron heat up to let the soleplate dry.

2 Unplug the iron when the temperature light goes out.

3 Move the iron gently over a piece of cloth to remove any water stains on the soleplate.

4 Let the iron cool down before you store it.

Storage

1 Unplug the iron and set the steam control to ☂ (dry ironing). (Fig. 2)

2 Wind the mains cord round the cord storage facility and store the iron on its heel (Fig. 15).

Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, visit www.philips.com/support for a list of frequently asked questions or contact the Consumer Care Centre in your country (see the worldwide guarantee leaflet for contact details).

| Problem | Possible cause | Solution |
|--|---|---|
| Water drips from the soleplate or wet spots appear on the garment during ironing. | The set temperature is too low for steam ironing. | Set an ironing temperature that is suitable for steam ironing. See table 1. |
| | You have put an additive in the water tank. | Rinse the water tank and do not put any additive in the water tank. |
| The steam boost function does not work properly (water leaks out of the soleplate). | You have used the steam boost function too often within a very short period. | Wait a while before you use the steam boost function again. |
| | You have used the steam boost function at a too low temperature. | Set an ironing temperature at which the steam boost function can be used (●● to MAX). |
| Flakes and impurities come out of the soleplate during ironing. | Hard water forms flakes inside the soleplate. | Use the Calc-Clean function (see chapter 'Cleaning and maintenance', section 'Calc-Clean function'). |
| Water drips from the soleplate after the iron has cooled down or has been stored. | You have put the iron in horizontal position while there was still water in the water tank. | Empty the water tank and set the steam control to position 'dry' after use. Store the iron on its heel. |
| Water leaks from the cap of the filling opening. | You have overfilled the water tank. | Do not fill the water tank beyond the MAX indication. Pour excess water out of the water tank. |
| When I push the steam control to the turbo steam position, the steam control jumps back. | You did not keep the steam control in the turbo steam position. | If you want to use turbo steam, you have to keep the steam control in the turbo steam position continuously. For other steam settings, this is not necessary. |

PORUGUÊS

Descrição geral (fig. 1)

- 1 Bocal de pulverização
- 2 Tampa da abertura para enchimento
- 3 Controlo do vapor
- **CALC CLEAN** = Função Calc-Clean
- ☂ = passar a ferro a seco
- **ECO** = vapor optimizado
- ☁ = vapor máximo
- ☀ = super vapor
- 4 Botão do jacto de vapor
- 5 Botão de pulverização
- 6 Botão da temperatura
- 7 Luz da temperatura (apenas modelos específicos: com indicação de desactivação automática de segurança)
- 8 Cabo de alimentação
- 9 Placa de identificação
- 10 Reservatório da água com indicação do nível MAX da água
- 11 Base

Utilizar o aparelho

Encher o depósito da água

Nota: O seu aparelho foi concebido para ser utilizado com água canalizada. Se viver numa área com água muito dura, pode ocorrer uma acumulação muito rápida de calcário. Neste caso, recomendamos uma mistura de 50% de água destilada e 50% de água canalizada para prolongar a vida útil do seu aparelho.

Nota: Não deite perfume, vinagre, goma, agentes descalcificantes, aditivos, água descalcificada quimicamente ou outras produtos químicos no reservatório da água.

1 Defina o controlo do vapor para a posição ☂ (passar a ferro a seco). (fig. 2)

2 Encha o depósito com água até à indicação MAX (fig. 3).

3 Feche a tampa da abertura de enchimento.

Seleccionar a definição de temperatura e vapor

Tabela 1

| Tipo de tecido | Regulação da temperatura | Regulação do vapor | Jacto de vapor | Borrifador |
|--|--------------------------|--------------------|----------------|------------|
| Linho | MÁX | ☁, ☀ | Sim | Sim |
| Algodão | ●●● | ☁, ☀ | Sim | Sim |
| Lã | ●● | ECO | Não | Sim |
| Seda | ● | ☒ | Não | Não |
| Tecidos sintéticos (p.ex.: acrílico, nylon, poliamida, poliéster) | ● | ☒ | Não | Não |

1 Consulte a tabela 1 para definir o botão da temperatura para a regulação apropriada para a sua peça de roupa (fig. 4).

2 Coloque o ferro sobre o seu descanso e ligue a respectiva ficha. A luz da temperatura acende-se para indicar que o ferro está a aquecer (fig. 5).

3 Quando a luz da temperatura se apaga, o ferro alcançou a temperatura correcta.

4 Consulte a tabela 1 para seleccionar uma regulação de vapor que corresponda à temperatura que definiu (fig. 6).

Nota: Para utilizar o super turbo ☀, mantenha o controlo do vapor premido continuamente na posição de super vapor ☀.

Atenção: Não defina o controlo do vapor para uma regulação com vapor.

Quando a temperatura definida for inferior a ●● nem quando o ferro ainda estiver a aquecer (quando a luz de temperatura está acesa). Caso contrário, o ferro pode verter água.

5 Consulte a tabela 1 para definir o botão da temperatura para a regulação apropriada para a sua peça de roupa (fig. 4).

6 Coloque o ferro sobre o seu descanso e ligue a respectiva ficha. A luz da temperatura acende-se para indicar que o ferro está a aquecer (fig. 5).

7 Quando a luz da temperatura se apaga, o ferro alcançou a temperatura correcta.

8 Consulte a tabela 1 para seleccionar uma regulação de vapor que corresponda à temperatura que definiu (fig. 6).

Nota: Para utilizar o super turbo ☀, mantenha o controlo do vapor premido continuamente na posição de super vapor ☀.

Atenção: Não defina o controlo do vapor para uma regulação com vapor.

Quando a temperatura definida for inferior a ●● nem quando o ferro ainda estiver a aquecer (quando a luz de temperatura está acesa). Caso contrário, o ferro pode verter água.

9 Quando a luz da temperatura se apaga, o ferro alcançou a temperatura correcta.

10 Consulte a tabela 1 para definir o botão da temperatura para a regulação apropriada para a sua peça de roupa (fig. 4).

11 Coloque o ferro sobre o seu descanso e ligue a respectiva ficha. A luz da temperatura acende-se para indicar que o ferro está a aquecer (fig. 5).

12 Quando a luz da temperatura se apaga, o ferro alcançou a temperatura correcta.

13 Consulte a tabela 1 para definir o botão da temperatura para a regulação apropriada para a sua peça de roupa (fig. 4).

14 Coloque o ferro sobre o seu descanso e ligue a respectiva ficha. A luz da temperatura acende-se para indicar que o ferro está a aquecer (fig. 5).

15 Quando a luz da temperatura se apaga, o ferro alcançou a temperatura correcta.

Função Calc-Clean (limpeza do calcário)