

# Always there to help you

Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)



AC4012

AC4014



---

EN User manual

3

---

ZH-TW 使用手冊

22

---

# PHILIPS



# Contents

<b>1 Important</b>	4	<b>11 Notices</b>	20
Safety	4	Electromagnetic fields (EMF)	20
		Compliance with EMF	20
		Recycling	20
<b>2 Your air purifier</b>	6		
What's in the box	6		
<b>3 Getting started</b>	7		
Install filters	7		
<b>4 Using the air purifier</b>	9		
Understand the air quality light	9		
Understand the healthy air protect alert	9		
Switch on	9		
Set the sensitivity of the air quality sensor	10		
Change the fan speed	10		
Manual	10		
Set the timer	12		
<b>5 Cleaning your air purifier</b>	13		
Clean the air purifier	13		
Clean the air quality sensor	13		
<b>6 Cleaning the pre-filter</b>	14		
<b>7 Replacing the filters</b>	16		
Replace the activated carbon filter and the HEPA filter	16		
<b>8 Resetting the filter lifetime counter</b>	18		
<b>9 Troubleshooting</b>	19		
<b>10 Guarantee and service</b>	20		
Order parts or accessories	20		

# 1 Important

---

## Safety

Read this user manual carefully before you use the appliance, and save it for future reference.

### Danger

- Do not let water or any other liquid or flammable detergent enter the appliance to avoid electric shock and/or a fire hazard.
- Do not clean the appliance with water, any other liquid, or a (flammable) detergent to avoid electric shock and/or a fire hazard.

### Warning

- Check if the voltage indicated on the bottom or indicated at the rear of the appliance corresponds to the local power voltage before you connect the appliance.
- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips, or similarly qualified persons in order to avoid a hazard.
- Do not use the appliance if the plug, the power cord, or the appliance itself is damaged.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and maintenance shall not be made by children without supervision.
- Do not block the air inlet and outlet, e.g. by placing items on the air outlet or in front of the air inlet.

### Caution

- This appliance is not a substitute for proper ventilation, regular vacuum cleaning, or use of an extractor hood or fan while cooking.
- If the power socket used to power the appliance has poor connections, the plug of the appliance becomes hot. Make sure that you plug the appliance into a properly connected power socket.
- Always place and use the appliance on a dry, stable, level, and horizontal surface.
- Leave at least 20cm free space behind and on both sides of the appliance and leave at least 30cm free space above the appliance.
- Do not place anything on top of the appliance and do not sit on the appliance.
- Do not place the appliance directly below an air conditioner to prevent condensation from dripping onto the appliance.
- Make sure all filters are properly installed before you switch on the appliance.
- Only use the original Philips filters specially intended for this appliance. Do not use any other filters.
- Avoid knocking against the appliance (the air inlet and outlet in particular) with hard objects.
- Always lift or move the appliance by the handle at the back of the appliance.
- Do not insert your fingers or objects into the air outlet.
- Do not use this appliance when you have used indoor smoke-type insect repellents or in places with oily residues, burning incense, or chemical fumes.
- Do not use the appliance near gas appliances, heating devices or fireplaces.
- Always unplug the appliance after use and before you clean it.
- Do not use the appliance in a room with major temperature changes, as this may cause condensation inside the appliance.
- To prevent interference, place the appliance at least 2m away from electrical appliances that use airborne radio waves such as TVs, radios, and radio-controlled clocks.


- The appliance is only intended for household use under normal operating conditions.
- Do not use the appliance in wet surroundings or in surroundings with high ambient temperatures, such as the bathroom, toilet, or kitchen.
- The appliance does not remove carbon monoxide (CO) or radon (Rn). It cannot be used as a safety device in case of accidents with combustion processes and hazardous chemicals.

# 2 Your air purifier

Congratulations on your purchase, and welcome to Philips!  
To fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](http://www.philips.com/welcome).  
Read this user manual carefully before you install and use the unit. Save it for future reference.

## What's in the box

Check and identify the contents of your package:




<b>AC4012</b>		
Filter 3	Activated carbon filter	AC4123
Filter 4	HEPA filter	AC4124

<b>AC4014</b>		
Filter 3	Activated carbon filter	AC4143
Filter 4	HEPA filter	AC4144



User manual



Warranty

# 3 Getting started

## Install filters

The air purifier comes with all filters fitted inside, but you have to remove the packaging of the filters before you can use it. Remove all filters, unpack them, and place them back into the air purifier as described below.



### Tip


- When you remove or insert filters, place the purifier against a wall for more stability.




### Note

- Insert the filters in the correct position.
- Make sure you place the filters in the order of HEPA filter; activated carbon filter; and finally the pre-filter.
- Make sure that the side with the tag is pointing towards you.


- 1 Place your fingers in the recesses of the side panels and gently pull the top part of the front panel towards you.
- 2 Gently pull the bottom of the panel out (1), then lift the top part of the front panel towards you (2).




- 3 Remove all the filters from the purifier.




- 4 Remove all packaging material from the filters.



- 5 Put the filters back into the purifier.




## 6 Place the pre-filter in the purifier.



### Note

- Make sure that the side with the two projections is pointing towards you, and that all hooks of the pre-filter are properly attached to the purifier.

## 7 To reattach the front panel, insert the top hooks into the top of the purifier first (1). Then, push the panel against the body of the purifier (2).





## 4 Using the air purifier

### Understand the air quality light

Color of the air quality light ring	Air quality level
Blue	Good
Purple	Fair
Red	Bad

The air quality light automatically goes on when the purifier is switched on.




#### Note

- The built-in air quality sensor measures the air quality and automatically selects the appropriate color of the air quality light. When the air is clean, the color of the air quality light is in blue. When the air quality deteriorates, the color of the air quality light changes to purple or red.

### Understand the healthy air protect alert

The filter replacement light (⌚) indicates the filters have to be replaced.




Healthy air protect alert	Follow this
Filter replacement light (⌚) is on continuously. This lasts approximately for 2 weeks. On the last day of 2 weeks, the purifier beeps every 30 minutes to inform you that the filters need to be replaced.	Replace the activated carbon filter and the HEPA filter.


### Switch on

- Plug the air purifier into the power supply.
  - ➔ All lights go on twice and you hear a beep. Then, the lights go out again.

AC4012 Control Panel	AC4014 Control Panel
----------------------	----------------------



- Press the ⏻ button to switch on the purifier.
  - ➔ The air quality light shows the current air quality.
  - ➔ The fan speed ~ light goes on.



- Press the ⏻ button to switch off the purifier.

# Set the sensitivity of the air quality sensor


People with certain health problems (for example: allergies or asthma) have a greater need for healthy air. For this reason, the purifier allows you to adjust the sensitivity of the air quality sensor. If you set it to higher sensitivity level, the purifier starts cleaning the air at lower pollution level. There are 3 sensitivity levels:


- standard
- sensitive
- extra sensitive


The pollution sensor is set to standard sensitivity. You can adjust the sensitivity of the air quality sensor in the following way.

## Note




- When it is set to a higher sensitivity, the purifier starts cleaning the air at lower pollution levels to make the air even cleaner. Plug the purifier before adjusting the sensitivity of the air quality sensor.

- 1 Press the  button and simultaneously put the power plug in the power socket.



- ➔ The purifier beeps twice and one of the  lights ( **1**, **4**, or **8** ) goes on to show the current sensitivity level of the air quality sensor.

Timer light	Sensitivity level
<b>1</b>	Extra sensitive
<b>4</b>	Sensitive
<b>8</b>	Standard

- 2 Press the  button to adjust the sensitivity level of the air quality sensor.
  - ➔ One of the  lights ( **1**, **4**, or **8** ) goes on to show the preferred sensitivity level of the air quality sensor.
- 3 Press the  button to switch off the purifier.

## Note





- When you change the sensitivity, the purifier automatically starts operating at the set sensitivity level whenever you switch on the purifier.

# Change the fan speed


## Manual


You can select the desired fan speed.




## Note


- When you select a fan speed, you can also use the timer function (see "Set the timer"). In this case, one of the  lights (AC4012:  and  ) and the  light ( **1**, **4**, or **8** ) are on.

- 1 Press the  button to switch on the purifier.




- 2 Press the  button once or more times to select the desired fan speed.

↳ For AC4012, select , , or ;



↳ For AC4014, select , , or .





#### Tip


- If the air quality light is in blue color, this means the air quality is good, and you can select a lower fan speed.


## Sleep mode


In sleep mode, the air filter operates very quietly while all lights are dimmed for your undisturbed sleep. (AC4012 only)

- 1 Press the  button to switch on the purifier.



- 2 Press the  button to select sleep mode.  
↳ The  light goes on.






To change to another fan speed, press the  button.


## Set the timer



With the timer function, you can let the purifier operate for a set number of hours. When the set time has elapsed, the purifier automatically switches off.



- 1 Press the  button to switch on the purifier.



- 2 Press the  button to activate the timer.  
→ The  light (1, 4, or 8) goes on.



- 3 Press the  button repeatedly to choose the number of hours you want the purifier to operate. The corresponding  light (1, 4, or 8) goes on.

To deactivate the timer function, press the  button repeatedly until the  light (1, 4, or 8) is out.

## 5 Cleaning your air purifier



### Note

- Always unplug the purifier before you clean it.
- Never immerse the purifier in water or any other liquid.
- Never use abrasive, aggressive, or flammable cleaning agents such as bleach or alcohol to clean any part of the purifier.
- Only the pre-filter is washable. Other air purifier filters are NOT washable nor vacuum cleanable.

### Clean the air purifier

Regularly clean the inside and outside of the purifier body to prevent dust from collecting.

- 1 Wipe away dust with a soft dry cloth from the body of the purifier.
- 2 Clean the air inlet and the air outlet with a soft dry cloth.

### Clean the air quality sensor


Clean the air quality sensor every 2 months for optimal functioning of the purifier. Clean it more frequently if you use the purifier in a dusty environment.




### Note

- When the humidity level in the room is very high, it is possible that condensation develops on the air quality sensor. As a result, the air quality light may indicate that the air quality is bad even though it is good. In this case you have to clean the air quality sensor or use one of the manual speed settings.


- 1 Clean the air quality sensor inlet and the air quality sensor outlet with a soft brush.



- 2 Remove the air quality sensor cover.



- 3 Clean the air quality sensor, the dust inlet and the dust outlet with a lightly moistened cotton swab.




- 4 Dry them with a dry cotton swab.
- 5 Reattach the air quality sensor cover.

## 6 Cleaning the pre-filter


### Note

- The pre-filter is washable and vacuum cleanable.
- Clean the pre-filter for every two weeks to ensure optimal functioning of the purifier.


- 1 Switch off the purifier and unplug it.




- 2 Place your fingers in the recess of the side panels and gently pull the bottom part of the front panel towards you (1). Then lift the hooks at the top of the panel out of the top of the purifier (2).



- 3 To remove the pre-filter, grab the two projections and pull the filter towards you.




- 4 Use a vacuum cleaner to clean the pre-filter or wash it under a running tap. If the pre-filter is very dirty, use a soft brush to brush away the dust.




- 5 Air dry the pre-filter.

- 6 Put the pre-filter back into the purifier. Attach all hooks properly to the purifier.



- 7 To reattach the front panel, insert the top hooks into the top of the purifier first (1). Then, push the panel against the body of the purifier (2).




#### Note

- Alternatively, you can clean the pre-filter by removing the dust with a vacuum cleaner.
- Make sure that the pre-filter is completely dry. If it is still wet, bacteria may multiply in it and shorten the lifetime of the pre-filter.
- Make sure that the side with the two projections is pointing towards you, and that all hooks of the pre-filter are properly attached to the purifier.

## 7 Replacing the filters

The filter replacement light (  ) indicates the filters have to be replaced.


### Note

- If you remove the front panel for filter changing while the purifier is switched on, all lights on the control panel will be off.
- Once the front panel is placed back to the purifier, all lights flash twice. Then, the purifier is off. Press the  button to switch on the purifier again.

## Replace the activated carbon filter and the HEPA filter

### Note

- The activated carbon filter and the HEPA filter are not washable nor vacuum cleanable.

Replace both the activated carbon filter and HEPA filter when the  light goes on. This will last for approximately 2 weeks. On the last day of the 2 weeks, the purifier beeps every 30 minutes to inform you that the filter needs to be replaced.


### Tip

- When you remove or insert filters, place the purifier against a wall for more stability.


### Note

- Insert the filters in the correct position.
- Make sure you place the filters in the order of HEPA filter; activated carbon filter; and finally the pre-filter.
- Make sure that the side with the tag is pointing towards you.


- 1 Switch off the purifier and unplug it.



- 2 Place your fingers in the recesses of the side panels and gently pull the bottom part of the front panel towards you. Lift the panel out of the hooks at the top of the purifier.



- 3 Remove the filters using the tag on the filter. Take the filters by both sides and gently deposit them into the house hold trash bin.




### Note


- Do not touch the pleated filter surface, or smell the filter as it has collected pollutants from the air.
- Wash your hands after disposing of the used filters.




- 4 Remove all packaging material from the new filters.




- 5 Place the new HEPA filter in the purifier first.



- 6 Then, place the new activated carbon filter in the purifier.




- 7 Place the pre-filter in the purifier.



#### Note

- Make sure that the side with the two projections is pointing towards you, and that all hooks of the pre-filter are properly attached to the purifier.

- 8 To reattach the front panel, insert the top hooks into the top of the purifier first (1). Then, push the panel against the body of the purifier (2).




- 9 Reset the activated carbon filter and the HEPA filter lifetime (see 'Reset the filter lifetime counter').

## 8 Resetting the filter lifetime counter


When you replace the filters, it is important that you also reset the filter lifetime counter afterwards. This allows the purifier to be in sync with the filter lifetime.


After you have replaced the filters, reset the filter time:


- 1 Switch off the purifier and unplug it.




- 2 Replace the air purifier filters (see 'Replace the filters').
- 3 Put the plug in the power socket and switch on the purifier again.



- 4 Press and hold the  button for 2 seconds.








### Note

- Reset the purifier when it is plugged in and switched on.
- Only replace the filters when you see the  light goes on.

## 9 Troubleshooting

This chapter summarizes the most common problems you could encounter with the purifier. If you are unable to solve the problem with the information below, contact the Consumer Care Center in your country.

Problem	Possible solution
The  light has been on continuously.	The filter is full. Replace the filter and reset the purifier.
No air comes out of the air outlet.	The purifier is not connected to the power supply. Plug the purifier into the power supply and switch on.
The fan speed does not change when the sleep mode is activated.	In sleep mode, the fan speed is set to a very low level. If you want to change the fan speed, press the  button one or more times to set the desired fan speed.
The airflow that comes out of the air outlet is significantly weaker than before.	<ul style="list-style-type: none"> <li>The pre-filter is dirty. Clean the pre-filter (see 'Clean the pre-filter').</li> <li>You have not removed all packaging material from the filters. Make sure that you have removed all packaging material.</li> </ul>
The air quality does not improve, even though the purifier has been operating for a long time.	<ul style="list-style-type: none"> <li>One of the filters has not been placed in the purifier. Make sure that all filters are properly installed in the following order, starting with the innermost filter: 1) HEPA filter; 2) activated carbon filter, and 3) pre-filter.</li> <li>The air quality sensor is wet. The humidity level in your room is high and causes condensation. Make sure that the air quality sensor is clean and dry (see 'Clean the air quality sensor').</li> </ul>
The color of the air quality light always stays the same.	<ul style="list-style-type: none"> <li>The air quality sensor is dirty. Clean the air quality sensor (see 'Clean the air quality sensor').</li> <li>There is not enough ventilation in the room. Open a window, to improve the air circulation.</li> </ul>
I need cleaner air because I have an allergy.	You can change the air quality sensor sensitivity (see 'Set the sensitivity of the air quality sensor') to make the purifier clean the air even better.
The purifier is extra loud.	<ul style="list-style-type: none"> <li>Please check if you have removed all the packaging material from the filters.</li> <li>If the appliance is still too loud, you can change the fan speed to a lower fan speed level.</li> </ul>
The purifier still indicates that I need to replace a filter, but I already did.	Perhaps you did not press the  button properly. Plug in the purifier, press the  button and press and hold the  button for 2 seconds.

# 10 Guarantee and service

If you need information or if you have a problem, please visit the Philips website at [www.philips.com](http://www.philips.com) or contact the Philips Consumer Care Center in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer:

---

## Order parts or accessories

If you have to replace a part or want to purchase an additional part, go to your Philips dealer or visit [www.philips.com/support](http://www.philips.com/support). If you have problems obtaining the parts, please contact the Philips Consumer Care Center in your country (you find its phone number in the worldwide guarantee leaflet).

# 11 Notices

---

## Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

---

## Compliance with EMF

Koninklijke Philips N.V. manufactures and sells many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals.

One of Philips' leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products.

Philips is committed to develop, produce and market products that cause no adverse health effects. Philips confirms that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today.

Philips plays an active role in the development of international EMF and safety standards, enabling Philips to anticipate further developments in standardization for early integration in its products.

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.

---

## Recycling



Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.



# 目錄

<b>1 重要事項</b>	23	<b>11 聲明</b>	38
安全	23	電磁場 (EMF)	38
		符合 EMF 標準	38
<b>2 您的空氣清淨機</b>	24	回收	38
包裝盒內容	24		
<b>3 快速入門</b>	25		
安裝濾網	25		
<b>4 使用空氣清淨機</b>	27		
瞭解空氣質量指示燈	27		
瞭解濾網更換提醒	27		
開機	27		
設定空氣質量感測器的			
敏感度	28		
變更風速	28		
設定定時器	30		
<b>5 清潔空氣清淨機</b>	31		
清潔空氣清淨機	31		
清潔空氣質量感測器	31		
<b>6 清潔預過濾網</b>	32		
<b>7 更換濾網</b>	34		
更換活性炭濾網和 HEPA 濾網	34		
<b>8 重設濾網壽命計算</b>	36		
<b>9 疑難排解</b>	37		
<b>10 保固與服務</b>	38		
訂購零件或配件	38		

# 1 重要事項

## 安全

在使用本產品前，請先仔細閱讀本使用手冊，並保留說明以供日後參考。

### 危險

- 請勿讓水或其他液體，或是易燃清潔劑進入產品內，以避免電擊和 / 或火災。
- 請勿用水、其他液體，或是 (易燃) 清潔劑清潔產品，以避免電擊和 / 或火災。

### 警告

- 在連接本產品的電源之前，請確認本產品機體底部或後方所標示的電壓與本地的電源電壓是否相同。
- 如果電線損壞，您必須將其交由飛利浦、飛利浦授權之服務中心，或是具備相同資格的技師進行更換，以免發生危險。
- 當插頭、電源線或產品本身受損時，請勿使用本產品。
- 本產品可供 8 歲以上孩童、身體官能或心智能力退化者，或是經驗與使用知識缺乏者使用，但需要有人在旁監督或適當指示如何安全使用本產品，以及可能遭受的危險。請勿讓兒童把玩本產品。若無人在旁監督，不得讓孩童清潔與維護本產品。
- 請勿在出風口上方或進風口前面放置物品，擋住進出風口。

### 注意

- 本產品不可用來作為維持良好通風的設備、替代吸塵器清潔，或烹調時用來當作抽油煙機使用。
- 如果供應產品電力的電源插座接頭不良，產品插頭會發熱。請確定將產品插入接頭良好的插座。


- 請將本產品放置在乾燥平穩的水平面上使用。
- 產品的背面及側面須至少保留 20 公分的間隔距離，頂部則至少保留 30 公分的間隔距離。
- 產品頂部請勿堆放任何物品，請勿坐在產品上。
- 請勿將產品放置在冷氣機正下方，以免冷氣機滴水，造成產品發生水滴凝結的現象。
- 請在開啟產品電源前，先確認所有濾網皆已正確安裝。
- 請僅使用產品專用的飛利浦原廠濾網。請勿使用其他濾網。
- 切勿使用堅硬的物體敲打產品 (特別是進風口及出風口)。
- 請務必使用產品背面的握柄提起或搬動產品。
- 請勿將手指或任何物體放入出風口。
- 當您使用室內噴霧式驅蟲劑或在充滿油漬、燒香、香煙的火星或化學煙霧的地方時，請勿使用本產品。
- 請勿在氣體用品、加熱裝置或壁爐附近使用本產品。
- 使用完畢後或進行清潔之前，請務必先拔除電源插頭。
- 請勿在溫差變化極大的室內使用本產品，因為室溫差距太大會造成本產品內部凝結水珠。
- 請將本產品遠離使用無線電電波的電子電器至少 2 公尺以避免干擾，例如電視、無線電廣播、無線電信號控制的時鐘。
- 本產品為家用產品，僅限於在正常操作環境下使用。
- 請勿在極為潮濕或周遭溫度很高的環境下使用本產品，例如浴室、廁所或廚房。
- 本產品無法清除一氧化碳 (CO) 或氫氣 (Rn)。發生燃燒意外及危險化學物品意外時，本產品無法當作安全裝置使用。

# 2 您的空氣清淨機

感謝您購買本產品。歡迎來到飛利浦的世界！  
請至 [www.Philips.com/welcome](http://www.Philips.com/welcome) 註冊您的產品，以獲得飛利浦提供的完整支援。  
在您安裝和使用本裝置前，請先詳讀本使用手冊。敬請妥善保管本手冊，以供日後參考。

## 包裝盒內容

請清點包裝內容物：



<b>AC4012</b>		
濾網 3	活性炭濾網	AC4123
濾網 4	HEPA 濾網	AC4124

<b>AC4014</b>		
濾網 3	活性炭濾網	AC4143
濾網 4	HEPA 濾網	AC4144



## 3 快速入門

### 安裝濾網

本空氣清淨機所有隨附的濾網皆已妥善安裝在機體內，但是在使用前，必須先拆下濾網包裝。請先取出所有濾網，拆下濾網包裝，然後把濾網放回空氣清淨機中，如下所述。



#### 秘訣


- 取出或裝入濾網時，將清淨機靠牆擺放可獲得較穩定的支撐。




#### 備註

- 將濾網裝入正確的位置。
- 請確實按照 HEPA 濾網、活性碳濾網、最後才是預過濾網的順序裝入濾網。
- 請確認有拉片的那一側朝向自己。


- 將手指放入兩邊護板的凹處，朝自己的方向輕輕拉出正面護板的頂部。
- 將護板的底部輕輕拉出 (1)，然後朝自己的方向拉出正面護板的頂部 (2)。




- 從清淨機內取出所有濾網。




- 拆下濾網的所有包裝材料。



- 將濾網裝回清淨機。




## 6 將預過濾網裝入清淨機。



### 備註

- 請確認有兩個凸出部分的那一側朝向自己，且預過濾網的所有扣鉤皆已正確裝入清淨機。

## 7 若要重新裝入正面護板，先將頂部扣鉤裝入清淨機頂部 (1)。然後將護板推入清淨機機體 (2)。



## 4 使用空氣清淨機

### 瞭解空氣質量指示燈

空氣品質環狀指示燈的 空氣品質等級  
色彩

藍色	很棒
紫色	普通
紅色	不良


清淨機電源開啟後，空氣質量指示燈就會自動亮起。

#### 備註

- 內建空氣質量感測器會檢測空氣品質並自動選擇適當的空氣質量指示燈色彩。當空氣乾淨時，空氣質量指示燈會顯示藍色。當空氣品質降低，空氣質量指示燈會變更為紫色或紅色。

### 瞭解濾網更換提醒

濾網更換指示燈 (C) 指示必須更換濾網。



#### 濾網更換提醒 遵循此程序


濾網更換指示燈 (C) 持續亮起。這種情況會持續約 2 週。在 2 週的最後一天，清淨機每隔 30 分鐘會發出嗶聲，通知您濾網需要更換。

更換活性碳濾網和 HEPA 濾網。


### 開機

- 將空氣清淨機的插頭插入電源供應器。  
→ 所有指示燈亮起兩次，並發出嗶聲，然後指示燈再次熄滅。

#### AC4012 控制面板 AC4014 控制面板



- 按下 (C) 按鈕以開啟清淨機電源。  
→ 空氣質量指示燈會顯示目前的空氣品質。  
→ 風速指示燈 ~ 會亮起。



- 按下 (C) 按鈕以關閉清淨機電源。

# 設定空氣質量感測器的 敏感度


擁有某些健康問題 (例如過敏或氣喘) 的人更需要乾淨的空氣。基於這個原因，本空氣清淨機可讓您調整空氣質量感測器的敏感度。如果您將敏感度的等級設為較高，清淨機在污染程度較低時就會開始潔淨空氣。


敏感度的等級有 3 種：


- 標準
  - 敏感
  - 超敏感
- 污染感測器的設定為標準敏感度。  
空氣質量感測器的敏感度可依照下列方式調整。

## 備註



- 敏感度的等級設為較高時，清淨機在污染程度較低時就會開始潔淨空氣，讓空氣更加乾淨。請先將清淨機插上電源，再調整空氣質量感測器的敏感度。

- 1 按下  按鈕，同時將電源插頭插入電源插座。



- 清淨機會發出兩次嗶聲，其中一個  指示燈 (1、4 或 8) 會亮起，顯示目前空氣質量感測器的敏感度等級。

定時指示燈	敏感度等級
1	超敏感
4	敏感
8	標準

- 2 按下  按鈕，調整空氣質量感測器的敏感度等級。  
→ 其中一個  指示燈 (1、4 或 8) 會亮起，顯示空氣質量感測器的偏好敏感度等級。

- 3 按下  按鈕以關閉清淨機電源。

## 備註



- 若您變更了敏感度，清淨機在開啟電源後，會依照您設定的敏感度等級自動開始運作。

# 變更風速


## 手冊


您可選擇想要的風速。




## 備註


- 選擇風速時，也可以使用定時功能 (請參閱「設定定時器」)。在此情況下，其中一個  指示燈 (AC4012: ~ 和 ≈) 以及  指示燈 (1、4 或 8) 會亮起。


- 1 按下  按鈕以開啟清淨機電源。





- 2 按下  按鈕一次或多次，選擇想要的風速。


↳ 若為 AC4012，請選擇 、 或 ；




↳ 若為 AC4014，請選擇 、 或 。





- 1 按下  按鈕以開啟清淨機電源。



- 2 按下  按鈕以選擇睡眠模式。

↳  指示燈會亮起。



如果想要更改風速，請按下  按鈕。



#### 秘訣


- 如果空氣質量指示燈顯示藍色，表示空氣品質良好，您可選擇較低的風速。


## 睡眠模式



在睡眠模式下，空氣濾網會非常安靜地運作，所有指示燈會以低亮度顯示，給您不受干擾的睡眠。(僅限 AC4012)


## 設定定時器



您可以使用定時功能，讓清淨機在設定的小時數內運作。設定時間結束後，清淨機會自動關閉電源。



- 1 按下  按鈕以開啟清淨機電源。



- 2 按下  按鈕以啟動定時功能。  
↳  指示燈 (1、4 或 8) 會亮起。



- 3 重複按下  按鈕，選擇想要清淨機運作的小時數。對應的  指示燈 (1、4 或 8) 會亮起。

要關閉定時功能，請重複按下  按鈕，直到  指示燈 (1、4 或 8) 熄滅。

## 5 清潔空氣清淨機

### 備註

- 進行清潔前，請務必先拔掉清淨機的電源插頭。
- 切勿讓清淨機浸入水或其他液體中。
- 切勿使用漂白劑或酒精等具磨蝕性、刺激性或易燃洗劑清潔清淨機的任何部分。
- 只有預過濾網可水洗。其他空氣清淨機濾網皆「不得」水洗或用吸塵器清潔。

### 清潔空氣清淨機

定期清潔清淨機機體的內部與外殼，可避免累積灰塵。

- 1 請使用柔軟的乾布擦拭清淨機的機體。
- 2 請使用柔軟的乾布清潔進風口及出風口。


### 清潔空氣質量感測器

每 2 個月清理空氣質量感測器，可確保清淨機發揮最佳效果。如果在佈滿灰塵的環境中使用清淨機，就要更常進行清潔。


### 備註

- 當室內濕度等級很高的時候，空氣質量感測器上可能會凝結水滴。如此一來，即使空氣品質良好，空氣質量指示燈可能會顯示空氣品質不良。在此情況下，您必須清潔空氣質量感測器，或使用手動風速設定。


- 1 請使用軟刷來清潔空氣質量感測器的進風口及出風口。



- 2 取下空氣質量感測器的護蓋。



- 3 請使用略濕的棉棒，清潔空氣質量感測器、進風口和出風口。




- 4 使用乾的棉棒擦乾。
- 5 重新裝入空氣質量感測器的護蓋。

## 6 清潔預過濾網


### 備註

- 預過濾網可水洗並可用吸塵器清潔。
- 請每兩週清潔一次預過濾網，確保清淨機發揮最佳效果。


#### 1 關閉清淨機電源，並拔除插頭。




#### 2 將手指放入兩邊護板的凹處，朝自己的方向輕輕拉出正面護板的底部 (1)。然後將護板頂部的扣鉤自清淨機頂部提起 (2)。



#### 3 若要取出預過濾網，抓住濾網上兩個凸出部分，朝向自己拉出。




#### 4 使用吸塵器清潔預過濾網或置於水龍頭下清洗。如果預過濾網很髒，請使用軟刷來清除灰塵。




#### 5 讓預過濾網自然風乾。

#### 6 將預過濾網裝回清淨機中。將所有扣鉤正確扣入清淨機。





- 7 若要重新裝入正面護板，先將頂部扣鉤裝入清淨機頂部 (1)。然後將護板推入清淨機機體 (2)。




#### 備註

- 清潔預過濾網的其他方法，就是使用吸塵器去除灰塵。
- 請確認預過濾網完全乾燥。如果預過濾網未乾，細菌可能會在其中滋生，造成其使用壽命縮短。
- 請確認有兩個凸出部分的那一側朝向自己，且預過濾網的所有扣鉤皆已正確裝入清淨機。

## 7 更換濾網

濾網更換指示燈 (C) 指示必須更換濾網。


### 備註

- 如果您在清淨機電源開啟時為了更換濾網而取下正面護板，控制面板上的所有指示燈都會熄滅。
- 一旦將正面護板裝回清淨機，所有指示燈會閃爍兩次。然後，清淨機電源會關閉。按下  按鈕以再次開啟清淨機電源。

## 更換活性碳濾網和 HEPA 濾網

### 備註

- 活性碳濾網和 HEPA 濾網皆不可水洗或用吸塵器清潔。

當  指示燈亮起時，請同時更換活性碳濾網和 HEPA 濾網。使用效期約為 2 週。在 2 週的最後一天，清淨機每隔 30 分鐘會發出嗶聲，通知您濾網需要更換。


### 秘訣

- 取出或裝入濾網時，將清淨機靠牆擺放可獲得較穩定的支撐。


### 備註

- 將濾網裝入正確的位置。
- 請確實按照 HEPA 濾網、活性碳濾網、最後才是預過濾網的順序裝入濾網。
- 請確認有拉片的那一側朝向自己。


### 1 關閉清淨機電源，並拔除插頭。



### 2 將手指放入兩邊護板的凹處，朝自己的方向輕輕拉出正面護板的底部。將護板的扣鉤自清淨機頂部提起。




### 3 使用濾網上的拉片取下濾網。從兩側握住濾網，輕輕丟棄至家用垃圾桶。




### 備註

- 請勿碰觸有皺摺的濾網表面或嗅聞濾網，因為它收集了空氣中的污染物。
- 丟棄舊濾網後務必洗手。


- 4 拆下新濾網的所有包裝材料。




- 5 先將新 HEPA 濾網裝入清淨機。



- 6 然後將新的活性炭濾網裝入清淨機。




- 7 將預過濾網裝入清淨機。



#### 備註

- 請確認有兩個凸出部分的那一側朝向自己，且預過濾網的所有扣鉤皆已正確裝入清淨機。

- 8 若要重新裝入正面護板，先將頂部扣鉤裝入清淨機頂部 (1)。然後將護板推入清淨機機體 (2)。




- 9 重設活性炭濾網和 HEPA 濾網的使用壽命 (請參閱「重設濾網壽命計算」)。

## 8 重設濾網壽命計算

更換濾網時，請務必在之後重設濾網壽命計算。如此可讓清淨機與濾網使用壽命的時間一致。


在更換濾網之後，重設濾網時間：

- 1 關閉清淨機電源，並拔除插頭。




- 2 更換空氣清淨機濾網（請參閱「更換濾網」）。


- 3 將插頭插入電源插座，然後再次開啟清淨機電源。



- 4 按住  按鈕 2 秒。



### 備註

- 在清淨機插入電源且開啟後進行重設。
- 僅在  指示燈亮起時才更換濾網。

## 9 疑難排解

本單元概述您使用清淨機時最常遇到的問題。如果您無法利用以下資訊解決您遇到的問題，請聯絡您所在國家/地區的客戶服務中心。

問題	可能的解決方法
ⓘ 指示燈持續亮起。	濾網已滿。更換濾網與重設清淨機。
出風口沒有空氣流出。	清淨機沒有連接至電源供應器。請將清淨機插頭插入電源供應器，然後開啟電源。
睡眠模式啟動時，風速沒有改變。	在睡眠模式下，風速會設得很低。如果想要變更風速，請按下 ⓘ 按鈕一次或多次，設定所需的風速。
出風口流出的風速比之前慢很多。	<ul style="list-style-type: none"> <li>預過濾網髒污。清潔預過濾網 (請參閱「清潔預過濾網」)。</li> <li>您尚未拆下濾網的所有包裝材料。請確認已拆下所有包裝材料。</li> </ul>
即使清淨機已經長時間運作，空氣品質仍未獲得改善。	<ul style="list-style-type: none"> <li>其中一個濾網尚未裝入清淨機內。請確認所有濾網都已按照下列順序正確安裝，濾網從內至外分別為：(1) HEPA 濾網；(2) 活性碳濾網和 (3) 預過濾網。</li> <li>空氣質量感測器潮濕。室內的濕度等級很高，造成水珠凝結。請確認空氣質量感測器乾淨且乾燥 (請參閱「清潔空氣品質感測器」)。</li> </ul>
空氣質量指示燈的顏色一直維持不變。	<ul style="list-style-type: none"> <li>空氣質量感測器髒污。清潔空氣質量感測器 (請參閱「清潔空氣質量感測器」)。</li> <li>室內空氣不夠流通。請開窗，促進空氣對流。</li> </ul>
我會過敏，需要更乾淨的空氣。	您可以變更空氣質量感測器敏感度 (請參閱「設定空氣品質感測器的敏感度」)，讓清淨機把空氣清潔得更加徹底。
清淨機噪音很大。	<ul style="list-style-type: none"> <li>請檢查是否已拆下濾網的所有包裝材料。</li> <li>如果產品噪音仍然很大，可將風速變更為較低的速度等級。</li> </ul>
清淨機不斷要求更換濾網，但濾網已經更換了。	您可能未確實按下 ⓘ 按鈕。請為清淨機插上電源，按下 ⓘ 按鈕並按住 ⓘ 按鈕 2 秒鐘。

## 10 保固與服務

若您需要相關資訊，或是有任何問題，請造訪飛利浦網站：[www.philips.com](http://www.philips.com)，或聯絡您所在國家/地區的飛利浦客戶服務中心（您可在全球保證書上找到電話號碼）。若當地沒有客戶服務中心，請洽詢當地的飛利浦經銷商。

### 訂購零件或配件

如果您必須更換零件或想購買其他零件，請聯絡您的飛利浦經銷商，或造訪

[www.philips.com/support](http://www.philips.com/support)。

如果您有取得零件方面的問題，請聯絡您所在國家/地區的飛利浦客戶服務中心（您可在全球保證書上找到電話號碼）。

## 11 聲明

### 電磁場 (EMF)

本飛利浦產品符合所有電磁場暴露的相關適用標準和法規。

#### 符合 EMF 標準

Koninklijke Philips N.V. 製造銷售多項消費性產品，這些產品就如同其他電器，通常能收發電磁訊號。

飛利浦的一大企業原則，就是針對自身的產品進行必要的健康與安全檢測，以符合所有適用的法律規定，以及在產品生產期間符合適用的 EMF 標準。

飛利浦致力於開發、生產及銷售不危害健康的產品。飛利浦保證，只要依照正確用途並妥善使用，根據現有的科學研究資料，使用本公司產品並無安全顧慮。

飛利浦積極參與國際 EMF 與安全標準的開發，因此得以掌握標準化的發展，及早將標準化與自身的產品整合。

未經 Philips Consumer Lifestyle 明示核可即變更或修改本裝置，可能導致使用者操作本設備的授權失效。

### 回收



請勿將您的產品與其他家用廢棄物共同丟棄。請瞭解當地電子及電器廢棄物的垃圾分類相關法規。正確處理廢棄產品有助於避免對環境和人類健康帶來負面影響。





Specifications are subject to change without notice

© 2014 Koninklijke Philips N.V.

All rights reserved.

4241 210 17331

