


Always here to help you


Register your product and get support at
www.philips.com/welcome

RI7035



PHILIPS





**1****1****2**

IMPORTANT

- Perform Calc-Clean process regularly for great steam and prolonged life (Fig. 1).
- Recommended water to use: distilled or demineralised water (Fig. 2).

IMPORTANTE

- Execute o processo Calc-Clean regularmente para garantir excelente qualidade de vapor e vida útil prolongada (fig. 1).
- Água recomendada para uso: destilada ou desmineralizada (fig. 2).

RI7035

ENGLISH 6
PORTUGUÊS DO BRASIL 12

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com.br/clube.

This iron has been approved by The Woolmark Company Pty Ltd for the ironing of wool-only products, provided that the garments are ironed according to the instructions on the garment label and those issued by the manufacturer of this iron, R1401. In the United Kingdom, Eire, Hong Kong and India, the Woolmark trademark is a certification trademark.

Important

Read this important information carefully before you use the appliance and save it for future reference.

Danger

- Never immerse the appliance in water.

Warning

- Do not use the appliance if the plug, the mains cord, the supply hose or the appliance itself shows visible damage, or if the appliance has been dropped or leaks. For repair or service, you must have the appliance inspected by Philips, a service centre authorised by Philips or similarly qualified persons.
- Check if the voltage indicated on the type plate corresponds to the local mains voltage before you connect the appliance
- Do not immerse the iron or the steam generator in water.
- Do not leave the appliance unattended when it is connected to the mains.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep the appliance and the mains cord out of the reach of children.
- Do not use any other cap on the steam generator than the EASY DE-CALC knob that has been supplied with the appliance.
- Specific types only: Do not open and remove the EASY DE-CALC knob from the steam generator during use.
- If steam or hot water droplets escape from under the EASY DE-CALC knob when the appliance heats up, switch off the appliance and tighten the EASY DE-CALC knob. If steam continues to escape when the appliance heats up, switch off the appliance and contact a service centre authorised by Philips.
- Specific types only: The iron platform (stand) can become extremely hot, and may cause burns if touched. Let it cool down for 5 minutes when performing cartridge replacement.
- **CAUTION: Hot surface** (Fig. 3)
Surfaces are liable to get hot during use (for irons with hot symbol marked on the appliance).
- Specific types only: Do not let the iron rest on its heel during the Calc-Clean process. Hot water comes out of the iron together with steam.

Caution

- Only connect the appliance to an earthed wall socket.
- Fully unwind the mains cord before you put the plug in the wall socket.
- Always place and use the iron and the steam generator on a stable, level, horizontal and heat-resistant surface.
- The iron platform and the soleplate of the iron can become extremely hot and may cause burns if touched. If you want to move the steam generator, do not touch the iron platform.

- When you have finished ironing, when you clean the appliance, when you fill or empty the water tank and also when you leave the appliance even for a short while: put the iron back on the iron platform, switch off the appliance and remove the mains plug from the wall socket.
- This appliance is intended for household use only.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

General description (Fig. 4)

- 1 Carry lock (specific types only)
- 2 Water tank filling funnel
- 3 Water tank
- 4 Iron platform
- 5 Supply hose
- 6 Mains cord with plug
- 7 Calc-Clean button with Calc-Clean light
- 8 On/off button with power-on light
- 9 ECO button with light
- 10 Soleplate
- 11 Steam trigger
- 12 'Iron ready' light
- 13 Smart Calc-Clean container

OptimalTemp Technology

The OptimalTemp technology enables you to iron all types of ironable fabrics, without adjusting the iron temperature.

- Fabrics with these symbols are ironable, for example linen, cotton, polyester, silk, wool, viscose and rayon (Fig. 5).
- Fabrics with this symbol are not ironable. These fabrics include synthetic fabrics such as Spandex or elastane, Spandex-mixed fabrics and polyolefins (e.g. polypropylene), but also prints on garments (Fig. 6).

Recommended water to use: distilled or demineralised water

Your appliance has been designed to be used with tap water. If you live in an area with hard water, fast scale build-up may occur. It is therefore recommended to use distilled or demineralised water to prolong the lifetime of your appliance.

Do not use perfumed water, water from the tumble dryer, vinegar, starch, descaling agents, ironing aids, chemically descaled water or other chemicals, as they may cause water spitting, brown staining or damage to your appliance.

Ironing

Please read the quick start guide on the packaging carefully to start using your appliance.

Note: Keep the steam trigger pressed continuously when you move the iron over the fabric while you iron.

IMPORTANT - Cleaning and maintenance**Smart Calc-Clean System**

Your appliance has been designed with a Smart Calc-Clean system to ensure that descaling and cleaning is done regularly. This helps to maintain a strong steam performance and avoids dirt and stains coming out of the soleplate over time. To ensure that the cleaning process is performed, the steam generator gives regular reminders. Besides that, a second defence step to protect the steam generator from scale is integrated: the steam function gets disabled if descaling is not done after 1 hour steam ironing once the reminder came up. After descaling is done, the steam function will be restored. This takes place regardless of the type of water used.

Sound and light Calc-Clean reminder

- After 1 to 3 months of use, the light of the Calc-Clean button starts flashing and the appliance starts beeping to indicate that you have to perform the Calc-Clean process (Fig. 7).
- You can continue steam ironing for 1 hour while the Calc-Clean light flashes and the appliance beeps. After 1 hour, the steam function is automatically disabled. You have to perform the Calc-Clean process before you can continue steam ironing. (Fig. 8)

Performing the Calc-Clean process with the Calc-Clean container

Do not leave the appliance unattended during the Calc-Clean process.

Caution: Do not interrupt the process by lifting the iron up from the Calc-Clean container, as hot water and steam will come out of the soleplate.

- 1** Fill up the water tank halfway (Fig. 9).
- 2** Make sure that the appliance is plugged in and switched ON during the Calc-Clean process (Fig. 10).
- 3** Place the Calc-Clean container on the ironing board or any other even, stable surface (Fig. 11).
- 4** Place the iron stably on the Calc-Clean container.
- 5** Press and hold the Calc-Clean button for 2 seconds until you hear short beeps (Fig. 12).
Note: The Calc-Clean container has been designed to collect scale particles and hot water during the Calc-Clean process. It is perfectly safe to rest the iron on this container during the entire process.
- 6** During the Calc-Clean process, you hear short beeps and a pumping sound. Wait approximately 2 minutes for the appliance to complete the process (Fig. 13).
- 7** When the Calc-Clean process is completed, the iron stops beeping (Fig. 14).
- 8** Wipe the iron with a piece of cloth and put it back on the base station (Fig. 15).
- 9** As the Calc-Clean container becomes hot during the Calc-Clean process, wait approx. 5 minutes before you touch it.
- 10** Carry the Calc-Clean container to the sink, empty it and store it for future use (Fig. 16).
- 11** If necessary, you can repeat steps 1 to 10. Make sure that you empty the Calc-Clean container before you start the Calc-Clean process.

Note: During the Calc-Clean process, clean water may come out of the soleplate if no scale has accumulated inside the iron. This is normal.

Energy saving

Eco mode

By using the ECO mode (reduced amount of steam), you can save energy without compromising on the ironing result.

- 1 To activate the ECO mode, press the ECO button. The green ECO light goes on. (Fig. 17)
- 2 To deactivate the ECO mode, press the ECO button again. The green light goes off.

Safety auto-off (specific types only)

The safety auto-off function automatically switches off the appliance if it has not been used for 5 minutes, to save energy.

Recycling

Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

Guarantee and support

If you need information or support, please visit www.philips.com.br/suporte or read the separate worldwide guarantee leaflet.

Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, visit www.philips.com.br/suporte for a list of frequently asked questions or contact the Consumer Care Centre in your country.

Problem	Possible cause	Solution
The iron does not produce any steam.	There is not enough water in the water tank.	Fill the water tank beyond the MIN indication. Press and hold the steam trigger until steam comes out. It may take up to 30 seconds until steam comes out.
	You have not pressed the steam trigger.	Press and hold the steam trigger until steam comes out.
The light of the Calc-Clean button flashes and/or the appliance beeps.	The steam function has been disabled until you have performed the Calc-Clean process.	Perform the calc-clean process to restore the steam function (see chapter 'IMPORTANT - Cleaning and maintenance').
	This is the Calc-Clean reminder.	Perform the Calc-Clean process within 1 hour after the Calc-Clean reminder is given (see chapter 'IMPORTANT - Cleaning and maintenance').

Problem	Possible cause	Solution
The light of the Calc-Clean button flashes and the appliance beeps every time I press the steam trigger. No steam comes out of the soleplate.	You have not done or have not completed the Calc-Clean process.	Perform the Calc-Clean process to enable the steam function again (see chapter 'IMPORTANT - Cleaning and maintenance').
The appliance has switched off.	The safety auto-off function was activated. This happens automatically when the steam generator has not been used for more than 5 minutes.	Set the on/off switch to 'off' position and then to 'on' position.
The appliance produces a loud pumping sound.	The water tank is empty.	Fill the water tank with water and press the steam trigger until the pumping sound becomes softer and steam comes out of the soleplate.
Water droplets come out of the soleplate.	After the Calc-Clean process, remaining water may drip out of the soleplate.	Wipe the soleplate dry with a piece of cloth. If the light in the Calc-Clean button still flashes and the appliance still beeps, perform the Calc-Clean process (see chapter 'IMPORTANT - Cleaning and maintenance').
	The Calc-Clean process has not been completed.	You have to perform the Calc-Clean process again (see chapter 'IMPORTANT - Cleaning and maintenance').
Dirty water and impurities come out of the soleplate.	Impurities or chemicals present in the water have deposited in the steam vents and/or soleplate.	Perform the Calc-Clean process regularly (see chapter 'IMPORTANT - Cleaning and maintenance').
Water flushes out of the soleplate.	You have accidentally started the Calc-Clean process (see chapter 'IMPORTANT - Cleaning and maintenance').	Switch off the appliance. Then switch it back on again. Let the iron heat up until the 'iron ready' light lights up steadily.
The Calc-Clean process does not start.	You have not pressed the Calc-Clean button for 2 seconds until the appliance started beeping.	See chapter 'IMPORTANT - Cleaning and maintenance'.
The iron leaves a shine or an imprint on the garment.	The surface to be ironed was uneven, for instance because you were ironing over a seam or a fold in the garment.	Perfect Care is safe on all garments. The shine or imprint is not permanent and will disappear when you wash the garment. Avoid ironing over seams or folds or you can place a cotton cloth over the area to be ironed to avoid imprints.

Problem	Possible cause	Solution
The ironing board cover becomes wet or water droplets come out of the soleplate.	Steam has condensed on the ironing board cover after a long ironing session.	Replace the ironing board cover if the foam material has worn out. You can also add an extra layer of felt material under the ironing board cover to prevent condensation on the ironing board.
	You may have an ironing board that is not designed to cope with the high steam rate of the steam generator.	Put an extra layer of felt material under the ironing board cover to prevent condensation on the ironing board.
Steam continues to come out after I release the steam trigger.	Steam is generated in the soleplate. When you release the steam trigger, remaining water is transformed into steam. This is normal.	Release the steam trigger 2 to 3 seconds before you place the iron back on the iron platform or ironing board.
There is a strong gush of steam when I release the steam trigger after placing the iron on the iron platform.	When the iron is tilted upwards, remaining water is collected and converted into strong steam. This is normal.	Release the steam trigger 2 to 3 seconds before you place the iron back on the iron platform or ironing board.
Steam is weak.	You do not press the steam trigger continuously.	Keep the steam trigger pressed continuously when you move the iron over the fabric.
	You use the ECO mode.	For more steam, switch off the ECO mode by pressing the ECO button. The green ECO light goes off.
Steam does not come out immediately when I press the steam trigger.	Water is converted into steam in the soleplate. When you press the steam trigger, it will take 1 to 2 seconds until steam is generated and released. This is normal.	Keep the steam trigger pressed continuously when you move the iron over the fabric.

Introdução

Parabéns pela sua compra e bem-vindo à Philips! Para aproveitar ao máximo o suporte oferecido pela Philips, registre o produto em www.philips.com.br/clube.

Este ferro foi aprovado pela The Woolmark Company Pty Ltd para passar peças de lã, desde que as peças de roupa sejam passadas de acordo com as instruções na etiqueta da peça e pelo rótulo emitido pelo fabricante do ferro. R1401. No Reino Unido, na Irlanda, em Hong Kong e na Índia, a marca registrada Woolmark corresponde a uma marca registrada de certificação.

Importante

Leia atentamente estas informações importantes antes de usar o aparelho. Guarde-as para consultas futuras.

Perigo

- Nunca mergulhe o aparelho na água.

Aviso

- Não utilize o aparelho se o plugue, o cabo de alimentação ou o próprio aparelho apresentarem danos visíveis ou se o aparelho tiver sofrido alguma queda ou vazamento. Para reparo ou manutenção, o aparelho deve ser inspecionado pela Philips, por uma assistência técnica autorizada pela Philips ou por profissionais igualmente qualificados.
- Antes de ligar o aparelho, verifique se a tensão indicada na placa de modelo é a mesma da tomada.
- Não mergulhe o ferro ou o gerador de vapor na água.
- Não deixe o aparelho ligado ao sistema elétrico com fio sem vigilância.
- Este aparelho não deve ser usado por pessoas (inclusive crianças) com capacidades físicas, mentais ou sensoriais reduzidas ou pouca experiência e conhecimento, a menos que sejam supervisionadas ou instruídas sobre o uso do aparelho por uma pessoa responsável por sua segurança.
- Crianças pequenas devem ser supervisionadas para que não brinquem com o aparelho.
- Mantenha o aparelho e o cabo de energia fora do alcance de crianças.
- Não utilize outra tampa no gerador de vapor além do botão giratório EASY DE-CALC fornecido com o aparelho.
- Somente tipos específicos: não abra nem remova o botão giratório EASY DE-CALC do gerador de vapor durante o uso.
- Se gotas de vapor ou de água quente vazarem do botão EASY DE-CALC quando o aparelho estiver aquecendo, desligue o aparelho e aperte o botão giratório EASY DE-CALC. Se o vazamento continuar durante o aquecimento do aparelho, desligue o aparelho e entre em contato com uma assistência técnica autorizada pela Philips.
- Somente tipos específicos: a plataforma (suporte) do ferro pode ficar extremamente quente e pode causar queimaduras na pele. Deixe-a esfriar por 5 minutos ao realizar a troca do cartucho.
- **CUIDADO: superfície quente** (fig. 3)
As superfícies tendem a esquentar durante o uso (para ferros, com o símbolo de calor marcado no aparelho).
- Somente tipos específicos: não deixe o ferro apoiado na vertical durante o processo Calc-Clean. A água quente sai do ferro com o vapor.

Atenção

- Conecte o aparelho somente a uma tomada elétrica aterrada.
- Desenrole completamente o cabo de alimentação antes de conectá-lo à tomada.
- Sempre coloque e use o ferro e o gerador de vapor em uma superfície estável, nivelada, horizontal e resistente ao calor.
- O suporte e a base do ferro podem ficar extremamente quentes e causar queimaduras se tocados. Se desejar mover o gerador de vapor, não toque no suporte do ferro.

- Quando terminar de passar, limpar o ferro, encher ou esvaziar o reservatório de água ou afastar-se do aparelho, mesmo que rapidamente, recoloque-o na plataforma, desligue-o e retire o plugue da tomada.
- Este aparelho destina-se somente a uso doméstico.

Campos eletromagnéticos

Este aparelho Philips está em conformidade com todos os padrões aplicáveis e regulamentos relacionados à exposição a campos eletromagnéticos.

Descrição geral (fig. 4)

- 1 Bloqueio de transporte (somente em modelos específicos)
- 2 Funil de abastecimento do reservatório de água
- 3 Reservatório de água
- 4 Plataforma do ferro
- 5 Mangueira de fornecimento
- 6 Fio com plugue
- 7 Botão Calc-Clean com luz Calc-Clean
- 8 Lâmpada piloto no botão liga/desliga
- 9 Botão ECO com luz
- 10 Base
- 11 Acionamento de vapor
- 12 Luz indicadora de "ferro pronto"
- 13 Reservatório inteligente Calc-Clean

Tecnologia OptimalTemp

Com a tecnologia OptimalTemp, você pode passar todos os tipos de tecidos permitidos, sem a necessidade de ajustar a temperatura do ferro.

- Os tecidos com estes símbolos podem ser passados, por exemplo, linho, algodão, poliéster, seda, lã, viscosa e raíom (fig. 5).
- Os tecidos com este símbolo não podem ser passados. Estes tecidos incluem componentes sintéticos tal como Spandex ou elastano, tecidos mistos de Spandex e poliolefinas (por exemplo, polipropileno), ou apresentam estampas (fig. 6).

Água recomendada para uso: destilada ou desmineralizada

Seu aparelho foi projetado para ser usado com água corrente. Caso você more em um local com incidência de água dura, é possível que as impurezas acumulem rapidamente. Portanto, recomenda-se usar água destilada ou desmineralizada para prolongar a vida útil do aparelho.

Não use água perfumada, água da secadora, vinagre, goma, agentes descalcificadores, produtos para passar roupas, água quimicamente descalcificada ou outros produtos químicos, pois eles podem causar jatos de água, manchas escuras ou danos ao aparelho.

Ferro de Passar e Vaporizador

Leia atentamente o guia de início rápido na embalagem para começar a usar o aparelho.

Nota: Mantenha pressionado o botão de vapor ao mover o ferro sobre o tecido ao passar.

IMPORTANTE - Limpeza e manutenção

Sistema Inteligente Calc-Clean

O aparelho foi desenvolvido com um sistema inteligente Calc-Clean para garantir que a remoção de impurezas e a limpeza sejam realizadas regularmente. Isso ajuda a manter um desempenho de vapor potente e evita que manchas e sujeira saiam da base com o tempo. Para garantir que o processo de limpeza seja realizado, o gerador de vapor emite lembretes regulares. Além disso, há integrada uma segunda etapa de defesa para proteger o gerador de vapor contra o acúmulo de impurezas: a função de vapor é desabilitada quando a remoção de impurezas não é realizada após 1 hora de uso do ferro a vapor depois do lembrete. Após remover as impurezas, a função de vapor é restaurada. Isso acontece independentemente do tipo de água usado.

Lembrete Calc-Clean sonoro e visual

- Após um a três meses de uso, a luz do botão Calc-Clean começa a piscar e o aparelho começa a emitir um bipe para indicar que você deve realizar o processo Calc-Clean (fig. 7).
- Você pode continuar passando o ferro a vapor por 1 hora enquanto a luz Calc-Clean pisca e o aparelho emite bipe. Após 1 hora, a função de vapor é desativada automaticamente. Você deve realizar o processo Calc-Clean antes de continuar a passar o ferro a vapor: (fig. 8)

Realizar o processo Calc-Clean com o reservatório Calc-Clean

Não se distancie do aparelho durante o processo Calc-Clean.

Cuidado: Não interrompa o processo levantando o ferro do reservatório Calc-Clean, pois a água quente e o vapor sairão da base.

- 1** Abasteça o reservatório de água até a metade (fig. 9).
- 2** Certifique-se de que o aparelho esteja conectado e LIGADO durante o processo Calc-Clean (fig. 10).
- 3** Coloque o reservatório Calc-Clean na tábua de passar ou em qualquer superfície estável e nivelada (fig. 11).
- 4** Coloque o ferro de modo estável no reservatório Calc-Clean.
- 5** Mantenha pressionado o botão Calc-Clean por 2 segundos até ouvir bipes breves (fig. 12).
Nota: O reservatório Calc-Clean foi desenvolvido para coletar partículas de impurezas e água quente durante o processo Calc-Clean. É totalmente seguro deixar o ferro em seu reservatório durante todo o processo.
- 6** Durante o processo Calc-Clean, você ouve dois bipes breves e um som de bombeamento. Aguarde cerca de 2 minutos para que o aparelho conclua o processo (fig. 13).
- 7** Quando o processo Calc-Clean for concluído, o ferro irá parar de emitir bipe (fig. 14).
- 8** Limpe o ferro com um pedaço de pano e recolque-o na estação base (fig. 15).
- 9** Como o reservatório Calc-Clean esquenta durante o processo Calc-Clean, aguarde cerca de 5 minutos antes de tocá-lo.
- 10** Leve o reservatório Calc-Clean até a pia, esvazie-o e armazene-o para uso futuro (fig. 16).
- 11** Se necessário, você pode repetir as etapas de 1 a 10. Não se esqueça de esvaziar o reservatório Calc-Clean antes de iniciar o processo Calc-Clean.

Nota: Durante o processo Calc-Clean, água limpa pode sair da base quando não há acúmulo de impurezas dentro do ferro. Isso é normal.

Economia de energia

Modo econômico

Ao utilizar o modo ECO (quantidade reduzida de vapor), você pode economizar energia sem comprometer o resultado do uso do ferro.

- 1 Para ativar o ECO, pressione o botão ECO. A luz verde ECO acende. (fig. 17)
- 2 Para desativar o modo ECO, pressione novamente o botão ECO. A luz verde apaga.

Desligamento automático de segurança (apenas em modelos específicos)

A função de desligamento automático de segurança desliga o aparelho automaticamente caso ele não seja utilizado por 5 minutos, economizando energia.

Reciclagem

Não descarte o aparelho com o lixo doméstico no final de sua vida útil. Leve-o a um posto de coleta oficial para que possa ser reciclado. Com esse ato, você ajuda a preservar o meio ambiente.

Garantia e suporte

Caso você precise de informações ou suporte, visite o site www.philips.com.br/suporte ou leia o folheto de garantia mundial à parte.











Resolução de problemas


Este capítulo resume os problemas mais comuns que podem ser encontrados durante o uso do aparelho. Caso você não consiga solucionar o problema com as informações abaixo, acesse www.philips.com.br/support para obter uma lista de perguntas frequentes ou entre em contato com a Central de atendimento ao cliente.

Problema	Possível causa	Solução
O ferro não produz vapor.	O reservatório não possui água suficiente.	Encha o reservatório com água além da indicação MIN. Pressione e segure o botão de acionamento de vapor até que o vapor saia. Pode demorar até 30 segundos para que o vapor saia.
	Você não pressionou o botão de acionamento de vapor.	Mantenha o botão de vapor pressionado até o vapor começar a sair.
	A função de vapor foi desativada até que você tenha executado o processo Calc-Clean.	Execute o processo calc-clean para restaurar a função de vapor (consulte o capítulo "IMPORTANTE - Limpeza e manutenção").
A luz do botão Calc-Clean pisca e/ou o aparelho emite um bipe.	Esse é o lembrete Calc-Clean.	Execute o processo Calc-Clean em 1 hora após o lembrete Calc-Clean (consulte "IMPORTANTE - Limpeza e manutenção").

Problema	Possível causa	Solução
A luz do botão Calc-Clean pisca e o aparelho emite um bipe sempre que pressiono o botão de vapor: O vapor não sai da base.	Você não realizou ou não concluiu o processo Calc-Clean.	Execute o processo Calc-Clean para ativar a função de vapor novamente (consulte o capítulo "IMPORTANTE - Limpeza e manutenção").
O aparelho desligou.	A função de desligamento automático de segurança foi ativada. Isso acontece automaticamente quando o gerador de vapor não é utilizado por mais de 5 minutos.	Ligue e desligue o aparelho.
O aparelho produz um som alto de bombear.	O reservatório de água está vazio.	Encha novamente o reservatório de água e pressione o botão de vapor até o som de bombear diminuir e o vapor sair da base.
Gotas de água saem da base.	Após o processo Calc-Clean, pode pingar água da base.	Seque a base com um pedaço de pano. Caso a luz do botão Calc-Clean continue piscando e o aparelho emitindo bipe, execute o processo Calc-Clean (consulte o capítulo "IMPORTANTE - Limpeza e manutenção").
	O processo Calc-Clean não foi concluído.	Você deve executar novamente o processo Calc-Clean (consulte o capítulo "IMPORTANTE - Limpeza e manutenção").
Água suja e impurezas saem da base.	Impurezas ou produtos químicos presentes na água acumularam nas saídas de vapor e/ou na base.	Execute o processo Calc-Clean regularmente (consulte o capítulo "IMPORTANTE - Limpeza e manutenção").
Sai água da base.	Talvez você tenha executado acidentalmente o processo Calc-Clean (consulte o capítulo "IMPORTANTE - Limpeza e manutenção").	Desligue o aparelho. Em seguida, ligue-o novamente. Aqueça o ferro até a luz indicadora de "ferro pronto" fique acesa.
O processo Calc-Clean não é iniciado.	Você não pressionou o botão Calc-Clean por 2 segundos até o aparelho começar a emitir bipe.	Consulte o capítulo "IMPORTANTE - Limpeza e manutenção".


Problema	Possível causa	Solução
O ferro deixa brilho ou uma marca na peça de roupa.	A superfície a ser passada estava desigual, por exemplo, por ter passado o ferro sobre uma costura ou uma dobra na peça de roupa.	A tecnologia PerfectCare é segura para todas as peças de roupa. O brilho ou a marca não são permanentes e desaparecerão quando você lavar a peça de roupa. Evite passar o ferro sobre costuras ou dobras. Como alternativa, você pode colocar um tecido de algodão sobre a área a ser passada para evitar danos às estampas.
A proteção da tábua de passar fica molhada ou gotas de água saem da base.	O vapor condensou na proteção da tábua de passar depois de muito tempo passando roupa. Pode ser que a sua tábua não seja adequada para lidar com o alto fluxo de vapor do gerador de vapor:	Substitua a proteção da tábua se o material de espuma estiver desgastado. Você também pode adicionar uma camada extra de feltro sob a proteção da tábua para impedir a condensação do vapor na tábua. Coloque uma camada extra de feltro sob a proteção da tábua de passar para impedir condensação na tábua.
O vapor continua saindo depois de liberar o botão de vapor.	O vapor é gerado na base. Ao liberar o botão de vapor, a água restante é transformada em vapor. Isso é normal.	Libere o botão de vapor 2 a 3 segundos antes de recolocar na plataforma ou na tábua de passar.
Há um forte fluxo de vapor ao liberar o botão de vapor após colocar o ferro na plataforma.	Quando o ferro é inclinado para frente, a água restante é coletada e convertida em um forte vapor. Isso é normal.	Libere o botão de vapor 2 a 3 segundos antes de recolocar na plataforma ou na tábua de passar.
O vapor é fraco.	Você não pressionou várias vezes o botão de vapor. Você utilizou o modo ECO.	Mantenha pressionado o botão de vapor ao mover o ferro sobre o tecido. Para gerar mais vapor; desative o modo ECO pressionando o botão ECO. A luz verde ECO apaga.
O vapor não sai imediatamente quando pressiono o botão de vapor.	A água é convertida em vapor na base. Quando você pressiona o botão de vapor, leva de 1 a 2 segundos para o vapor ser gerado e liberado. Isso é normal.	Mantenha pressionado o botão de vapor ao mover o ferro sobre o tecido.







www.philips.com



4239.000.9663.1